

Gefen

®

VGA Extender LR

EXT-VGA-141LR

User's Manual



ASKING FOR ASSISTANCE

Technical Support:

Telephone (818) 772-9100
(800) 545-6900

Fax (818) 772-9120

Technical Support Hours:

8:00 AM to 5:00 PM Monday thru Friday Pacific Time

Write To:

Gefen, LLC.
c/o Customer Service
20600 Nordhoff St
Chatsworth, CA 91311

www.gefen.com
support@gefen.com

Notice

Gefen, LLC. reserves the right to make changes in the hardware, packaging and any accompanying documentation without prior written notice.

VGA Extender LR is a trademark of Gefen, LLC.

© 2011 Gefen, LLC. All rights reserved.
All trademarks are the property of their respective owners.

CONTENTS

- 1 Introduction**
- 2 Operation Notes**
- 3 Features**
- 4 Panel Layout**
- 5 Panel Descriptions**
- 6 Connecting And Operating The VGA Extender LR**
- 7 Connecting And Operating The VGA Extender LR**
- 8 Network Cable Wiring Diagram**
- 9 Specifications**
- 10 Warranty**

INTRODUCTION

Congratulations on your purchase of the VGA Extender LR. Your complete satisfaction is very important to us.

Gefen

Gefen delivers innovative, progressive computer and electronics add-on solutions that harness integration, extension, distribution and conversion technologies. Gefen's reliable, plug-and-play products supplement cross-platform computer systems, professional audio/video environments and HDTV systems of all sizes with hard-working solutions that are easy to implement and simple to operate.

The Gefen VGA Extender LR

The VGA Extender allows users to extend video signals beyond the A/V rack. The VGA Extender Series can be used to extend an analog signal to cover distances up to 330 feet. Industry standard Category 5e (CAT-5e) cable is used for the extension.

How It Works

The VGA Extender LR Sender unit connects to your source using the supplied cable. The Receiver unit connects to your display – up to 330 feet away. One CAT-5 cable connects the Sender and the Receiver to each other, extending your video flawlessly.

Note: This is a new VGA Extender that goes double the distance of the previous version, and also has a trim pot for fine video adjustment.

OPERATION NOTES

READ THESE NOTES BEFORE INSTALLING OR OPERATING THE VGA EXTENDER LR

- Display information (EDID) is not sent back to the source. Standard VESA resolutions should be output by most computers without the need of an EDID. If using a non-VESA standard resolution or if EDID is needed, an EDID storage and relay device is necessary. Gefen recommends the use of a DVI Detective (part# EXT-DVI-EDID, EXT-DVI-EDIDN, or EXT-DVI-EDIDP) with two VGA to DVI adapters.
- Use industry standard Category-5 (CAT-5) cable to operate the VGA Extender LR system. CAT-5e cable is preferred.
- Please connect all the cables between the computer and the VGA Extender LR before powering up the VGA Extender LR unit.
- The VGA Extender LR units are housed in a metal box for better RF shielding.

FEATURES





Features

- Extends any VGA or high definition component display up to 330 feet (100 meters)
- One CAT-5e cable for extension
- Supports resolutions up to 1080p, 2K, and 1920 x 1200

Package Includes

- (1) VGA Extender S Sender Unit
- (1) VGA Extender R Receive Unit
- (1) 6 Foot VGA cable (M-F)
- (1) 5V external power supply
- (1) Quick-Start Guide

PANEL LAYOUT



PANEL DESCRIPTIONS

1 5V DC Power Supply Input

Connect the included 5V DC power supply to this input. Power for the receiving unit will be provided over the CAT-5e cable that connects the sending and receiving units together.

2 Sender RJ-45 Input

Connect a CAT-5e cable (terminated according to the TIA/EIA-568-B specification. Please see page 7) between the sending and receiving units.

3 VGA Input

Connect the VGA source to this input. EDID is not transmitted from the display through the VGA Extender LR units. If the display has a non-standard VESA resolution, please purchase an EDID storage device (part# EXT-DVI-EDIDN) to record and transmit the displays EDID back to the source.

4 Brightness Trim Pot Control

Adjusting this control will brighten or dim the output video. Please see page 6 for more details.

5 Receiver RJ-45 Input

Connect a CAT-5e cable (terminated according to the TIA/EIA-568-B specification. Please see page 7) between the sending and receiving units.

6 Power LED

This LED will become active once the included power supply is connected and a properly connected CAT-5e cable is joining the sending and receiving units.

7 VGA Output

Connect the VGA display to this output port.

CONNECTING AND OPERATING THE VGA EXTENDER LR

How to Connect the VGA Extender LR

1. Connect the VGA Extender LR Sender unit to the VGA output on the back of your computer. The six foot M-F VGA cable connects the CPU and Sender unit together.
2. Connect the VGA Extender LR Receiver unit to your monitor with the VGA cable that is attached to your monitor.
3. Connect the CAT-5e cable between the VGA Extender LR Sender and Receiver's CAT5 input.
4. Plug the 5V DC power supply into the Sender unit. The VGA Extender LR Receiver will draw power from the Sender.

BRIGHTNESS ADJUSTMENT CONTROL

A brightness adjustment control (or "trim pot") is found on the Receiver unit and will help compensate for issues that can be introduced by outside interference and cable variances. If the outgoing image is too dark or too bright, the brightness trim pot can be tuned to help brighten the image. To use the brightness trim pot, insert a small philips screwdriver into the brightness trim pot hole. Turn the trim pot in small increments in either a clockwise or counterclockwise direction until the desired brightness is reached. Do not force the trim pot to turn if resistance is encountered; turn it the other way instead. Forcing the trim pot may render the product inoperative.

CABLE SKEW / COLOR CONVERGENCE ADJUSTMENTS

In order to reduce the amount of crosstalk between twisted pairs within the CAT5 cable, the rate of twist for each pair is varied. The rate of twist affects the length of each twisted pair and is referred to as CABLE SKEW. Slight differences in cable skew between pairs of wire can result in undesirable color separation.

The EXT-VGA-LR allows you to manually compensate for cable skew. Underneath the Receiver unit, there are a group of DIP switches. These switches are pre-set to optimal values at the factory but can easily be changed to correct color smearing or separation. To use the DIP switches, peel back the small strip of silver-grey tape. The exposed small sliding switches can be turned ON or OFF with a small pointed instrument such as a very small screwdriver or the head of a mechanical pencil (without lead exposed). The DIP switch banks and instructions for their use are shown on the next page.

Using DIP Switches to Compensate for Video Issues

The first step in adjusting the video quality is to display text and a graphic on your monitor (i.e. desktop icons). Then set your computer to the resolution that you will be using most frequently. Set the DIP (Dual Inline Package) switches to the settings that are recommended for the different lengths of CAT5 cable (see chart below). Verify that the picture quality is to your satisfaction. If the recommended setting does not produce a great quality picture, try using a different DIP switch setting.

The three DIP switch banks affect the primary colors Red, Green and Blue directly and are thus labelled accordingly. Should you find a problem with too much or too little of a certain color present in the output video, begin adjustments in the DIP switch bank corresponding to the color that is present/absent too much.

The settings shown below are our recommendations for best performance.


0-25 Feet	All DIP switches are set to OFF for all colors.
26-100 Feet	Set DIP switch #1 ON for all colors. 2,3,4 remain OFF.
101-200 Feet	Set DIP switch #2 ON for all colors. 1,3,4 remain OFF.
201-300 Feet	Set DIP switch #3 ON for all colors. 1,2,4 remain OFF.
301 Feet and Up	Set DIP switch #4 ON for all colors. 1,2,3,remain OFF.

NOTE: A DIP switch is set to the OFF position when the switch is closest to the number printed immediately below it. The word "ON" will be printed at the top of the DIP switch bank, usually in the lefthand upper corner.


NOTE: The default position of the DIP switches is that of the 26-100 Feet setting above with DIP Switch #1 ON for all colors and switches 2,3,4 OFF.

Underside of Receiver Unit

DIP Switch Bank for Video Adjustments




NETWORK CABLE WIRING DIAGRAM



Gefen has specifically engineered their products to work with the TIA/EIA-568-B specification. Please adhere to the table below when field terminating cable for use with Gefen products. Failure to do so may produce unexpected results and reduced performance.

Pin	Color
1	Orange / White
2	Orange
3	Green / White
4	Blue
5	Blue / White
6	Green
7	Brown / White
8	Brown



CAT-5 and CAT-5e cabling comes in stranded and solid core types. Gefen recommends using solid core cabling. CAT-5e cable is recommended for best results.

Each cable run must be one continuous run from one end to the other. No splices or use of punch down blocks.

SPECIFICATIONS

Video Amplifier Bandwidth	350 MHz
Input Video Signal	1.2 Volts p-p
Input Sync Signal	5 Volts p-p (TTL)
Horizontal Frequency Range.....	15-70 KHz
Vertical Frequency Range.....	30-170 KHz
Video In	HD-15
Focus	25 to 330 FT
Video out	HD-15
Link Connector	RJ-45
Power Consumption	5W (per unit, max.)
Power Supply	5VDC (External)
Dimensions	1.9"H x 1.6"W x 3.5"D
Shipping Weight	2 Lbs

WARRANTY

Gefen warrants the equipment it manufactures to be free from defects in material and workmanship.

If equipment fails because of such defects and Gefen is notified within two (2) years from the date of shipment, Gefen will, at its option, repair or replace the equipment, provided that the equipment has not been subjected to mechanical, electrical, or other abuse or modifications. Equipment that fails under conditions other than those covered will be repaired at the current price of parts and labor in effect at the time of repair. Such repairs are warranted for ninety (90) days from the day of reshipment to the Buyer.

This warranty is in lieu of all other warranties expressed or implied, including without limitation, any implied warranty or merchantability or fitness for any particular purpose, all of which are expressly disclaimed.

1. Proof of sale may be required in order to claim warranty.
2. Customers outside the US are responsible for shipping charges to and from Gefen.
3. Copper cables are limited to a 30 day warranty and cables must be in their original condition.

The information in this manual has been carefully checked and is believed to be accurate. However, Gefen assumes no responsibility for any inaccuracies that may be contained in this manual. In no event will Gefen be liable for direct, indirect, special, incidental, or consequential damages resulting from any defect or omission in this manual, even if advised of the possibility of such damages. The technical information contained herein regarding the features and specifications is subject to change without notice.

For the latest warranty coverage information, refer to the Warranty and Return Policy under the Support section of the Gefen Web site at www.gefen.com.

PRODUCT REGISTRATION

Please register your product online by visiting the Register Product page under the Support section of the Gefen Web site.

* MA - VGA - 141LR*

Rev A3

20600 Nordhoff St., Chatsworth CA 91311

1-800-545-6900 818-772-9100 fax: 818-772-9120

www.gefen.com support@gefen.com



This product uses UL listed power supplies.