

# ADJ MEGA 24PRO



## User Instructions

### Mega 24PRO

### Introduction

**Unpacking:** Thank you for purchasing the Mega 24PRO by American DJ®. Every Mega 24PRO has been thoroughly tested and has been shipped in perfect operating condition. Carefully check the shipping carton for damage that may have occurred during shipping. If the carton appears to be damaged, carefully inspect your fixture for any damage and be sure all accessories necessary to operate the unit has arrived intact. In the case damage has been found or parts are missing, please contact our toll free customer support number for further instructions. Do not return this unit to your dealer without first contacting customer support.

**Introduction:** The Mega 24PRO is part of American DJ's continuing pursuit for creating high quality affordable intelligent LED fixtures. The Mega 24PRO is a DMX intelligent LED color wash. This wash can be used in a stand alone mode or connected in a Master/Slave configuration. The unit can also be controlled via DMX controller. This unit has four operating modes: Color mode, Program mode, RGB mode and DMX control mode.

**Customer Support:** American DJ® provides a toll free customer support line, to provide set up help and to answer any question should you encounter problems during your set up or initial operation. You may also visit us on the web at [www.americandj.com](http://www.americandj.com) for any comments or suggestions. Service Hours are Monday through Friday 9:00 a.m. to 4:30 p.m. Pacific Standard Time.

Voice: (800) 322-6337

Fax: (323) 582-2941

E-mail: [support@americandj.com](mailto:support@americandj.com)

To purchase parts online visit <http://parts.americandj.com>

**Warning!** To prevent or reduce the risk of electrical shock or fire, do not expose this unit to rain or moisture.

**Caution!** There are no user serviceable parts inside this unit. Do not attempt any repairs yourself, doing so will void your manufactures warranty. In the unlikely event your unit may require service please contact American DJ®.

**PLEASE recycle the shipping carton when ever possible.**

## Mega 24PRO

## General Instructions

To optimize the performance of this product, please read these operating instructions carefully to familiarize yourself with the basic operations of this unit. These instructions contain important safety information regarding the use and maintenance of this unit. Please keep this manual with the unit, for future reference.

## Mega 24PRO

## Features

- Multicolors (32 Colors to choose from)
- 4 Operating Modes
- Electronic Dimming 0-100%
- Built in Microphone
- DMX-512 protocol
- 6 DMX Channel Modes: 3, 6, 7, 10, 12, or 16 DMX Channels

## Mega 24PRO

## Warranty Registration

The Mega 24PRO carries a 3 year (1095 days) limited warranty. Please fill out the enclosed warranty card to validate your purchase and warranty. You may also register your product online at [www.americandj.com](http://www.americandj.com). All returned service items whether under warranty or not, must be freight pre-paid and accompany a return authorization (R.A.) number. If the unit is under warranty you must provide a copy of your proof of purchase invoice. Please contact American DJ® customer support for a R.A. number.

## Mega 24PRO

## Cleaning

Due to fog residue, smoke, and dust cleaning the internal and external optical lenses must be carried out periodically to optimize light output.

1. Use normal glass cleaner and a soft cloth to wipe down the outside casing.
2. Clean the external optics with glass cleaner and a soft cloth every 20 days.
3. Always be sure to dry all parts completely before plugging the unit back in.

Cleaning frequency depends on the environment in which the fixture operates (i.e. smoke, fog residue, dust, dew).

## Mega 24PRO

## Safety Precautions

- To reduce the risk of electrical shock or fire, do not expose this unit rain or moisture
- Do not spill water or other liquids into or on to your unit.
- Be sure that the local power outlet match that of the required voltage for your unit.
- Do not attempt to operate this unit if the power cord has been frayed or broken. Do not attempt to remove or break off the ground prong from the electrical cord. This prong is used to reduce the risk of electrical shock and fire in case of an internal short.
- Disconnect from main power before making any type of connection.
- Do not remove the cover under any conditions. There are no user serviceable parts inside.
- Never operate this unit when it's cover is removed.
- Never plug this unit in to a dimmer pack
- Always be sure to mount this unit in an area that will allow proper ventilation. Allow about 6" (15cm) between this device and a wall.
- Do not attempt to operate this unit, if it becomes damaged.
- This unit is intended for indoor use only, use of this product outdoors voids all warranties.
- During long periods of non-use, disconnect the unit's main power.
- Always mount this unit in safe and stable matter.
- Power-supply cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them, paying particular attention to the point they exit from the unit.
- Cleaning -The fixture should be cleaned only as recommended by the manufacturer. See page 3 for cleaning details.
- Heat -The appliance should be situated away from heat sources such as radiators, heat registers, stoves, or other appliances (including amplifiers) that produce heat.
- The fixture should be serviced by qualified service personnel when:
  - A. The power-supply cord or the plug has been damaged.
  - B. Objects have fallen, or liquid has been spilled into the appliance.
  - C. The appliance has been exposed to rain or water.
  - D. The appliance does not appear to operate normally or exhibits a marked change in performance.

**Power Supply:** The American DJ® Mega 24PRO contains a electronic ballast, which will auto sense the voltage when it is plugged into the power source. With the electronic ballast you do not need to worry about wall voltage, this unit can be plugged in anywhere.

**DMX-512:** DMX is short for Digital Multiplex. This is a universal protocol used as a form of communication between intelligent fixtures and controllers. A DMX controller sends DMX data instructions from the controller to the fixture. DMX data is sent as serial data that travels from fixture to fixture via the DATA “IN” and DATA “OUT” XLR terminals located on all DMX fixtures (most controllers only have a DATA “OUT” terminal).

**DMX Linking:** DMX is a language allowing all makes and models of different manufactures to be linked together and operate from a single controller, as long as all fixtures and the controller are DMX compliant. To ensure proper DMX data transmission, when using several DMX fixtures try to use the shortest cable path possible. The order in which fixtures are connected in a DMX line does not influence the DMX addressing. For example; a fixture assigned a DMX address of 1 may be placed anywhere in a DMX line, at the beginning, at the end, or anywhere in the middle. When a fixture is assigned a DMX address of 1, the DMX controller knows to send DATA assigned to address 1 to that unit, no matter where it is located in the DMX chain.

**Data Cable (DMX Cable) Requirements (For DMX Operation):**

The Mega 24PRO can be a 3, 6, 7, 10, 12, or 16 channel DMX unit. The DMX address is set on the rear panel of the Mega 24PRO. Your unit and your DMX controller require a approved DMX-512 110 Ohm Data cable for data input and data output (Figure 1). We recommend Accu-Cable DMX cables. If you are making your own cables, be sure to use standard 110-120 Ohm shielded cable (This cable may be purchased at almost all professional sound and lighting stores). Your cables should be made with a male and female XLR connector on either end of the cable. Also remember that DMX cable must be daisy chained and cannot be split.



Figure 1

**Notice:** Be sure to follow figures two and three when making your own cables. Do not use the ground lug on the XLR connector. Do not connect the cable’s shield conductor to the ground lug or allow the shield conductor to come in contact with the XLR’s outer casing. Grounding the shield could cause a short circuit and erratic behavior.




Figure 2




Figure 3

XLR Pin Configuration	
Pin 1 =	Ground
Pin 2 =	Data Compliment (negative)
Pin 3 =	Data True (positive)

**Special Note: Line Termination.** When longer runs of cable are used, you may need to use a terminator on the last unit to avoid erratic behavior. A terminator is a 110-120 ohm 1/4 watt resistor which is connected between pins 2 and 3 of a male XLR connector (DATA + and DATA -). This unit is inserted in the female XLR connector of the last unit in your daisy chain to terminate the line. Using a cable terminator (ADJ part number Z-DMX/T) will decrease the possibilities of erratic behavior.



Termination reduces signal errors and avoids signal transmission problems and interference. It is always advisable to connect a DMX terminal, (Resistance 120 Ohm 1/4 W) between PIN 2 (DMX-) and PIN 3 (DMX+) of the last fixture.

Figure 4

**5-Pin XLR DMX Connectors.** Some manufactures use 5-pin XLR connectors for DATA transmission in place of 3-pin. 5-pin XLR fixtures may be implemented in a 3-pin XLR DMX line. When inserting standard 5-pin XLR connectors in to a 3-pin line a cable adaptor must be used, these adaptors are readily available at most electric stores. The chart below details a proper cable conversion.

3-Pin XLR to 5-Pin XLR Conversion		
Conductor	3-Pin XLR Female (Out)	5-Pin XLR Male (In)
Ground/Shield	Pin 1	Pin 1
Data Compliment (- signal)	Pin 2	Pin 2
Data True (+ signal)	Pin 3	Pin 3
Not Used		Do Not Use
Not Used		Do Not Use

**LED Display On/Off:** To make the display stay ON all of the time press the MODE and UP buttons at the same time. To make the display turn OFF after 20 seconds, press the MODE and DOWN buttons at the same time.

### Operating Modes:

You can use the Mega 24PRO in either a stand alone mode or a master/slave configuration, there are 7 modes to choose from:

- Color Mode - Select one of 32 different colors to remain static.
- Program Mode - In this mode you can choose 1 of 12 programs to run and also adjust the rate of speed.
- RGB mode - Control the intensity of all three colors adjusting the intensity to your desire to create you own desired color.
- DMX control mode - This function will allow you to control each individual fixtures traits with a standard DMX 512 controller such as as the Elation® Show Designer™.

### Master-Slave Operation:

This function will allows you to link units together to run in a Master-Slave mode. In Master-Slave operation one unit will act as the controlling unit and the others will react to the controlling units built-in programs. Any unit can act as a Master or as a Slave however, only one unit can be programmed to act as the “Master.”

### Master-Slave Connections and Settings:

1. Daisy chain your units via the XLR connector on the rear of the unit. Use standard XLR microphone cables to link your units together. Remember that the Male XLR connector is the input and the Female XLR connector is the output. The first unit in the chain (master) will use the female XLR connector only. The last unit in the chain will use the male XLR connector only. **Note:** *You can also daisy chain the power cords, this can only be done with 20 fixtures. After 20 you will need to use a new power outlet. They must be the same fixtures. DO NOT mix fixtures.*
2. You will also have to link the power cords to each other, as you did with the XLR cables.
3. Using the Master unit, choose your desired mode or program and connect the “Slave” unit or units. The master and slave will sync

automatically.

### Color Mode:

In this mode you can choose a desired color to remain static.

1. Plug the fixture in and press the MODE button until “ColMacro Macro XX” is displayed. “XX” = 0-32.
2. Press the UP or DOWN buttons to scroll through the preset colors and find your desired color.

### Program Mode:

In this mode the Mega 24PRO will change through the different colors.

1. Plug the fixture in and press the MODE button until “ColProgr Progr XX” is displayed. “XX” = 01-12 & All. There are 12 different preset programs to choose from. You can also set it to “All” in which all 12 programs will run.
2. Press the UP or DOWN buttons to find your desired program.
3. When you have found your desired program press the MODE button, “ColSpeed Speed XX” should be displayed. In this menu you can adjust the running speed of the program, “XX” = 1-16. 1 is the slowest speed, 16 the fastest speed.
4. You can also run the program in sound active mode. Press the UP or DOWN buttons until “ColSpeed Speed so” is displayed. You are now running the program in Sound Active mode.

### RGB Mode:

In this mode you can select either red, green, blue, or adjust the colors to make a desired color, which will remain static. You can adjust the intensity of each color to make your desired color.

1. Plug the fixture in and press the MODE button until either “ColSet Red”, “ColSet Green”, or “ColSet Blue” is displayed.
2. You can press the UP or DOWN buttons to adjust the intensity of the displayed color. When you have adjusted your desired color press MODE to move to the next color.

### DMX Mode:

There are six DMX Channel Modes to choose from: 3 Channels, 6 Channels, 7 Channels, 10 Channels, 12 Channels, and 16 Channels. Operating through a DMX controller give the user the freedom to create their own programs tailored to their own individual needs.



**Mega 24PRO****Operating Instructions**

1. This function will allow you to control each individual fixture's traits with a Elation® DMX 512.
2. To run your fixture in DMX mode, plug in the fixture via the XLR connections to any standard DMX controller.
3. Press the MODE button until one of the DMX Channel modes is displayed in the LCD screen; i.e. "DMX-3CH DMX X", X representing the address.
4. Press the UP or DOWN buttons to select your desired address. Once you have found your desired DMX address connect your DMX Controller.
5. Please see pages 10-15 for DMX values and traits.

**Mega 24PRO****Power Cord Daisy Chaining**

*With this feature you can connect the fixtures to one another using the IEC input and output sockets. The quantity that can be connected is 10 fixtures maximum. After 10 fixtures you will need to use a new power outlet. They must be the same fixtures. DO NOT mix fixtures.*

**Mega 24PRO DMX Values & Functions - 3 Channel Mode**

Channel	Value	Function
1	1 - 255	RED 0% - 100%
2	1 - 255	GREEN 0% - 100%
3	1 - 255	BLUE 0% - 100%

**Mega 24PRO DMX Values & Functions - 7 Channel Mode**

Channel	Value	Function
1	1 - 255	RED 0% - 100%
2	1 - 255	GREEN 0% - 100%
3	1 - 255	BLUE 0% - 100%
4	0 1 - 7 8 - 15 16 - 23 24 - 31 32 - 39 40 - 47 48 - 55 56 - 63 64 - 71 72 - 79 80 - 87 88 - 95 96 - 103 104 - 111 112 - 119 120 - 127 128 - 135 136 - 143 144 - 151 152 - 159 160 - 167 168 - 175 176 - 183	<u>COLOR MACROS</u> OFF BASTARD AMBER MEDIUM AMBER PALE AMBER GOLD GALLO GOLD GOLDEN AMBER LIGHT RED MEDIUM RED MEDIUM PINK BROADWAY PINK FOLLIES PINK LIGHT LAVENDER SPECIAL LAVENDER LAVENDER INDIGO HEMSLEY BLUE TIPTON BLUE LIGHT STEEL BLUE LIGHT SKY BLUE SKY BLUE BRILLIANT BLUE LIGHT GREEN BLUE BRIGHT BLUE PRIMARY BLUE

7 Channel Mode is continued on the next page.

Mega 24PRO DMX Values & Functions - 7 Channel Mode		
Channel	Value	Function
4	184 - 191	<u>COLOR MACROS CONT.</u>
	192 - 199	CONGO BLUE
	200 - 207	PALE YELLOW GREEN
	208 - 215	MOSS GREEN
	216 - 223	PRIMARY GREEN
	224 - 231	DOUBLE CTB
	232 - 239	FULL CTB
	240 - 247	HALF CTB
	248 - 255	DARK BLUE
		WHITE
5		<u>STROBING/PROGRAM SPEED</u>
		<u>STROBING</u>
	0 - 15	OFF
	16 - 255	SLOW - FAST
		<u>PROGRAM SPEED</u>
	0 - 239	SLOW - FAST
	240 - 255	SOUND ACTIVE
6		<u>PROGRAMS</u>
	0 - 18	OFF
	19 - 37	PROGRAM 1
	38 - 56	PROGRAM 2
	57 - 75	PROGRAM 3
	76 - 94	PROGRAM 4
	95 - 113	PROGRAM 5
	114 - 132	PROGRAM 6
	133 - 151	PROGRAM 7
	152 - 170	PROGRAM 8
	171 - 189	PROGRAM 9
	190 - 208	PROGRAM 10
	209 - 227	PROGRAM 11
	228 - 246	PROGRAM 12
247 - 255	ALL PROGRAMS	
7	1 - 255	MASTER DIMMER 0% - 100%

Mega 24PRO DMX Values & Functions - 6 Channel Mode		
Channel	Value	Function
1	1 - 255	RED 1 0% - 100%
2	1 - 255	GREEN 1 0% - 100%
3	1 - 255	BLUE 1 0% - 100%
4	1 - 255	RED 2 0% - 100%
5	1 - 255	GREEN 2 0% - 100%
6	1 - 255	BLUE 2 0% - 100%

### Mega 24PRO DMX Values & Functions - 10 Channel Mode

Channel	Value	Function
1	1 - 255	RED 1 0% - 100%
2	1 - 255	GREEN 1 0% - 100%
3	1 - 255	BLUE 1 0% - 100%
4	1 - 255	RED 2 0% - 100%
5	1 - 255	GREEN 2 0% - 100%
6	1 - 255	BLUE 2 0% - 100%
7	1 - 255	COLOR MACROS PLEASE SEE CH. 4 IN 7 CH. MODE
8	0 - 15 16 - 255  0 - 239 240 - 255	<u>STROBING/PROGRAM SPEED</u> <u>STROBING</u> OFF SLOW - FAST <u>PROGRAM SPEED</u> SLOW - FAST SOUND ACTIVE
9		PROGRAMS PLEASE SEE CH. 6 IN 7 CH. MODE
10	1 - 255	MASTER DIMMER 0% - 100

When using Channels 1-7, Channel 8 will control Strobging.  
When using Channel 9, Channel 8 will control Program Speed.

### Mega 24PRO DMX Values & Functions - 12 Channel Mode

Channel	Value	Function
1	1 - 255	RED 1 0% - 100%
2	1 - 255	GREEN 1 0% - 100%
3	1 - 255	BLUE 1 0% - 100%
4	1 - 255	RED 2 0% - 100%
5	1 - 255	GREEN 2 0% - 100%
6	1 - 255	BLUE 2 0% - 100%
7	1 - 255	RED 3 0% - 100%
8	1 - 255	GREEN 3 0% - 100%
9	1 - 255	BLUE 3 0% - 100%
10	1 - 255	RED 4 0% - 100%
11	1 - 255	GREEN 4 0% - 100%
12	1 - 255	BLUE 4 0% - 100%

### Mega 24PRO DMX Values & Functions - 16 Channel Mode

Channel	Value	Function
1	1 - 255	RED 1 0% - 100%
2	1 - 255	GREEN 1 0% - 100%
3	1 - 255	BLUE 1 0% - 100%
4	1 - 255	RED 2 0% - 100%
5	1 - 255	GREEN 2 0% - 100%
6	1 - 255	BLUE 2 0% - 100%
7	1 - 255	RED 3 0% - 100%
8	1 - 255	GREEN 3 0% - 100%
9	1 - 255	BLUE 3 0% - 100%
10	1 - 255	RED 4 0% - 100%
11	1 - 255	GREEN 4 0% - 100%
12	1 - 255	BLUE 4 0% - 100%
13	1 - 255	COLOR MACROS PLEASE SEE CH. 4 IN 7 CH. MODE
14	0 - 15 16 - 255  0 - 239 240 - 255	<u>STROBING/PROGRAM SPEED</u> <u>STROBING</u> OFF SLOW - FAST <u>PROGRAM SPEED</u> SLOW - FAST SOUND ACTIVE
15		PROGRAMS PLEASE SEE CH. 6 IN 7 CH. MODE
16	1 - 255	MASTER DIMMER 0% - 10

### Mega 24PRO

### RGB Macro Chart

COLOR	RED	GREEN	BLUE
BASTARD AMBER	255	206	143
MEDIUM AMBER	254	177	153
PALE AMBER GOLD	254	192	138
GALLO GOLD	254	165	98
GOLDEN AMBER	254	121	0
LIGHT RED	176	17	0
MEDIUM RED	96	0	11
MEDIUM PINK	234	139	171
BROADWAY PINK	224	5	97
FOLLIES PINK	175	77	173
LIGHT LAVENDER	119	130	199
SPECIAL LAVENDER	147	164	212
LAVENDER	88	2	163
INDIGO	0	38	86
HEMSLEY BLUE	0	142	208
TIPTON BLUE	52	148	209
LIGHT STEEL BLUE	1	134	201
LIGHT SKY BLUE	0	145	212
SKY BLUE	0	121	192
BRILLIANT BLUE	0	129	184
LIGHT GREEN BLUE	0	83	115
BRIGHT BLUE	0	97	166
PRIMARY BLUE	1	100	167
CONGO BLUE	0	40	86
PALE YELLOW GREEN	209	219	182
MOSS GREEN	42	165	85
PRIMARY GREEN	0	46	35
DOUBLE CTB	8	107	222
FULL CTB	107	156	231
HALF CTB	165	198	247
DARK BLUE	0	0	189
WHITE	255	255	255



## Mega 24PRO

## Fuse Replacement

First unplug the power. The fuse holder is located next to the power cord. Using a flat-head screw driver unscrew the fuse holder. Remove the bad fuse and replace with a new one.

## Mega 24PRO

## Trouble Shooting

Listed below are a few common problems the user may encounter, with solutions.

### ***Unit not responding to DMX:***

1. Check that the DMX cables are connected properly and are wired correctly (pin 3 is “hot”; on some other DMX devices pin 2 may be ‘hot’). Also, check that all cables are connected to the right connectors; it does matter which way the inputs and outputs are connected.

### ***Unit does not respond to sound:***

1. Quiet or high pitched sounds will not activate the unit.

*If problems are not resolved; Contact American DJ® for service.  
1-800-322-6337*

## Mega 24PRO

## Warranty

### MANUFACTURER'S LIMITED WARRANTY

A. American DJ, Inc. hereby warrants, to the original purchaser, American DJ and American Audio products to be free of manufacturing defects in material and workmanship for a prescribed period from the date of purchase (see specific warranty period on reverse). This warranty shall be valid only if the product is purchased within the United States of America, including possessions and territories. It is the owner's responsibility to establish the date and place of purchase by acceptable evidence, at the time service is sought.

B. For warranty service you must obtain a Return Authorization number (RA#) before sending back the product. Contact American DJ, Inc. Service Department at 800-322-6337. Send the product only to the American DJ, Inc. factory. All shipping charges must be pre-paid. If the requested repairs or service (including parts replacement) are within the terms of this warranty, American DJ, Inc. will pay return shipping charges only to a designated point within the United States. If the entire instrument is sent, it must be shipped in its original package. No accessories should be shipped with the product. If any accessories are shipped with the product, American DJ, Inc. shall have no liability whatsoever for loss of or damage to any such accessories, nor for the safe return thereof.

C. This warranty is void if the serial number has been altered or removed; if the product is modified in any manner which American DJ, Inc. concludes, after inspection, affects the reliability of the product; if the product has been repaired or serviced by anyone other than the American DJ, Inc. factory unless prior written authorization was issued to purchaser by American DJ, Inc.; if the product is damaged because not properly maintained as set forth in the instruction manual.

D. This is not a service contract, and this warranty does not include maintenance, cleaning or periodic check-up. During the period specified above, American DJ, Inc. will replace defective parts at its expense with new or refurbished parts, and will absorb all expenses for warranty service and repair labor by reason of defects in material or workmanship. The sole responsibility of American DJ, Inc. under this warranty shall be limited to the repair of the product, or replacement thereof, including parts, at the sole discretion of American DJ. All products covered by this warranty were manufactured after January 1, 1990, and bear identifying marks to that effect.

E. American DJ, Inc. reserves the right to make changes in design and/or improvements upon its products without any obligation to include these changes in any products theretofore manufactured. No warranty, whether expressed or implied, is given or made with respect to any accessory supplied with products described above. Except to the extent prohibited by applicable law, all implied warranties made by American DJ, Inc. in connection with this product, including warranties of merchantability or fitness, are limited in duration to the warranty period set forth above. And no warranties, whether expressed or implied, including warranties of merchantability or fitness, shall apply to this product after said period has expired. The consumer's and/or Dealer's sole remedy shall be such repair or replacement as is expressly provided above; and under no circumstances shall American DJ, Inc. be liable for any loss or damage, direct or consequential, arising out of the use of, or inability to use, this product.

This warranty is the only written warranty applicable to American DJ and American Audio Products and supersedes all prior warranties and written descriptions of warranty terms and conditions heretofore published.

### MANUFACTURER'S LIMITED WARRANTY PERIODS:

- All American Audio Products = 1-year (365 day) Limited Warranty (except V-Plus Series Amplifiers)
- All American Audio V-Plus Series Amplifiers = 3-year (1095 day) Limited Warranty
- American DJ Lighting and American DJ Branded Products = 1-year (365 day) Limited Warranty (Such as: Special Effect Lighting, Intelligent Lighting, UV lighting, Strobes, Fog Machines, Bubble Machines, Mirror Balls, Par Cans, Trussing, Lighting Stands etc. excluding Laser Products, lamps, and Star Tec Series)
- American DJ Laser Products and Star Tec Products = 90-Day Limited Warranty
- American DJ L.E.D. Products = 3-year (1095 day) Limited Warranty (excluding motors which have a 1-year (365 day Limited Warranty)

**Model: Mega 24PRO**SPECIFICATIONS:

Working Position:	Any safe working position
Voltage:	100V ~ 240V, 50/60Hz
LEDs:	24 x 1W LEDs (8 Red, 8 Green, & 8 Blue)
Power Draw:	40W
Power Cord Daisy Chain:	10 Fixtures Max.
Beam Angle:	10 Degrees Vertical 40 Degrees Horizontal
Fuse:	4 Amp
Weight:	6.5lbs./ 2.92Kgs.
Dimensions:	16" (L) x 7.5" (W) x 2.8" (H) 405 (L) x 190 (W) x 71 (H) mm
Colors:	RGB Color Mixing
DMX Channels:	3, 6, 7, 10, 12, or 16 DMX Channels
Warranty:	3 Year (1095 days)

**Auto Sensing Voltage:** *This fixture contains a electronic ballast, which will auto sense the voltage when it is plugged into the power source.*

**Please Note:** Specifications and improvements in the design of this unit and this manual are subject to change without any prior written notice.

American DJ®  
 American DJ World Headquarters:  
 6122 S. Eastern Ave. Los Angeles, CA 90040 USA  
 Tel: 323-582-2650 / Fax: 323-725-6100  
 Web: [www.americandj.com](http://www.americandj.com) / E-mail: [info@americandj.com](mailto:info@americandj.com)

American DJ Europe  
 Junostraat 2  
 6468 EW Kerkrade  
 Netherlands  
[service@americandj.eu](mailto:service@americandj.eu) / [www.americandj.eu](http://www.americandj.eu)  
 Tel: +31 45 546 85 00 / Fax: +31 45 546 85 99