



Sports Select Receiver Programming Mode Instructions

The Sports Select Receiver provides a Programming Mode to enable a technician to establish which of the receiver's sixteen channels will be available for use. Refer to the table below for a listing of all sixteen channels and their corresponding frequencies. The Sports Select Receiver may be programmed to allow access to all sixteen channels, or a subset of them.

Channel Number	Frequency (MHz)
1	911.450
2	911.950
3	912.950
4	914.450
5	914.950
6	916.450
7	917.450
8	918.950
9	919.450
10	920.450
11	921.950
12	922.950
13	923.450
14	924.950
15	925.950
16	926.450

To program the Sports Select Receiver for the desired channel(s), perform the following procedure:

1. With the receiver turned off, simultaneously press and hold the UP and Down buttons.
2. While continuing to hold the Up and Down buttons pressed, turn on the power by rotating the Volume knob clockwise, past the click. The LED display will indicate "--" (2 dashes, instead of a normal channel number indication). Do not release the Up and Down buttons.

3. Continue holding the Up and Down buttons pressed for an additional 10 seconds.
 - a. When the Up and Down buttons have been continuously pressed for at least 10 seconds, the LED display will change to a rapidly flashing “1.” Programming Mode is now engaged, and the Up and Down buttons may be released.
 - b. If either or both buttons is (are) released in less than 10 seconds (while “– –“ is displayed) the receiver shall revert to normal operation, with no change to the receiver’s channel programming then in effect.
4. Once the Programming Mode is engaged (as indicated by the rapidly flashing “1”), momentarily press the Up (or Down) button to increment (or decrement) the LED display to the number corresponding to the highest-numbered channel that is to be available to the normal user of the receiver.

NOTE: Unlike normal operation, neither auto-increment nor auto-decrement shall occur if the Up or Down button is pressed and held continuously when the Programming Mode is engaged.

When the button is released, the channel corresponding to the number currently flashing in the display shall be stored in the receiver’s non-volatile memory as the highest numbered channel that is to be available to the normal user. For example:

- a. If the Up or Down button is pressed repeatedly until “16” is flashing on the LED display, all channels from 1 through 16 shall be available.
 - b. Conversely, if the Up or Down button is pressed repeatedly until “8” is flashing on the LED display, only channels from 1 through 8 shall be available.
5. Programming Mode will terminate when the receiver’s power switch is turned off, or when neither the Up nor the Down button is pressed for ten seconds, whichever occurs first.