

Contents

Updates.....	1
New functions	1
V2.10 addition	1
V2.00 additions	1
V1.30 addition	1
V1.20 addition	1
V1.10 additions	1
V1.02 addition	2
Maintenance items	2
V2.12 fix	2
V2.11 fix	2
V2.10 fixes	2
V2.00 fixes	2
V1.30 fix	2
V1.20 fixes	2
V1.10 fixes	3
V1.02 fixes	3
V1.01 fixes	3
Confirmation of firmware version	3
Firmware update procedures	3

Updates

Always use the most recent firmware for this device. Please visit the TEAC Global Site at <http://teac-global.com> to check for the latest firmware.

New functions

V2.10 addition

- An erase format function for SD cards has been added.

NOTE

Using the **ERASE FORMAT** function might improve writing speeds.

V2.00 additions

- SDXC cards of up to 128 GB can now be used.
- An auto tone function, which is convenient when editing video on other equipment, has been added.
- An **AUTO DIVIDE** function that can be used to divide a file at all its mark points at once has been added.

V1.30 addition

In order to comply with European standby power regulations (ErP Directive), the auto-

matic power saving function now also operates when an AC adaptor is connected.

By default, the automatic power saving function is set to 30 minutes, and the unit will automatically turn OFF (enter standby) after 30 minutes pass without operation.


If you want to change the setting of the automatic power saving function, use the **AUTO PWR SAVE** item in the **SYSTEM** menu to adjust the amount of time until the unit power automatically turns OFF (enters standby).

For details, see the “New function in version 1.30” section in the addendum to the DR-40 Owner’s Manual.

V1.20 addition

The tuner is now easier to use.

When the **TUNER** screen is open, you can press the **ENTER/MARK** button to reverse the screen orientation, making it easier to tune using the built-in mic.



V1.10 additions

You can now set the EXT IN input levels for the left and right channels independently.

If the input selection on the **REC MODE** screen (**SOURCE** or **EXT IN**) is set to **EXT INDEP.**, you can set the **EXT IN** input levels of the left and right channels independently.

When the Home Screen is open, you can use the **INPUT LEVEL (+/-)** buttons on the left side panel to adjust the input level.

Use the following buttons to switch between adjusting the input levels of the left and right channels.

- When the **REC MODE** item is set to **STEREO**, **DUAL** or **OVERDUB-SEPARATE**, use the **1/2 [SOLO]** button.
- When the **REC MODE** item is set to **4CH** or **OVERDUB-MIX**, use the **3/4 [SOLO]** button.

NOTE

When the **SOURCE** item on the **EFFECT** screen is set to **EXT IN** or **INT MIC** and an effect is applied to the input signal, elements of both left and right channels

will be included in the effect sound, so sound from the opposite channel will be mixed into the recorded signal.

When the input selection on the `REC MODE` screen (`SOURCE` or `EXT IN`) is set to `EXT IN 1/2`, the `EXT IN` input level will be the same for both left and right channels.

The delay time range when the `REC MODE` item is set to `4CH` has been expanded.

The delay time can now be set to a maximum of 150 ms.

The delay time when the `REC MODE` item is set to `4CH` can now be set independently for left and right channels.

If there are differences in the distances from the sound source to the `INT MIC`, to the `EXT IN L` channel and to the `EXT IN R` channel, you can compensate for the time lag by treating the `INT MIC` as the basic position and then adjusting the `EXT IN L` and `EXT IN R` channel delay times.

The input level setting pull-up menu has been changed so that its items correspond to the input source.

V1.02 addition

Right external input channel muting when recording 4 channels

When the `REC MODE` item is set to `4CH` on the `REC MODE` screen, a new function has been added that allows the right external input channel to be muted by setting the `EXT IN` item to `EXT IN 1`. This function allows you to use a mono mic on the left external input channel with the built-in mics for three-channel recording.

The files created, however, will still be two stereo files with the right external input channel muted.

NOTE

- When the `EXT IN` item is set to `EXT IN 1`, effects cannot be used when recording
- If you want the left external input channel to be centered when monitoring, press the **MIXER** button during recording or recording standby and set the channel `SPAN` to `C` (center) on the `MIXER` screen.

Maintenance items

V2.12 fix

- When the dual recording `LVL CTRL` item was set to `LIMITER`, the `DUAL LVL` item setting value would not be highlighted. This has been fixed.
- Operation stability has been improved.

V2.11 fix

- When using the erase format function, writing speed would slow and a `Write Timeout` error would occur sometimes. This has been fixed.

V2.10 fixes

- When using the `RC-3F` footswitch in `MINUTES` mode, briefly pressing the middle switch would return to the beginning. This has been fixed.
- During playback, the volume pop-up sometimes became slow to appear. This has been fixed.
- A `Write Timeout` would occur sometimes when adding a mark and incrementing a track during recording. This has been fixed.
- The input level range for correctly achieving the dual recording effect has been improved. Previously, depending on the `DUAL LVL` setting, the dual recording effect would not be achieved correctly when the input level was 0–24 or less. This range has been changed to 0–12 or less.
- Operation stability has been improved.

V2.00 fixes

- The time interval for the track incrementation setting has been changed.
- Operation stability has been improved.

V1.30 fix

- Operation stability has been improved.

V1.20 fixes

- When overdubbing in `SEPARATE` mode with an MP3 file recorded on a device other than this unit as the playback file, jumping back and searching backward or forward (rewinding or fast forwarding), for example, caused the audio of channel pairs 1/2 and 3/4 to become out of sync. This has been fixed.

NOTE

about projects with overdubbing in `SEPARATE` mode using firmware versions 1.10 and earlier

- If the bit rate of the playback file is one that this unit can use for recording (32, 64, 96, 128, 192, 256 or

320 kbps) jumping back and searching backward or forward, for example, will not cause the audio of channel pairs 1/2 and 3/4 to become out of sync using firmware versions 1.10 and earlier.

- If the bit rate of the playback file is one that this unit cannot use for recording (48, 56, 80, 112, 160 or 224 kbps) jumping back and searching backward or forward, for example, will cause the audio of channel pairs 1/2 and 3/4 to become out of sync using firmware versions 1.10 and earlier. Use firmware version 1.20 or later when overdubbing to avoid this.
- After VSA playback, searching forward or backward sometimes caused the volume to decrease during later playback operations. This has been fixed.
- The sensitivity of the tuner has been improved.

V1.10 fixes

- If a mixdown was executed when the open capacity of an SD card was more than 4 GB, a `CARD FULL` error would occur and the mixdown would fail in some cases. This has been fixed.
- Operation stability has been improved.

V1.02 fixes

- If the `REC MODE` item was set to `DUAL` and the `SOURCE` item was set to `INT MIC MONO` or `EXT IN 1` on the `REC MODE` screen, the `DUAL` peak value in decibels would not be shown correctly on the recording screen. This has been fixed.
- When a file recorded in MP3 format was played back using the I/O loop function, sometimes loop playback did not occur properly. This has been fixed.
- Operation reliability has been improved.

V1.01 fixes

- If recording was conducted when the `REC MODE` item on the `REC MODE` screen was set to `STEREO` or `MONO`, the remaining recording time display could show less than the actual amount and a `Card Full` message might appear and recording might stop even if the SD card still had remaining capacity. This has been fixed.
- During recording with certain SD cards, a `File Error` would occur. This has been fixed.
- Operation reliability has been improved.

Confirmation of firmware version

Confirm the firmware version of your DR-40 before conducting a firmware update.

- 1 Turn the unit's power ON.
- 2 Press the **MENU** button to open the **MENU** screen.
- 3 Use the **+/-** buttons to select the **OTHERS** menu item, and press the **ENTER/MARK** button to open the **OTHERS** submenu.
- 4 Use the **+/-** buttons to select the **INFORMATION** menu item, and press the **ENTER/MARK** button to open the **INFORMATION** screen **FILE** page.
- 5 Use the **+/-** buttons to open the **SYSTEM** page where you can check the **System Ver.** item that shows the firmware version.

If the **System Ver.** shown here is the same or newer than the firmware version that you planned to update to, then there is no need to update it.

Firmware update procedures


CAUTION

When updating the firmware, be sure that the batteries have sufficient charge or power the unit using a TASCAM PS-P515U AC adaptor (sold separately) or USB bus power from a computer.

The program has been set so that the update will not be conducted if battery power is insufficient.

- 1 Download the most recent firmware from the TEAC Global Site (<http://teac-global.com/>). If the file that you have downloaded is compressed in ZIP format, for example, decompress it.
- 2 Turn the unit's power ON and use the included USB cable to connect it with a computer. This unit will be recognized as an external drive (external storage device) by the computer.
- 3 Copy the downloaded firmware (DR40_074.130 for V1.30) to the **UTILITY** folder on the DR-40.
- 4 After copying has completed, disconnect the unit from the computer following the correct procedures, and turn the unit power OFF.
- 5 While pressing and holding both the **MIXER** and **◀◀** buttons, turn the unit power ON.

The unit starts up in update mode, and the update file appears on the screen.



CAUTION


- If this screen does not appear, turn the power OFF. Then while pressing and holding both the **MIXER** and

◀◀ buttons, turn the unit's power ON again. Continue to press and hold the **MIXER** and ◀◀ buttons firmly until this screen appears.

- When firmware has been copied to this unit's *UTILITY* folder from a Mac, in addition to the firmware file itself, another file with "." added to the beginning of the firmware name is also shown. Use the file without the "." at the beginning of the name.

NOTE

- This screen shows a list of the firmware update files inside the *UTILITY* folder of the unit. Also, the screen shows the firmware copied at Step 3 above. No Update File appears if there is no update file in the *UTILITY* folder.
 - The screen shown is an example. The actual display differs.
- 6 Use the +/- buttons to select the firmware and press the ENTER/MARK button to open the following screen.**



The current version appears on the left and the updated version appears on the right.

NOTE

The screen shown is an example. The actual display differs.

- 7 Press the ENTER/MARK button to start the update.**
- 8 When the update is complete, Update Complete appears at the bottom of the screen, and then the power turns OFF automatically. Turn the power ON again.**
- 9 Follow the "Confirmation of firmware version" instructions above to check that the System Ver. is now the most recent version of the firmware.**

This completes the procedure for updating this unit.

- 10 Connect to a computer with USB and delete the firmware update from the unit's *UTILITY* folder.**