

## 1 Port Serial Ethernet Device Server - Power Over Ethernet

NETRS2321POE

NETRS23POEGB



\*actual product may vary from photos

DE: Bedienungsanleitung - [de.startech.com](http://de.startech.com)

FR: Guide de l'utilisateur - [fr.startech.com](http://fr.startech.com)

ES: Guía del usuario - [es.startech.com](http://es.startech.com)

IT: Guida per l'uso - [it.startech.com](http://it.startech.com)

NL: Gebruiksaanwijzing - [nl.startech.com](http://nl.startech.com)

PT: Guia do usuário - [pt.startech.com](http://pt.startech.com)

For the most up-to-date information, please visit: [www.startech.com](http://www.startech.com)

## FCC Compliance Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

## Use of Trademarks, Registered Trademarks, and other Protected Names and Symbols

This manual may make reference to trademarks, registered trademarks, and other protected names and/or symbols of third-party companies not related in any way to StarTech.com. Where they occur these references are for illustrative purposes only and do not represent an endorsement of a product or service by StarTech.com, or an endorsement of the product(s) to which this manual applies by the third-party company in question. Regardless of any direct acknowledgement elsewhere in the body of this document, StarTech.com hereby acknowledges that all trademarks, registered trademarks, service marks, and other protected names and/or symbols contained in this manual and related documents are the property of their respective holders.

# Table of Contents


|  |           |
|--|-----------|
| <b>Introduction</b> .....                        | <b>1</b>  |
| Package contents .....                           | 1         |
| Front Panel .....                                | 1         |
| Rear Panel .....                                 | 2         |
| LED Indicators .....                             | 2         |
| <b>Hardware Installation</b> .....               | <b>3</b>  |
| <b>Configuring the Adapter</b> .....             | <b>3</b>  |
| Setting the IP Address .....                     | 3         |
| Managing the Adapter Settings .....              | 5         |
| Controller Setup Menu Items .....                | 6         |
| <b>Software Installation</b> .....               | <b>8</b>  |
| VSP Virtual COM Port Driver .....                | 8         |
| Installing the VSP Virtual COM Port Driver ..... | 8         |
| <b>Specifications</b> .....                      | <b>11</b> |
| <b>Technical Support</b> .....                   | <b>12</b> |
| <b>Warranty Information</b> .....                | <b>12</b> |

# Introduction

## Package contents


- Driver CD
- Industrial Switch
- Instruction Manual
- Power Adapter

## Front Panel




1. Switch to Restore Default Settings - This switch can be used to reset the product to its factory default settings. Pressing the switch using either a pen or similar tool will immediately restore the unit to its default settings.
2. RJ45 LAN Connector - 10/100Mbps Ethernet port. It supports the auto cross-over feature, and allows use of the same cable to connect to either a Hub/Switch or a host computer.
3. Heartbeat LED
4. +7~12VDC Power Input DC Jack

## Rear Panel



1. RS-232 Connector

## LED Indicators



1. 10/100 Mbps LED (amber colour)
2. Link / Activity LED (green colour)
3. Heartbeat LED (green colour)

| LED Name      | Colour | Function   |
|---------------|--------|--|
| 10/100 Mbps   | Green  | On: 100 Mbps Off: 10 Mbps                            |
| Link/Activity | Green  | On: Linked Blinking: Transferring Data               |
| Heartbeat     | Amber  | Blinking: Normal Operation Not Blinking: Malfunction |

# Hardware Installation

1. Use static electricity discharge precautions. Remove possible static discharge potential from any objects that the adapter may come in contact with prior to installation. This can be accomplished by touching a bare metal chassis rail after you have turned off the power.
2. If you will be externally powering the device, connect the DC power adapter. If connecting to a PoE switch, hub, or other device, then a power adapter is not required, as the product will draw its power from the host device it is connected to. In this case, ensure that your switching hub is the PoE type that can act as PSE (Power Source Equipment).
3. Connecting LAN cable: Use a standard straight-through Ethernet cable to connect to a Hub or Switch. If you connect the adapter to your computer's Ethernet port instead, you don't need to change to a cross-over type cable since the adapter provides the auto cross-over feature.
4. Connect the Adapter's serial port to your serial device.
5. Use the DIN RAIL mounting Kit if you want to place the product on the industrial DIN RAIL. (optional)

## Configuring the Adapter

### Setting the IP Address

Please consult your Network Administrator to determine the appropriate IP address. The adapter comes with the factory installed IP address 192.168.1.254. It is ready to accept a new IP address from a DHCP Server. If your network has a DHCP server, it will automatically assign an IP address to the Adapter the first time it is connected and powered up.


#### 1. Setting the IP Address from a DHCP Server

A DHCP server will automatically assign an IP address (dynamic address) as well as Subnet Mask and Gateway to this adapter. If you power up the Adapter without a fixed (static) IP address, the DHCP server will be able to assign an IP address (Note: By default, DHCP is disabled. If you wish to support DHCP, Enable it in the Adapter Setup Menu).

**Note:** If you will set the IP address using another method, you will need to use a static IP address. To do this, Disable DHCP (this is the default setting) in the Adapter Setup Menu.

## 2. Setting the IP Address using a Web Browser

Please ensure that your PC's IP address is set to the same subnet as the adapter. If not, you will need to change your PC's IP address from Local Area Connection Properties menu, shown below:



Run your browser and access the product by entering the default (**192.168.1.254**) or current IP address into your browser's address window. Enter the password (default has no password), then go to **Change your IP Address**, and make the necessary changes.

## 3. Setting the IP Address using the ETM.exe Utility

The **ETM.exe** is a Microsoft Windows based utility used to identify the adapters connected on the same subnet and network segment. To run the ETM.exe utility, please insert the driver CD supplied with the Adapter. Open the program at the following location (assume the CD-ROM drive is at E):

**E:\IO\_over\_IP\Utilities\EM\EM.exe**



## Managing the Adapter Settings

When you enter the **Adapter Setup Menu**, the following page will be available for your access. By default there is no password for entry.

| Controller Status   |                   |
|---------------------|-------------------|
| System time elapsed | 00:00:18          |
| Firmware version    | Oct 24 2007 18:43 |
| Serial number       | N51F4-3D8101D9    |

**Setup Login**

Password

Once you have entered the **Controller Setup Menu** and made the necessary changes, click the **Update** button. Also ensure that you make note of your password as you will need it to enter the setup menu again.



# Controller Setup Menu Items

| Controller Setup   |                  |
|--|------------------|
| IP address   | 192.168.1.254    |
| Subnet mask  | 255.255.255.0    |
| Gateway address  | 0.0.0.0          |
| Network link speed   | Auto             |
| DHCP client  | Disable          |
| Socket port of HTTP setup  | 80               |
| Socket port of serial I/O  | 100 COM Port     |
| Socket port of digital I/O   | 101 Disabled     |
| Destination IP address / socket port (TCP client and UDP) Connection | 0.0.0.0 0 Manual |
| TCP socket inactive timeout (minutes)                                | 0                |
| Serial I/O settings (baud rate, parity, data bits, stop bits)        | 9600 N 8 1       |
| Interface of serial I/O  | RS 232           |
| Packet mode of serial input  | Enable           |
| Device ID  | 1                |
| Report device ID when connected                                      | Disable          |
| Setup password   |                  |
| <input type="button" value="Update"/>                                |                  |

| Menu Item                        | Description   |
|----------------------------------|---|
| <b>IP Address</b>                | 4 numbers separated by dots. If enabled, these can be assigned by the DHCP server.      |
| <b>Subnet Mask</b>               | 4 numbers separated by dots. If enabled, these can be assigned by the DHCP server.      |
| <b>Gateway Address</b>           | 4 numbers separated by dots. If enabled, these can be assigned by the DHCP server.      |
| <b>DHCP Client</b>               | If disabled, the IP address, Subnet mask and Gateway address must be assigned manually. |
| <b>Socket Port of HTTP Setup</b> | If disabled, the IP address, Subnet mask and Gateway address must be assigned manually. |

| <b>Menu Item</b>   | <b>Description</b>   |
|--|--|
| <b>Socket Port of Serial I/O</b>                                     | <p>Port Number:<br/>Any number between 1 and 65536, except 80 and 8080 (these have been designated as the web pages).</p> <p>Socket Type:<br/>TCP Server - Uses TCP protocol, passively waits for Client.<br/>TCP Client - Uses TCP protocol, actively connects to Server.<br/>UDP Client - Uses UDP protocol, exchanges packets with Server without connection.</p> |
| <b>Socket Port of Digital I/O</b>                                    | Spared function for the future expansion. Currently has no function.   |
| <b>Destination IP Address/Socket Port (TCP client and UDP)</b>       | The Server IP address under TCP client or UDP client mode.   |
| <b>Serial I/O Settings (baud rate, parity, data bits, stop bits)</b> | <p>Baud Rate: 300 – 115200 bps</p> <p>Parity Bits: No Parity, Even, Odd</p> <p>Data Bits: 5, 6, 7, 8</p> <p>Stop Bit: 1 or 2</p>   |
| <b>Interface of serial I/O</b>                                       | RS-232   |
| <b>Packet mode of serial input</b>                                   | If packet mode is disabled, the data received from the serial port will be transmitted immediately with minimal delay. If packet mode is enabled, the data will be saved in the buffer memory first, and transmitted when the entire packet is received or when the buffer memory is full.   |
| <b>Packet mode inter-packet timeout</b>                              | In packet mode, the time constant used to determine if the packet is finished. Acceptable range is 10 to 1000 ms.  |
| <b>Device ID</b>   | User assigned device ID number. Acceptable range is 0 to 65535.  |

| Menu Item                              | Description  |
|--|--|
| <b>Report device ID when connected</b> | <p>If this function is enabled, the device will report the device ID after the socket is connected. The format is:</p> <p>Serial I/O socket nnnnnA[LF][CR]<br/>           Digital I/O socket nnnnnB[LF][CR]</p> <p>There are eight bytes: nnnnn is the 5-digit device ID, [LF] is decimal 10, and [CR] is decimal 13</p> |
| <b>Setup password</b>                  | <p>The login password can be empty or 1 to 15 characters long. If the password is empty then no password is required for login.</p>  |

## Software Installation


### VSP Virtual COM Port Driver

The VSP is a redirector driver that allows your applications to use serial devices provided by serial device servers on your network. This redirection is achieved by creating one or more virtual COM port(s) that allow these networked serial devices to function as though they are directly connected to the local computer.

Since the redirector's virtual COM port(s) function much like standard Windows COM ports, your application software sees no difference between a local serial device and one provided by a serial server.

### Installing the VSP Virtual COM Port Driver

1. Locate the necessary Software in the following folder on your driver CD. The VserPortConsole.exe is the redirector software. The Em.exe is used to setup the hardware mode to support VSP redirector.




- Configure your hardware mode to support VSP.
  - Run the ETM.exe application to find the device hardware



- Enter the setup menu by double clicking the listed hardware.
- Click Login (by default settings, there is no password).




- Change the settings to **COM Port**, save the changes, and exit the setup menu.




### 3. Run the **VSP Setup Program**.

- Double click the **VserPortConsole.exe** application in the VSP folder on the supplied CD. You may receive a message indicating that this driver has not yet passed Windows logo testing. If so, click **Continue Anyway**.


- Select the COM ports to be redirected by checking the boxes next to them:



- Set the COM Port settings: The following figure shows only one COM port setting being changed. You may have 4 COM ports (or 1, 2 ports depending on the model), you will need to set it 4 times for, once for each COM port.



- Checking installation: Go to the Device Manager (right click My Computer, Hardware, Device Manager) to check the installation, a successful settings will look something like the following figure:



# Specifications

| <b>Specification</b>         |  | <b>NETRS2321POE</b>   |
|------------------------------|--|---|
| <b>Connector</b>             |  | RJ45  |
| <b>Speed</b>                 |  | 10/100 Mbps   |
|                              |  | <b>RS-232</b>   |
| <b>Number of Ports</b>       |  | 1 x RS-232  |
| <b>Signals</b>               |  | TXD, RXD, RTS, CTS, DTR, DSR, DCD, GND                                  |
| <b>Connector</b>             |  | DB9 Male (RS-232)   |
| <b>Parity</b>                |  | None, Odd, Even   |
| <b>Data Bits</b>             |  | 6, 7, 8   |
| <b>Stop Bits</b>             |  | 1, 2  |
| <b>Speed</b>                 |  | 300 to 115.2Kbps  |
|                              |  | <b>Power Requirements</b>   |
| <b>Power Input</b>           |  | 12V DC (via DC Jack), or<br>48V DC (via Ethernet Cable, PoE model only) |
| <b>Power Consumption</b>     |  | 110mA @ 12V DC  |
|                              |  | <b>Mechanical Specifications</b>  |
| <b>Material</b>              |  | Metal   |
| <b>Gross Weight</b>          |  | 250.5g (0.55 lb)  |
|                              |  | <b>Environmental</b>  |
| <b>Operating Temperature</b> |  | 0° to 55°C (32° to 131°F)   |
| <b>Storage Temperature</b>   |  | -20° to 85°C (-4° to 185°F)   |
| <b>Operating Humidity</b>    |  | 5% to 95% RH  |

# Technical Support

StarTech.com's lifetime technical support is an integral part of our commitment to provide industry-leading solutions. If you ever need help with your product, visit [www.startech.com/support](http://www.startech.com/support) and access our comprehensive selection of online tools, documentation, and downloads.

For the latest drivers/software, please visit [www.startech.com/downloads](http://www.startech.com/downloads)

## Warranty Information

This product is backed by a two year warranty.

In addition, StarTech.com warrants its products against defects in materials and workmanship for the periods noted, following the initial date of purchase. During this period, the products may be returned for repair, or replacement with equivalent products at our discretion. The warranty covers parts and labor costs only. StarTech.com does not warrant its products from defects or damages arising from misuse, abuse, alteration, or normal wear and tear.

### Limitation of Liability

In no event shall the liability of StarTech.com Ltd. and StarTech.com USA LLP (or their officers, directors, employees or agents) for any damages (whether direct or indirect, special, punitive, incidental, consequential, or otherwise), loss of profits, loss of business, or any pecuniary loss, arising out of or related to the use of the product exceed the actual price paid for the product. Some states do not allow the exclusion or limitation of incidental or consequential damages. If such laws apply, the limitations or exclusions contained in this statement may not apply to you.

Hard-to-find made easy. At StarTech.com, that isn't a slogan. It's a promise.

StarTech.com is your one-stop source for every connectivity part you need. From the latest technology to legacy products — and all the parts that bridge the old and new — we can help you find the parts that connect your solutions.

We make it easy to locate the parts, and we quickly deliver them wherever they need to go. Just talk to one of our tech advisors or visit our website. You'll be connected to the products you need in no time.

Visit [www.startech.com](http://www.startech.com) for complete information on all StarTech.com products and to access exclusive resources and time-saving tools.

*StarTech.com is an ISO 9001 Registered manufacturer of connectivity and technology parts. StarTech.com was founded in 1985 and has operations in the United States, Canada, the United Kingdom and Taiwan servicing a worldwide market.*