

QUICK START

Before complaining about having to install the **SRM 66** in the rack *twice* (because you forgot to set the internal highpass filters ahead of time), take note that the very first (non-joke) line in this manual is: *Before installing the SRM 66 in a rack, be sure the internally switchable 80 Hertz highpass filters are set as desired. They are shipped with the filters in the OUT (disabled) position. (See the bottom of page Manual-2 to enable these filters.)* If you were smart enough to read this much of the manual, this paragraph may already have saved you a few minutes of your life – you’re welcome. If you’ve learned the hard way, hopefully you’ve learned an important lesson – read at least the first line in the manual first.

Make all connections with the power and amplifiers *off*. The **SRM 66** is fully balanced and equipped with removable 5-position Euroblock connectors. Inputs and Outputs are arranged on Euroblocks in pairs, i.e., 1&2, 3&4, 5&6.

Be sure the **FP LOCK** switch (on rear) is in the *out* position to enable programming from the front panel.

Apply power so the **PWR** LED lights and LCD screen glows with the **SRM 66** welcome marquee. During initialization, the startup muting circuit immediately starts counting down from 40 in the Limiter Gain Reduction area of the display. Adjust the **VIEWING ANGLE** with a miniature screwdriver if necessary.

With signal applied to the Inputs, watch the **MIX INPUT HEADROOM** indicators. These verify correct setting of the Output of the previous device and the rear panel Input **GAIN** switches. Adjust so that **4 dB** lights during peaks.

Navigating the LCD Edit pages is simple. The top buttons marked << and >> are the left/right Page scroll buttons. These navigate to Output pages 1 through 6, the assign *Outputs to Output Group* page, the assign *Remote to Group* page, the assign *Group to Master Remote* page, the *Group Levels* page, and the *Memory* page.

The bottom buttons marked < and > are the left/right cursor buttons. These select the (underlined) parameter to edit.

Rotating the **DATA** knob changes the parameter setting.

Let’s start by navigating to Output 1’s page. Move the cursor under **IN1**. With a signal driving Input 1 and a working amplifier connected to Output 1, adjust the **DATA** knob to the desired level. Adjust any other Input going to Output 1. **MST** controls the Master level of Output 1. **LIM** sets the Limit Threshold of the Limiter circuit for Output 1.

To Copy settings from Output 1 to any other Output, move the cursor to **Copy**. Press the **EXE** button. The display now reads **Paste**. Change the page to the one you want these same settings in, and press **EXE** again. The settings have now been pasted into the new Output.

Settings may be Stored and Recalled in the Memory Page. To Store, select the **Store** field, select a Memory number with the **DATA** wheel and press **EXE**. To Recall, select the **Recall** field, select a Memory number with the **DATA** wheel and press **EXE**. Look deeper into this manual for information on remote control of Memories, level adjustments and, the most powerful feature of the SRM 66, Output Groups which “link” Output levels. A Master Remote feature allows controlling the level of any Output Groups assigned to it.

To maintain signal control over the specified dynamic range, *the Master output should be turned off when no inputs are routed to a given output.*

CAUTION: *Never connect anything except an approved Rane Power Supply to the thing that looks like a red telephone jack on the rear of the SRM 66.* This is an 18 VAC center tapped power input. Consult the Rane factory for a replacement or substitute.

SRM 66 CONNECTION

Balanced Operation

Connect the ‘+’ to ‘+’, ‘-’ to ‘-’, and shield to shield. Use only when driving from a true balanced source and driving to a true balanced destination — either transformer coupled or active drive.

Unbalanced Operation

To avoid nasty side effects such as hum and noise – which are consequences of unbalanced operation – keep cable lengths as short as possible. For lengths longer than ten feet, use a transformer such as a Rane BB 44x.

Coming from an unbalanced source, the SRM 66’s Input


uses two conductors plus a shield; connect ‘+’ to ‘+’, the unbalanced source ground to ‘-’, and the cable shield to the SRM 66’s ground.

Going to an unbalanced device using a single conductor plus a shield, connect ‘+’ to ‘+’, leave ‘-’ unconnected and connect the cable shields at both ends to ground.

Combination Operation

For combined balanced and unbalanced operation, use whichever half of the above instructions apply for each end. See the “Sound System Interconnection” RaneNote included with this manual for more information on cabling and grounding requirements.


FRONT PANEL DESCRIPTION




- ① **MIX INPUT HEADROOM meters.** These assist setting of the rear panel GAIN switches as well as the output level of the preceding device. The 16 dB and 4 dB LEDs indicate the *remaining headroom* for each of the six Inputs. Optimal settings allow the 4 dB LEDs to flash only during signal peaks.
- ② **Edit Pages.** This 2x40 backlit LCD screen displays the Edit pages for controlling and revealing all the functions of the SRM 66 (see ⑤). Refer to the OPERATION section on page Manual-4 for details.
- ③ **VIEWING ANGLE adjust.** This recessed adjustment allows optimizing the LCD display contrast for various vertical viewing angles.
- ④ **DATA wheel.** Allows adjustment of a field parameter after it is selected with the Page (see ⑤) and Cursor (see ⑥) buttons. Turning the DATA wheel clockwise increases the parameter, and turning it counterclockwise decreases the parameter.
- ⑤ **Page buttons.** The Previous Page << and Next Page >> buttons scroll through all 10 Edit pages. When the EXE button is held and MAX >> is pressed, the selected parameter jumps to its highest value (see ⑦).
- ⑥ **Cursor buttons.** The Previous < and Next > cursor buttons scroll through each of the adjustable fields on each page. These buttons select each adjustable parameter along the bottom row by moving the underline left < or right >. When any parameter is selected, the DATA wheel adjusts that parameter. When the EXE button is held and MIN > is pressed, the selected parameter jumps to its lowest value (see ⑦).
- ⑦ **EXE (Execute) button.** Several commands are implemented with this button. Holding down EXE while pressing MAX >> alters the selected parameter to its highest nominal value. Holding down EXE while pressing MIN > alters the selected parameter to its lowest value or Off. Pressing EXE when the Copy, Paste, Recall, Store, and Zero commands are selected executes that function.
- ⑧ **Power indicator.** In case the backlit Edit display isn't enough assurance, this yellow indicator glows anytime adequate power is applied to the SRM 66, alerting you to its *on* condition.

INTERNAL 80 Hz HIGHPASS FILTERS

Each Output of the SRM 66 features an internally switchable 80 Hz highpass filter. These filters roll off low frequencies. This is useful in small sound reinforcement systems or for use with constant voltage line transformers. These switches are shipped from the factory in the OUT position. If you wish to enable any or all of the filters for each Output, it will be necessary to remove the unit's top cover before installation. Locate the switches near the center of the board, as shown below. S2 = Output 1, S4 = Output 2, S6 = Output 3, S8 = Output 4, S10 = Output 5, and S12 = Output 6.



REAR PANEL DESCRIPTION



- ① **POWER input connector.** Use only an RS 1, or other Remote AC power supply approved by Rane. This unit is supplied with a remote power supply suitable for connection to this input jack. Consult the factory for a replacement or a substitute. This unit's power input is designed for an AC supply, delivering 18 volts, from a center-tapped transformer capable of supplying at least the 750 mA of current demanded by this product. Using any other type of supply may damage the unit and void the warranty.
- ② **Chassis ground point.** A #6-32 screw is supplied for chassis grounding purposes. Units with external power supplies such as this SRM 66 supply do not ground the chassis to earth through the line cord. This chassis connection is critical and in most installations, required by law. Many chassis ground this point to an amplifier chassis ground or directly to the grounding screw on a grounded AC outlet cover by means of a wire secured on both ends with star washers to guarantee proper contact. See the CHASSIS GROUNDING note below.
- ③ **FP LOCK button.** When pressed *in*, locks out all front panel control except for Group Levels and Memory Recall. The SR 1L remotes (sold separately) are also able to control Group Levels with FP LOCK engaged. The user is able to view, but not edit, all Edit pages.
- ④ **MEMORY RECALL PORT (MRP).** This Port allows any remote switch to recall any of the system Memories. The first eight Memories recall with simple switch closure to a single pin. A "binary" wiring mode allows access to more complex Memory recall functions. See Figure 8 on page Manual-6. Complete programmability of the MRP is possible using the *Edit MRP Configuration* feature found in SRM Exchange software. See *DSC 1 & SRM Exchange software* on page Manual-7.
- ⑤ **REMOTE INTERFACE PORT (RIP).** This Port supports up to seven optional SR 1L "Smart" digital Remote controls as seen in Figure 4 on page Manual-5. Each Remote may be assigned to adjust the Level of any one of the six SRM 66 Output Groups or the Master Group.
- ⑥ **OUTPUT GAIN switches.** These assist setting the optimal gain structure of the Output stage, depending on what the following device would like to see (or hear). Balanced signals usually require a +4 dBu setting (button *out*), and unbalanced signals usually require the -10 dBV setting (button *in*).
- ⑦ **OUTPUTS.** These balanced Euroblock connectors may be wired balanced or unbalanced. See page Manual-1 or RaneNote 110, "Sound System Interconnection" later in this manual for assistance.
- ⑧ **INPUT GAIN switches.** These assist setting the optimal gain structure of the Input stage, depending on the level from the previous device. Balanced signals usually require a +4 dBu setting (button *out*), and unbalanced signals usually require the -10 dBV setting (button *in*). Use the MIX INPUT HEADROOM meters as a guide for determining GAIN switch position (see ① in the Front Panel Description).
- ⑨ **INPUTS.** These balanced Euroblock connectors may be wired balanced or unbalanced. See page Manual-1 or RaneNote 110, "Sound System Interconnection" elsewhere in this manual for assistance.

CHASSIS GROUNDING

If after hooking up your system it exhibits excessive hum or buzzing, there is an incompatibility in the grounding inside a unit(s) or between units somewhere. Your mission is to discover how your particular system wants to be grounded. Try these things:

1. Try combinations of lifting grounds on units that are supplied with ground lift switches or links. Other than in your own home, it is illegal and unsafe to use 2-prong to 3-prong AC line cord cheaters, even though this is a common (short term) remedy. Using such "cheaters" can (and has been known to) electrocute or kill people. [Ace Frehley and Keith Richards survived; Keith Relf (The Yardbirds) and John Rostill (The Shadows) did not.]
2. If your equipment is in a rack, verify that all chassis are tied to a good earth ground, either through the AC line cord grounding pin (3rd prong) or the rack screws to another grounded chassis.
3. Units with outboard power supplies may *not* ground the chassis through the line cord. Make sure that these units are grounded either to another chassis which is earth grounded, or directly to the grounding screw on a grounded AC outlet cover.

Please refer to RaneNote 110 "Sound System Interconnection" (elsewhere in this manual) for further information.

OPERATION

The User Interface

All SRM 66 programming is done with the Data wheel and the front panel buttons using one of the eleven LCD pages. Each page consists of the page name, multiple parameter fields and possible Command fields and status indicators.

To navigate between pages use the Next Page (>>) and Previous Page (<<) buttons. Within a page the Next (>) and Previous (<) buttons move the cursor to each field.

Above each parameter field is a label indicating its function. Once the cursor is positioned beneath the desired parameter field, the Data wheel is turned clockwise to increase the value and counter-clockwise to decrease it. To quickly jump to extreme maximum or minimum values, hold down the Shift (EXE) Button and press either the MAX (>>) or MIN (>) buttons. For added safety, executing MAX for the Input mix levels sets the level to unity or zero gain, not +6 dB which is the actual maximum.




Figure 1. Output Edit Page

Command Fields

Most pages contain a Command field. Here you can Copy settings from the current page to the clipboard, Paste settings from the clipboard, Recall page settings from memory, and Zero all page settings.

To access a command, position the cursor under the Command field, use the Data wheel to select the desired command (not all commands are available in all pages) and press the EXE button.

Clipboard

There are actually three separate clipboards in the SRM 66: one for an Output's settings (shared by all Outputs), one for the Remote to Group settings, and one for the Output to Group settings. Using the clipboard can greatly simplify and speed setting up multiple Outputs or multiple Memories. *The clipboard settings are lost whenever power is removed.*

Status Indicators

Next to the page name in many pages is a Status Indicator. In the Output pages it shows the current amount of Limiter gain reduction or startup muting. If there is no gain reduction being applied, the field is blank. On the Memory page an asterisk (*) appears in this field whenever the current working Memory does not match the last recalled Memory.

Programming the SRM 66

Programming each SRM 66 Output requires only one edit page as in Figure 1. Note that unique Input mix levels are possible for each Output. All adjustments are in 1 dB steps.

The following parameters define each Output:
 IN1 Input one mix Level +6 dB to -25 dB, Off
 IN2 Input two mix Level +6 dB to -25 dB, Off
 IN3 Input three mix Level +6 dB to -25 dB, Off
 IN4 Input four mix Level +6 dB to -25 dB, Off
 IN5 Input five mix Level +6 dB to -25 dB, Off
 IN6 Input six mix Level +6 dB to -25 dB, Off
 MST Master mix Level +0 dB to -59 dB, Off
 LIM Limit Threshold Max (0 dB) to -28 dB re: clip point.

Output Groups

The SRM 66 uses Output Groups to link the attenuation level and Limiter gain reduction of one or more Outputs. Any one of the seven possible SR 1L remote controls can then be assigned to control an Output Group Level. The SRM 66 can also assign any number of the six possible Output Groups to a Master Group. Any number of the seven possible SR 1L Remotes can then be assigned to control the Master Group Level. Understanding and utilizing the power of Groups is essential to harness the power and versatility of the SRM 66.

The Output to Group Assign page is shown in Figure 2. Outputs can be assigned to 1 of 6 Output Groups or no Group (*off*). For example, a stereo Output pair would typically be assigned to the same Output Group in order to ensure that the two stereo Outputs limit together and are controlled by the same Output Group Level. Output Group Levels may be controlled from the Group Level page shown in Figure 3 or by any SR 1L remote assigned to the Group on the Remote to Group page shown in Figure 5.

The Group to Master Remote assignment page is shown in Figure 4. Any number of the six (6) possible Output Groups can be assigned to the Master Group. The Level of all Output Groups assigned to the Master Group can be controlled by the MST control on the Group Level page shown in Figure 3 or by any SR 1L remote assigned to the Master Group on the Remote to Group Assign page shown in Figure 5. This feature




Figure 2. Output to Group Edit Page




Figure 3. Group Levels Edit Page




Figure 5. Remote to Group Assign Page

allows SR 1L remotes to independently control the level of up to six Zones while allowing one or more Master Remotes to control the level of all Zones.

Group Level parameters are *independent* of mix Input level and Output Master level. *Group Levels are not affected by Memory changes.* See the APPLICATIONS section for more discussion on fully utilizing Group functionality.

SR 1L Remote Controls & Remote Interface Port (RIP)

The SRM 66 provides a Remote Interface Port (RIP) which supports up to seven optional SR 1L “Smart” digital Remote controls as seen in Figure 6. The SR 1L has 31 LEDs to indicate the Group’s current attenuation setting of 0 to 29 dB in 1 dB steps, the last step is OFF. It is designed to mount in a standard U.S. electrical box with a minimum depth of 2-¼ inches, and can be covered with a standard Decora® plate cover. (Decora is a registered trademark of Leviton)

Each SR 1L Remote must have a unique address (1-7). Any of the possible seven (7) Remotes may be assigned to any one of the six (6) possible Output Groups, to the Master Group or set to off. See the Remote to Group Assign page in Figure 5. If a Groups level is altered by one of the SRM 66s Group Level controls (Fig. 3), then every Remote assigned to that Group is updated to reflect the new setting. If a Group Level is adjusted by a Remote, then the SRM 66’s Group Level page is updated to reflect the new setting.

Each of the 24 Memories stored in the SRM 66 may have unique assignments for Output to Group, Group to Master Remote and Remote to Group parameters. This allows for very flexible room combining applications and system reconfiguration.




Figure 4. Group to Master Remote Assign Page




Figure 6. SR 1L Remote Control

SR 1L Wiring

The SR 1L Remote interface is a powered, half duplex, (RS-485) party line system (BYOB). Five wires are required to connect an SR 1L to the SRM 66’s RIP (Remote Interface Port [see Figure 7, next page]). Each connection must be wired. Up to six SR 1Ls can be wired in any combination of daisy chain (series) or star configurations for a total cable length of up to 1000 feet (305 meters), assuming the use of any good quality Category 5 (standard Ethernet) cable. Engage the RT (termination switch) *only on the SR 1L farthest away from the SRM 66*. Hook the Shield connection to the cable’s shield for best emission suppression. The loop in the metal at the back of the SR 1L is provided for a cable tie-wrap.

To lock out SR 1L level changes yet still display the proper settings, disable the encoder by connecting the ENCODER LOCK terminal to the V- terminal. Use a key switch, relay, or any old thing that passes electrons such as a Tesla coil.

SR 1L Troubleshooting

Double-check all wiring for accuracy before power is applied via the SRM 66. A single LED on the SR 1L should light immediately after SRM 66 power is applied. A blinking LED indicates that it has not yet detected communication on the Port. This is common until the SRM 66 has fully initialized but should not happen after that point. *If after hook up and SRM 66 power up, an SR 1L LED blinks or does not respond, one of several problems is to blame. Either the wiring is incorrect, the SR 1L address is invalid (must be between 1 and 7), the SRM 66 is not in SR1 mode (under the RIP parameter in the Memory LCD page), or the SR 1L's ENCODER LOCK terminal is shorted, thus locking out the encoder. Also, the SRM 66 Remote to Group assignment may be set to Off, thus disabling the entire SR 1L, not just the encoder.*

Alternate Remote Interface Port Modes

There are three Remote Interface Port modes. The default RIP mode allows communication to SR 1L Remotes. *To permit SR 1L Remote functionality, the RIP parameter setting on the Memory page must be set to SR1 (the default).*

When using the DSC 1 accessory product, the RIP parameter must be set to DSC. (See DSC 1 & SRM Exchange Software on page Manual-7.) When using the SRM 66's Master Slave feature, RIP must be set to SLAVE, see the next section.

Advanced SRM 66 & SR 1L Applications

A single SR 1L can control Output Groups across multiple SRM 66s. For more information on this Master/Slave functionality, see RaneNote 142, "Advanced Applications of the Ingenious SRM 66 and SR 1L."

For room controller fans out there, two more RaneNotes of interest are RaneNote 138, "Using a Control System with an SRM 66" and RaneNote 139, "Using SR 1Ls with Other Rane Products." These RaneNotes happen to cover AMX, but the Device Control Language and complete communications details are covered for easy incorporation into Crestron systems. See the ADVANCED APPLICATIONS & ACCESSORIES section below for more advanced functionality.

All of these RaneNotes are available in PDF form at <http://www.rane.com/library.htm> or we'll email it to you if you ask info@rane.com, or we'll fax or snail mail it if you ask real nice.

Memories

Twenty-four non-volatile Memories can save up to twenty-four system configurations. Each Memory contains the following parameters.

| | |
|-----------------------------|-------------------------------------|
| Mix Source Routing | Input 1-2-3-4-5-6 to each Output |
| Mix Source Levels | +6 dB to -25 dB for each Output |
| Master Level Reduction | +0 dB to -59 dB for each Output |
| Limit Threshold | Max (0 dBr) to -28 dBr, each Output |
| Output to Group Assignments | |
| Remote to Group Assignments | |

Memories are stored and recalled using the Memory page shown in Figure 9.




Figure 7. Memory Recall Port (MRP) and Remote Interface Port (RIP)




Figure 8. MRP Wiring

Memory Recall Port

In addition to the Memory page, the SRM 66 provides a Memory Recall Port (MRP). This port allows remote switch closures to recall any of the twenty-four system Memories. The first eight Memories recall with simple switch closures on the eight MRP pins (see the Normal section of Table 1). A binary wiring mode allows accessing all 24 Memories (see the Binary section of Table 1).

"Paging" mode provides installers an easy way to configure a system which uses a single switch (such as a push-to-talk mic switch) to toggle between two sequential Memories to change source levels. See Figure 8 and Table 1.

FP LOCK

The recessed FP LOCK switch (on the rear) locks out all front panel control except for Group Levels and Memory Recall. With FP LOCK engaged, the SR 1L Remotes are able to control Group Levels, and all Edit Pages are viewable but not editable.




Figure 9. Memory Page

| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | Mode | Result |
|---|---|---|---|---|---|---|---|-----------|--------|
| 1 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | Normal | 1 |
| 0 | 1 | 0 | 0 | 0 | 0 | 0 | 0 | | 2 |
| 0 | 0 | 1 | 0 | 0 | 0 | 0 | 0 | | 3 |
| 0 | 0 | 0 | 1 | 0 | 0 | 0 | 0 | | 4 |
| 0 | 0 | 0 | 0 | 1 | 0 | 0 | 0 | | 5 |
| 0 | 0 | 0 | 0 | 0 | 1 | 0 | 0 | | 6 |
| 0 | 0 | 0 | 0 | 0 | 0 | 1 | 0 | | 7 |
| 0 | 0 | 0 | 0 | 0 | 0 | 0 | 1 | | 8 |
| 0 | 0 | 0 | 0 | 0 | 1 | 1 | 1 | | 1 |
| 1 | 0 | 0 | 0 | 0 | 1 | 1 | 1 | | 2 |
| 0 | 1 | 0 | 0 | 0 | 1 | 1 | 1 | | 3 |
| 1 | 1 | 0 | 0 | 0 | 1 | 1 | 1 | | 4 |
| 0 | 0 | 1 | 0 | 0 | 1 | 1 | 1 | | 5 |
| 1 | 0 | 1 | 0 | 0 | 1 | 1 | 1 | | 6 |
| 0 | 0 | 0 | 1 | 0 | 1 | 1 | 1 | | 7 |
| 1 | 0 | 0 | 1 | 0 | 1 | 1 | 1 | | 8 |
| 0 | 0 | 0 | 0 | 1 | 1 | 1 | 1 | | 9 |
| 1 | 0 | 0 | 0 | 1 | 1 | 1 | 1 | | 10 |
| 0 | 0 | 0 | 0 | 0 | 1 | 0 | 1 | no change | |
| 1 | 0 | 0 | 0 | 0 | 1 | 0 | 1 | 1 | |
| 0 | 1 | 0 | 0 | 0 | 1 | 0 | 1 | 2 | |
| 1 | 1 | 0 | 0 | 0 | 1 | 0 | 1 | 3 | |
| 0 | 0 | 1 | 0 | 0 | 1 | 0 | 1 | 4 | |
| 1 | 0 | 1 | 0 | 0 | 1 | 0 | 1 | 5 | |
| 0 | 1 | 1 | 0 | 0 | 1 | 0 | 1 | 6 | |
| 1 | 1 | 1 | 0 | 0 | 1 | 0 | 1 | 7 | |
| 0 | 0 | 0 | 1 | 0 | 1 | 0 | 1 | 8 | |
| 1 | 0 | 0 | 1 | 0 | 1 | 0 | 1 | 9 | |
| 0 | 1 | 0 | 1 | 0 | 1 | 0 | 1 | 10 | |
| 1 | 1 | 0 | 1 | 0 | 1 | 0 | 1 | 11 | |
| 0 | 0 | 1 | 1 | 0 | 1 | 0 | 1 | 12 | |
| 1 | 0 | 1 | 1 | 0 | 1 | 0 | 1 | 13 | |
| 0 | 1 | 1 | 1 | 0 | 1 | 0 | 1 | 14 | |
| 1 | 1 | 1 | 1 | 0 | 1 | 0 | 1 | 15 | |
| 0 | 0 | 0 | 0 | 1 | 1 | 0 | 1 | 16 | |
| 1 | 0 | 0 | 0 | 1 | 1 | 0 | 1 | 17 | |
| 0 | 1 | 0 | 0 | 1 | 1 | 0 | 1 | 18 | |
| 1 | 1 | 0 | 0 | 1 | 1 | 0 | 1 | 19 | |
| 0 | 0 | 1 | 0 | 1 | 1 | 0 | 1 | 20 | |
| 1 | 0 | 1 | 0 | 1 | 1 | 0 | 1 | 21 | |
| 0 | 1 | 1 | 0 | 1 | 1 | 0 | 1 | 22 | |
| 1 | 1 | 1 | 0 | 1 | 1 | 0 | 1 | 23 | |
| 0 | 0 | 0 | 1 | 1 | 1 | 0 | 1 | 24 | |

Table 1. MRP Binary Control

DSC 1 & SRM Exchange Software

The optional Rane DSC 1 accessory provides a bridge to connect a PC's RS-232 port and the SRM 66's RIP (Remote Interface Port). Coupled with the included SRM Exchange Software, the DSC 1 allows the exchange of settings between an SRM 66 and the PC's SRM Exchange software. Once the settings are obtained by the PC they can be manipulated, stored in a file, printed for future reference or sent to subsequent SRM 66s. SRM Exchange software can be downloaded from www.rane.com allowing SRM 66 programming "offline" without an SRM 66 present. However, the DSC 1 is required to download such settings to the SRM 66.

For programming the Memory Recall Port using the Edit MRP button, see RaneNote 142 "Advanced Applications for the Ingenious SRM 66."





Figure 10. SRM Exchange Software & DSC 1



APPLICATIONS

One of the best ways to grasp the true versatility of the SRM 66 is to observe one in action.

Figure 11 shows an installation using one SRM 66 to distribute sound throughout an entire manufacturing facility. Each Output can have different mix Inputs and Levels. For example, the offices may mix in a different page source than the shop floor. Also note that all three of the shop floor Outputs may have different mixes, Master Levels and Limiter thresholds.

The use of Output Groups allows a large variety of Remote / Output combinations. In this example both the offices and lobby have their own Remotes to control their own Output Levels, while the shop floor has two Remotes, either of which can control the level of all three Output Levels assigned to them.

The example shown in Figure 12 demonstrates a system using the SRM 66 for room combining. The fact that Group configurations can be different in each Memory adds the versatility of linking multiple Remotes together in one condition while separating them in another. In Memory 2, the Master can control both Output Groups, while permitting individual control within each divided room.

One thing to keep in mind in such a situation is the Group's Level is *not* stored in each Memory. This allows you to change Memories without it resetting the Group's Level each time. If a different Group Level is desired you can change the Group assignments. For example, in Figure 12 (Memory #2) you could assign Output 1, Output 2 and Remote 1 to Group 3. When you changed from Memory #1 to Memory #2 the Group's Level would change to the last value set for that Group. If your application requires no change in Level between Memories, simply keep the Group Level assignments (to Outputs and Remotes) intact between Memories.

Other applications for the SRM 66 are time of day clocks with contact closure outputs which adjust the level and/or distribution of audio for scheduled events. Or connect the SRM 66's MRP through a relay to the power switches on noisy machinery to increase and decrease background or paging audio during use in manufacturing facilities.




Figure 11. Manufacturing Facility System




Figure 12. Room Combining System

ADVANCED APPLICATIONS & ACCESSORIES

For AMX or Crestron room controller applications, see RaneNotes 138 & 139 available from Rane. Two more advanced SRM 66 features are discussed in RaneNote 142 "Advanced Applications of the Ingenious SRM 66 and SR 1L." Master/Slave functionality is covered, where one SR 1L remote can control Output Groups across multiple SRM 66s. SR 1L room controller applications are greatly simplified using Master/Slave mode; AMX software for this application is also available from Rane. Also covered in RaneNote 142 is *Edit MRP Configuration* which can eliminate the costly, time consuming and labor intensive diode logic that is occasionally required in applications with multiple contact closure sensors. This feature is provided via the completely programmable SRM 66 Memory Recall Port using SRM Exchange software (see previous page).