

SMARTMODULE 2

Accessory Mounting Kits

Installation Guide


Overview

The SmartModule 2 can be either wall mounted or pipe mounted depending on the installation need. ETC offers two accessory mounting kits for use (universally) on UL and CE units:

NOTE: Instructions for mounting the 6 channel unit can be found on page 2 of this document.


Install the 4 Channel Pipe Mounting Kit

The SmartModule 2 with the pipe mounting kit (7543K1013) attached is designed for use with accessory clamps or u-bolts for mounting onto pipes or truss. Clamps and u-bolts are provided by others.



NOTE: The hex flange nuts provided in the kit may be used for CE units to attach clamps or u-bolts as needed. Please discard if they are not required for your installation.

The pipe mounting bracket fits the 4 channel SmartModule 2 with the bracket facing towards or away from the unit. Simply attach the brackets to the SmartModule 2 using the M6 hardware provided.




Alternatively, you may install the 4 channel pipe mounting brackets to the bottom of the unit for SmartStand or tree stand mounting.

For added security, attach a safety cable (not included) between the pipe mounting bracket and the hanging structure.

Install the 4 Channel Wall Mounting Kit

The SmartModule 2 with the wall mounting kit (7543K1011) attached is designed to be installed to a sufficient support structure as determined by a structural engineer for the application..



- Step 1: Align one of the wall mounting bracket to the wall, mark and pre-drill the center keyhole locations. The keyholes are suitable for M6 (1/4") bolts or screws (provided by others).
- For convenience, a template is located on the right edge of this page. You may choose to post this document on the wall location to mark and pre-drill holes.
- Step 2: Measure, mark and pre-drill for the opposite side mounting bracket.
- For UL listed units, measure across 16 inches.
 - For CE marked units, measure across 44.6cm.
- Step 3: Using an adjustable wrench, install two M6 (1/4") bolts or screws (provided by others) into the pre-drilled mounting holes, leaving approximately 1" (25.4mm) temporarily exposed.
- Step 4: Using an adjustable wrench, attach the mounting brackets to the SmartModule 2 using the M6 bolt hardware provided in the installation kit.
- Step 5: Install the SmartModule 2 mounting bracket onto the installed wall hardware through the keyholes.
- Step 6: Using an adjustable wrench, tighten each of the mounting bolts until they are snug.
- Step 7: For a more secure installation, install one additional screw (not provided) into a top mounting keyhole slot and tighten until the bracket is snug against the wall.



Corporate Headquarters ■ 3031 Pleasant View Road, P.O. Box 620979, Middleton, Wisconsin 53562-0979 USA ■ Tel +608 831 4116 ■ Fax +608 836 1736
London, UK ■ Unit 26-28, Victoria Industrial Estate, Victoria Road, London W3 6UU, UK ■ Tel +44 (0)20 8896 1000 ■ Fax +44 (0)20 8896 2000
Rome, IT ■ Via Ennio Quirino Visconti, 11, 00193 Rome, Italy ■ Tel +39 (06) 32 111 683 ■ Fax +44 (0) 20 8752 8486
Holzkirchen, DE ■ Ohmstrasse 3, 83607 Holzkirchen, Germany ■ Tel +49 (80 24) 47 00-0 ■ Fax +49 (80 24) 47 00-3 00
Hong Kong ■ Rm 1801, 18/F, Tower 1 Phase 1, Enterprise Square, 9 Sheung Yuet Road, Kowloon Bay, Kowloon, Hong Kong ■ Tel +852 2799 1220 ■ Fax +852 2799 9325
Service: (Americas) service@etcconnect.com ■ (UK) service@etcconnect.com ■ (DE) techserv-hoki@etcconnect.com ■ (Asia) service@etcconnect.com
Web: www.etcconnect.com ■ Copyright © 2010 ETC. All Rights Reserved. ■ Product information and specifications subject to change.
7543M2210 ■ Rev A ■ 2010-03


SMARTMODULE 2

Accessory Mounting Kits

Installation Guide

Install the 6 Channel Pipe Mounting Kit

The SmartModule 2 with the pipe mounting kit (7543K1014) attached is designed for use with accessory clamps or u-bolts for mounting onto pipes or truss. Clamps and u-bolts are provided by others.




NOTE: The hex flange nuts provided in the kit may be used for CE units to attach clamps or u-bolts as needed. Please discard if they are not required for your installation.

The pipe mounting brackets fit the 6 channel SmartModule 2 with the brackets facing towards or away from the unit and in an offset up orientation or flush.


Offset Mounting

Orient the mounting bracket facing towards or away from the unit and use the second set of mounting holes to secure the bracket to the unit.



Flush Mounting


Orient the mounting bracket away from the unit and use the first set of mounting holes to secure the bracket to the unit.



Simply attach the brackets to the SmartModule 2 using the M6 hardware provided.
For added security, attach a safety cable (not included) between the pipe mounting bracket and the hanging structure.

Install the 6 Channel Wall Mounting Kit

The SmartModule 2 with the wall mounting kit (7543K1012) attached is designed to be installed to a sufficient support structure as determined by a structural engineer for the application.



- Step 1: The two brackets provided are left and right side specific. Align one of the brackets to the wall, mark and pre-drill the center keyhole locations. The keyholes are suitable for M6 (1/4") bolts or screws (provided by others).
- For convenience, a template is located on the right edge of this page. You may choose to post this document on the wall location to mark and pre-drill holes.
- Step 2: Measure, mark and pre-drill for the opposite side mounting bracket.
- For UL listed units, measure across 16 inches.
 - For CE marked units, measure across 44.6cm.
- Step 3: Using an adjustable wrench, install two M6 (1/4") bolts or screws (provided by others) into the pre-drilled mounting holes leaving approximately 1" (25.4mm) temporarily exposed.
- Step 4: Using an adjustable wrench, attach the mounting brackets to the SmartModule 2 utilizing the M6 hardware bolt hardware provided in the installation kit.
- Align the correct bracket to the side of the SmartModule 2. Secure the bottom bolt hole first then secure the top two bolts.
- Step 5: Install the SmartModule 2 mounting bracket onto the installed wall hardware through the keyholes.
- Step 6: Using an adjustable wrench, tighten each of the mounting bolts until they are snug.
- Step 7: For a more secure installation, install one additional screw into the center hole provided on each mounting bracket and tighten until the bracket is snug against the wall.

