

# Snap-On Anchor

## USER GUIDE



**NOTE:** Snap-On Anchors should only be used with 2" ProPanels.  
**DO NOT USE** with 1" ProPanels.



1

Screw the Snap-On Anchors into the back of the panel using the Snap-On Hex Driver tool.\*

\* TIP: Sometimes it helps to cut the panel to get the anchor started. This can be done with a utility knife.



2

Insert marking plugs into the Snap-On anchors.



3

Push panel against wall to mark anchor locations.



4

Screw ratchet plugs to wall at marked locations.  
*(\*\*Number of screws varies with panel size.)*



5

Firmly push panel onto ratchet plugs to complete installation.

\*\* Recommended quantity of **Snap-On Anchors** and screws to panels

| <u>Panel Size</u> | <u>Qty</u> |
|-------------------|------------|
| 2x2               | 4          |
| 2x4               | 4          |
| 4x4               | 4          |
| 4x8               | 8          |