



Use this template for drilling. Refer to instructions on reverse for hardware and installation.



Diversity Architectural™ Antenna  
470-698 MHz

## Instructions for Use:

1) Remove bracket from back of antenna (a screw on either side holds it in place, leave them threaded into the bracket for easier installation)

2) Use the provided template on the reverse of this page as a drilling guide

### Junction Box Mounting:

Use screws and wall anchors as required in at least 2 of the “J” holes.

### Ceiling Mounting:

Use screws and wall anchors or toggles as required in at least 2 of the “L” holes.

### Wall Mounting:

Use (2) screws and wall anchors as necessary in “K” holes.

**OR**

Use screws and wall anchors as required in at least 2 of the “L” holes.

**Note: Be sure to orient the cable cutout on the correct side for your cable routing**

3) Connect both cables on the Diversity Architectural Antenna to coax cables and route through cutout in the side of the bracket or the junction box cutout

4) Use the 2 screw holes on the sides of the bracket to mount the antenna to the bracket

## Suggested Mounting Hardware (not included)

### Junction Box Mounting:

For “J” holes:

Use at least 2 screws: 6-32, 8-32, or as required for your box

### Ceiling Mounting:

For “L” holes:

Qty 2: 1/8” Toggle Bolt, 6-32, 2” long

Qty 2: 1/4” x 1 1/4” OD Fender Washer

### Also required:

The Diversity Architectural antenna has 2 elements and uses 2 coax cables (not included).

### Wall Mounting:

For Keyhole “K” holes:

Qty 2-4: #6 or #8 screws

**OR**

For “L” holes:

Qty 2: 7/8” Drywall Anchor

Qty 2: #6 x 1” Pan Head Sheet Metal Screw