



PLANET WAVES™

# Auto-Trim™ Tuning Machine

## Installation Instructions



1. Insert the tuner through the hole in the headstock and align it in the desired position.



2. Gently push with thumb until tuner is flush against the headstock.



3. Place the washer and nut over the tuning post. Turn the loose nut with a wrench or nut driver until you feel the first sign of resistance.



4. Fasten the screw through the eyelet and into the headstock.



5. Again, with a wrench or nut driver, turn the nut 1/4 turn (90°). The nut should be tight and secure. If not, tighten it 1/4 turn at a time until it is secure.

J.D'Addario & Company, Inc.  
PO Box 290  
Farmingdale, NY  
11735 USA

Tel: 631-439-3300

Fax: 631-439-3333

[www.planet-waves.com](http://www.planet-waves.com)