




# GL4800 Surface Parts



### Buttons and Knobs

- WHITE RECT BUTTON AJ2962
- GREY RECT BUTTON AJ2865
- BLACK RECT BUTTON AJ3228
- WHITE SQUARE BUTTON AJ2960
- GREY SQUARE BUTTON AJ2864
- RED SQUARE BUTTON AJ2961
- WHITE ILLUM BUTTON AJ8107
- GREY ROUND BUTTON AJ3955
- GREY - GREY KNOB AJ2078A
- GREY - BLACK KNOB AJ6106A
- GREY - YELLOW KNOB AJ2079A
- GREY - RED KNOB AJ2074A
- GREY - BROWN KNOB AJ2080A
- GREY - GREEN KNOB (SHORT) AJ5712
- GREY - BLUE KNOB AJ2075A
- GREY - L/BLUE KNOB AJ2076A
- GREY - BLACK FADER KNOB AJ6278
- BLACK - WHITE FADER KNOB AJ3503
- L/BLUE - BLACK FADER KNOB AJ8081
- BLUE - WHITE FADER KNOB AJ6237
- YELLOW - BLACK FADER KNOB AJ8080
- RED - BLACK FADER KNOB AJ8079

# GL4800 Surface Parts

(GL4800-824B shown)

