

ALLEN&HEATH

Parts identification sheet



How to order parts

Parts must be ordered from our distributor in your territory. A list of international distributors can be viewed at <http://www.allen-heath.com/UK/distributors.asp>

UK parts must be ordered through an appointed A&H dealer or service centre. A list of UK service centres can be viewed at http://www.allen-heath.com/UK/service_centres.asp

EXTERIOR PARTS

Knobs:

- Knob red AJ2074A
- Knob green AJ2077A
- Knob grey AJ2078A
- Knob black AJ6106A
- Knob brown AJ2080A
- Knob light blue AJ2076A
- Knob dark blue AJ2075A
- Knob yellow AJ2079A

Buttons:

- Push button square grey AJ7210
- Push button rect black AJ7182
- Push button rect grey AJ7179
- Push button rect white AJ7180
- Push button round black AJ4251


Fader Screws:


- Fader screw AB2811

Fader Knobs:

- Fader knob black AJ3503
- Fader knob light blue AJ8081JIT
- Fader knob dark blue AJ6237JIT
- Fader knob grey AJ6278JIT
- Fader knob red AJ8079JIT
- Fader knob brown AJ6692JIT
- Fader knob yellow AJ8080JIT
- Fader knob green AJ6691JIT

INTERIOR PARTS





Ident strip 17-24
AK6474JIT


Ident strip 9-16
AK6473JIT

Ident strip 1-8
AK6472JIT

8	7	6	5	4	3	2	1
---	---	---	---	---	---	---	---

Feet
AK0102JIT

INTERIOR PARTS



IDENTIFY PANASONIC FADERS / ALPS FADERS BY MIXER SERIAL NUMBER

List of mixer serial numbers using Panasonic Faders on Mix Masters to date 15109106:

L28MON24002847
L28MON32002932
L28MON32002934
L28MON32002935
L28MON32002936
L28MON40002944
L28MON40002945
L28MON24002949
L28MON24002950
L28MON40002951
L28MON40002952
L28MON48002983
L28MON32002985
L28MON24003012
L28MON24003013
L28MON24003014
L28MON24003015
L28MON32003017
L28MON32003019
L28MON40003026
L28MON40003027
L28MON40003028
L28MON40003031

**List of mixer serial numbers using Panasonic Faders on Mix Masters to date
5110106:**

L28MON24002847
L28MON32002932
L28MON32002934
L28MON32002935
L28MON32002936
L28MON40002944
L28MON40002945
L28MON24002949
L28MON24002950
L28MON24003012
L28MON24003013
L28MON24003014
L28MON24003015
L28MON3200298s
L28MON32003017
L28MON32003019
L28MON32003055
L28MON32003063
L28MON32003064
L28MON320031 13
L28MON40002951
L28MON40002952
L28MON48002983
L28MON40003026
L28MON40003027
L28MON40003028
L28MON40003029
L28MON40003031
L28MON40003048
L28MON40003052
L28MON40003055
L28MON400031 19

GL2800Ms with Panasonic faders on whole mixer.

L28MON40003144
L28MON32003132
L28MON40003149
L28MON40003146
L28MON48003161
L28MON32003134
L28MON40003145
L28MON40003142
L28MON32003128
L28MON48003206
L28MON48003207
L28MON48003209
L28MON40003152
L28MON32003191