

PDMIC58 PDMIC78

Professional Dynamic Microphone

OPERATION INSTRUCTION

HANDLING PRECAUTONS

If you cover the microphone head with your hand or place it near a speaker, you may get feedback. To prevent feedback, decrease the volume of your speaker, and make sure that the microphone is not facing the speaker. Your microphone is sensitive equipment; avoid dropping, hitting, or shocking your microphone. Do not store the microphone in a place with high temperature or humidity.

The optimal distance between the microphone and mouth is 2 to 4 inches. If the microphone is too close, the sound may be unclear, with heavy bass, or create popping noises when the user of the microphone breathes in and out. To prevent these distortions, move the microphone farther from your mouth.

To plug your microphone in, align the hollow part of the output connected on the microphone body with the projecting part of the connecter on the microphone cord. Push in until a CLICK sound is heard.

To disconnect your microphone, pull the connector out from the microphone while pushing the tab on the cord connector.

Dynamic microphone

