

# Pulsar radio trigger system

Integrated radio triggering. Easier than one... two... three...



one. Insert trigger card. two. Attach antenna.



## Pulsar Tx Unit (Transmitter)

This ultra-compact transmitter with its camera-hugging low profile ensures you can shoot comfortably without your camera becoming unbalanced by unwieldy attachments.

The Pulsar Tx features a unique 'click-lock' system for attaching the unit to your camera hotshoe securely without the need for tightening via a thumbscrew. The 'click-lock' holds the trigger firmly in place whether the camera is being used in landscape or portrait position.

Weighing in at just 1.2oz, it is powered by a single CR2032 battery, and the power management system ensures long battery life.

Functionality couldn't be easier!

The Tx is controlled by two simple push buttons allowing full control over the 24 radio zones. Channel and studio selections are indicated by a row of LED's.

**BW3965** Pulsar Tx Unit.

**BW3967** Pulsar Tx Unit with Rx Card.

## Pulsar Rx Card Set (Receiver)

Gemini Classic, R & Pro monolights can become compatible with the Pulsar system by using this unique upgrade pack.

Simply insert the Radio Trigger Card into the slot on the back of the Gemini unit then fit the antenna into the socket on the side and your monolight is ready to receive signals from a Pulsar unit mounted onto your camera. Never be let down by unreliable sync cords or connections again.

**BW5170** Rx Card & Antenna Set.

**BW3967** Rx Card Set with Pulsar Tx Unit.

### Pulsar Tx Specifications:

Length: 55mm [2¼"]  
Width: 40mm [1½"]  
Height: 40mm [1½"]  
Weight: 34g [1.2oz]

### Pulsar Rx Specifications:

Length: 38mm [2¾"]  
Width: 38mm [1½"]  
Height: 8mm [¾"]  
Weight: 8g [0.3oz]





### Pulsar Tx/Rx Set (Trigger Unit & Receiver Card)


Gemini Classic, R & Pro monolights can become compatible with the Pulsar system by using this unique upgrade pack.

Simply insert the Radio Trigger Card into the slot on the back of the Gemini unit then fit the antenna into the socket on the side and your monolight is ready to receive signals from a Pulsar unit mounted onto your camera.

Never be let down by unreliable sync cords or connections again.

**BW5170** Rx Card & Antenna Set.

**BW3967** Rx Card Set with Pulsar Tx Unit.



Ready Sounder  
Toggles On/Off

Photocell  
Toggles On/Off

Modelling Mode  
Max / Usr / Relative

Lamp Ready Indication  
Toggles On/Off

Channel Select  
Select 1-8 or all (O)

Increase  
Power or Modelling level

Decrease  
Power or Modelling level

Flash Test  
Flashes the unit

### Specifications

- Length: 95mm [3<sup>7</sup>/<sub>8</sub>"
- Width: 45mm [1<sup>3</sup>/<sub>8</sub>"
- Height: 10mm [3/<sub>8</sub>"
- Weight: 34g [1.2oz]

### Gemini R & Pro Remote Control

The pocket-sized Gemini Remote Control makes working with Gemini 'R' and 'Pro' monolights (or our Jetstream Wind machines) a breeze.

Weighing in at just 1.2oz this diminutive device allows photographers precise control of features such as power, test flash, modeling, sounder, photocell and channel setting without ever leaving the camera position - up to seven meters (22') away.

**BW3960** Gemini R & Pro Remote Control.

