#### WARRANTY REGISTRATION

**Visit www.ultimatesupport.com** for a quick and convenient process for registering your new Ultimate Support product. Warranty Registration and Proof of Purchase are required for warranty fulfilment. Full Limited Lifetime Warranty and Ultimate Protection Plus Premium Service and Support Plan details are available online under Music Gear & Instrument Stands / Customer Support.

### ULTIMATE S U P P O R T

### LIMITED LIFETIME WARRANTY

Ultimate Support products are constructed of the finest materials and designed and tested to stand up to the demanding lifestyle of the touring musician, gigging DJ, and working sound engineer. In the unlikely event that a product should fail due to manufacturing defect, Ultimate Support is pleased to repair or replace that product.

Please see www.ultimatesupport.com for more information.

This warranty applies to the original purchaser only and does not include damage to the product resulting from normal wear and tear, accident, misuse, improper installation or operation, or unauthorized repair or alterations.

THE STRENGTH OF INNOVATION® AX-48 Pro S **Product Manual** for Ultimate Support **APEX** SERIES KEYBOARD STAND AX-48 Pro B AX-48 PRO B ITEM #17351 AX-48 PRO S ITEM #17476



## ULTIMATE

# Congratulations on your purchase!

**Updated Design –** The AX-48
Pro delivers everything you
loved about the original APEX
stand, but now features a sleek
exterior design for the modern
keyboard player.

Longer Tri-bar Arms – In addition to one set of 13-inch Tri-bar arms, the AX-48 Pro now includes a set of 18-inch Tri-bar arms to support your larger keyboards.

True Portability – Take the AX-48 Pro anywhere. The Tri-bar arms store in the column top and the legs slide into the bottom creating a self-contained, compact unit complete with a heavy-duty carrying handle.

Stable & Durable – Just like the original APEX, the AX-48 Pro features locking legs for proven stability and a black or silver anodized aluminum finish that won't rust and resists scratches.

## HANDLE ATTACHMENT



1. Remove included screws from handle mount (in stand).



2. Position handle in place by lining up holes in handle and holes in handle mount.



**3.** Secure handle in place with screws.

## **SETUP FOR APEX-48 PRO**



 Lay stand on the floor. Press the buttons at the base of the column and slide legs out.



**2.** Rotate legs until they snap into place.

### SETUP FOR APEX-48 PRO (Continued)



3. Stand AX-48 Pro upright and pen top cap to remove Tribars.



**4.** Position clamp on column face and install bracket and T-screw. (Angular edge rides in column slot.)



Attach Tribars to clamps by Tribar hook. Gently push Tribar down into slot.



**6.** Loosen thumbscrew and slide stabilizer to touch the floor. Re-tighten the thumbscrew.



**7.** To accommodate larger, heavier keyboard and / or lower playing styles, remove angle adapter and re-adjust stabilizer. This changes column angle and shifts center of gravity.



8. After loading top instrument first, secure cables in cable clips. Rotate cable clips. NOTE: Rotate cable clips again for re-positioning.

2