

**FP-2
FOOT PEDAL**

**FEATURE
OVERVIEW**

Allows hands-free mixing

Adjust volume, select channels and activate intercom

Two multi-function buttons

Connect one per CS-SOLO or two per CS-DUO

Rugged metal construction



The FP-2 is a multi-function foot pedal allowing hands-free control of key CS-SOLO and CS-DUO features.

The FP-2 allows musicians and performers to make channel selections and mix adjustments without taking their hands off their instruments or microphones.



By tapping or holding each button, users can select channels, adjust volumes and activate the built-in intercom on the personal mixer.

When using a CS-DUO, select "MIX A" or "MIX B" on the side of the FP-2. By connecting two FP-2 units together, both mixes on the CS-DUO can be controlled.



1. **BUTTONS 1 & 2:** Activate FP-2 functions.

2. **IN:** Connect a 1/4" TRS cable to the FOOTSWITCH jack on the CS-SOLO or CS-DUO. A standard TS or guitar cable will not work with the FP-2.

3. **THRU (CS-DUO ONLY):** The FP-2 THRU Connector allows you to connect two foot pedals; one for MIX A and the other for MIX B. Use a TRS cable to connect two foot pedals.

4. **A/B Switch (CS-DUO ONLY):** Set this switch to 'A' to control MIX A or 'B' to control MIX B.

FP-2 FOOT PEDAL

Dimensions	6.25" (159mm) W 3.5" (89mm) D 1.125" (29mm) H
Weight	.78 lb (.35kg)

FOR ORDERS CONTACT:

sales@digitalaudio.com

Phone: 952-401-7700

Fax: 952-401-7725

DIGITAL AUDIO LABS

1266 PARK RD CHANHASSEN, MN 55317

WWW.DIGITALAUDIO.COM