TECHNICAL DATA

HM162 Headset Microphone



The HM162 headset microphone is a lightweight, noisecancelling design for use with high output PA systems. The comfortable, over-the-ear headband and flexible boom place the pickup capsule in an optimum location just to the left of the user's mouth. The headband keeps the pickup in this position as the user moves about, leaving the hands free for other tasks.

A bi-directional, dual-element, noise cancelling microphone capsule rejects extraneous sound and emphasizes the user's voice for maximum gain before feedback even in close proximity to sound system loudspeakers.

The lightweight headband includes an adjustable, elastic neckband to provide a comfortable fit around the back of the head. The over the ear design also allows the user to comfortably wear a cap or hat without interfering with the operation of the microphone. The HM162 is furnished with a locking micro connector for use with Lectrosonics VHF belt pack wireless transmitters.

Rugged materials are used throughout the assembly to withstand the rigors of heavy use.



OPERATING INSTRUCTIONS

1) Place the microphone headband on the head with the headband over the ears. The pickup boom should be positioned to the left of the mouth with the flexible neckband around the back of the neck.


2) Adjust the flexible neckband so that the frame of the headset fits comfortably over the ears.

3) Adjust pickup boom so that pickup element is to the left of the mouth, 1/2" to 1" away from the skin. The pickup element should not be positioned in front of the mouth, since breath pops directly into the capsule will cause severe distortion.

4) Route the microphone cable loosely around the body so that the plug reaches the transmitter without coiling the microphone cable. Do not coil the cable around the transmitter.

5) Make sure the pickup element is directed toward the mouth (see photo).

Rotate the pickup element so that the large opening faces the mouth. Remove the foam windscreen to observe the large and small openings in the pickup element, then replace the windscreen.



Remove foam windscreen to observe large and small openings in the pickup. The larger opening must point toward the mouth for best performance. Do not position the pickup element directly in front of the mouth, since breath pops directly into the capsule will cause severe distortion.

Pickup Type: Polar Pattern: Bias Requirements: Current drain: Wiring configuration:

Frequency response:

Maximum input level:

Back electret condenser Bi-directional, noise cancelling +1.3 to +20V DC 50 uA • Red: + DC bias • White: audio + signal • Shield: Audio ground 200 - 6000 Hz (2 cm, close-talking) 120 dB SPL

Specifications

- Waterproofing: Boom length: Cable length: Weight: Connector:
- Secondary diaphragm 4.5 inches 44 inches 1.6 ozs. 2.5 mm Locking micro



2.5mm locking micro plug



581 Laser Road NE • Rio Rancho, NM 87124 USA • www.lectrosonics.com (505) 892-4501 • (800) 821-1121 • fax (505) 892-6243 • sales@lectrosonics.com