

## EASEL ACCESSORIES

### White Board Package

Contains 1 each red, blue, green and black dry erase markers, one eraser, one bottle of white board cleaner and one telescopic pointer.



### Paper Pad Package

Consists of 1 each red, blue, green and black dry erase markers, one standard paper pad, and one telescopic pointer.



### Dry Erase Markers

Blue dozen  
Black dozen  
Red dozen  
Green dozen



### Dry Erase Markers

One each: blue, green, red and black.



### Paper Pads

Contains 5 pads per carton, 35 sheets per pad.

- A-306 Plain 27" x 34"
- R-305 Grid ruled 1", 27" x 34"
- G-332-Giant Plain 45" x 34"
- T-106-Junior Plain 19" x 24"



Contains 10 pads per carton, 20 sheets per pad.

- S-200 Plain 27" x 34"

Contains 2 pads per carton, 30 sheets per pad.

- P-400-Post-It® Plain 25" x 30"
- P-405-Post-It® Grid ruled 25" x 30"

### Laser Pointers

The ultimate in presentation convenience. Select from three models.

- Laser Pointer
- Blinking Laser Pointer
- Jumbo Laser Pointer



### Carrying Case

Durable nylon zippered case fits all sizes of paper pad, writing surface and folding dual-purpose easels.

- Standard Paper Pad, Porcelain, or A-Frame
- Giant
- D-305 Portable Easel
- H321, Brass Easels or
- H323

