

031=591235001	DIAPHRAGM 7110XC/ID30C8/30CT
031=26421XX	DIAPHRAGM 802/806A/605A
031=26420XX	DIAPHRAGM 8028G/6048K/9028A
031=25885XX	DIAPHRAGM ALTEC 299 160HM
031=81256XX	DIAPHRAGM DH1A/DH2012
031=81320XX	DIAPHRAGM DH1A-16
031=82816XX	DIAPHRAGM DH2A 160HM
031=81161XX	DIAPHRAGM DH2A/DH2T
031=81498XX	DIAPHRAGM DH3 SH1810H-ER
031=84234XX	DIAPHRAGM DH7 QRX112
031=81514XX	DIAPHRAGM FM1202ER/SX SERIES
031=89858XX	DIAPHRAGM FM1502/S1202 DH1202
031=85558XX	DIAPHRAGM ID60CT/ID60C8
031=591239000	DIAPHRAGM ID60D8
031=SPARE PART 402	DIAPHRAGM MLCT
031=DIAPH KIT	DIAPHRAGM MOD KIT 031=26421XX
031=85535	DIAPHRAGM PA430T
031=89753A	DIAPHRAGM S200
031=89222A	DIAPHRAGM SENTRY SER/MUSICASTR
031=84233XX	DIAPHRAGM Xi1152
031=89486A	DIAPHRAGM, T35/S1503/ST350
<b>GEMINI</b>	
712=DIA-500/1000	DIAPHRAGM, HF H500
<b>JBL</b>	
050=D8R075	DIAPHRAGM 2402H
050=D16R2405	DIAPHRAGM 2405/2404H DRIVERS
050=D8R2406	DIAPHRAGM 2406H MPRO415
050=D8R2417	DIAPHRAGM 2417H
050=D8R2425	DIAPHRAGM 2426H/2425H/2425HS
050=D16R2441	DIAPHRAGM 2441 DRIVER
050=D8R2445	DIAPHRAGM 2445
050=D16R2445	DIAPHRAGM 2445J 160HM
050=D16R2450	DIAPHRAGM 2446J/2447J/2450J
050=D8R2450	DIAPHRAGM 2447H/2446H
050=D8R044	DIAPHRAGM DWT-044A
050=D8R2415	DIAPHRAGM MI632A/MI631
050=D8R2416-1	DIAPHRAGM SR4722/G734/MR802
050=D8R035TI	DIAPHRAGM, TWEETER
050=330862-001	DIAPHRAGM, TWEETER 6208
050=D16R2425	DIAPHRAGM 2425J/2426J/2427J
050=D8R2418-1	DIAPHRAGM 2418H EONG2/EON15
<b>KLIPSCH</b>	
722=K-1132-8	DIAPHRAGM
<b>KRIX</b>	
728=DR.R7450	DIAPHRAGM KX7450
<b>MACKIE</b>	
659=15410105	DIAPHRAGM, TWEETER OLD SA1521
<b>PANASONIC</b>	
298=EASCD3505B	DIAPHRAGM WSA200
<b>PEAVEY</b>	
455=00327470	DIAPHRAGM, 22XT DRIVER
455=00452400	DIAPHRAGM RX22 DRIVER
455=00577340	DIAPHRAGM 22XT+/SP2G
455=70777059	DIAPHRAGM, TWEETER W/O RED RING
455=70777115	DIAPHRAGM, HORN PR1000/KBA300
455=76000541	DIAPHRAGM 14XT TLF5X
<b>PANASONIC</b>	
298=EASCD3505B	DIAPHRAGM WSA200
<b>SAMSON</b>	
083=200027	DIAPHRAGM,TWEETER RS15M
<b>TANNOY</b>	
587=79000550	DIAPHRAGM CPA12/112
587=79000304	DIAPHRAGM SYSTEM 10-II TWEETER
<b>TOA</b>	
250=DG431-8	DIAPHRAGM 38SD TWEETER
<b>TURBOSOUND</b>	
132=RD-103	DIAPHRAGM CD103
132=RD-107	DIAPHRAGM CD107 TFM212/TCS56
132=RD-165	DIAPHRAGM CD165 YHL2/THL811W
132=RD-508	DIAPHRAGM IMPACT 80 TW508
132=RD-102	DIAPHRAGM, 1 TMS2
<b>UNIVERSITY</b>	
034=85679	DIAPHRAGM ID30CT/CFID-32T
034=85558XX	DIAPHRAGM ID60C8
034=85615XX	DIAPHRAGM ID60DT
034=86806B	DIAPHRAGM PA30A 16 OHM
<b>YAMAHA</b>	
682=NBE20610	DIAPHRAGM S115N/S112HII/S115V/12V

682=NB074960	DIAPHRAGM JA4201/4204/4208
682=NBFO0001	DIAPHRAGM S112/S112H
682=NBFO0002	DIAPHRAGM SM10HII HORN

## » EAR PADS & OTHER PADS

### AKG

001=2144Z1601	EAR PAD K141 (EACH)
001=2260Z0901	EAR PAD INSERT K240DF
001=2118Z0301	EAR PAD K135S/145S +2144Z0801
001=2019Z0402	EAR PAD K18 (EACH)
001=2058Z1001	EAR PAD K240/M/DF/S/K241 (EACH)

### AUDIO TECHNICA

010=135405750	EAR PAD ATHM30 (EACH)
010=050572200	EAR PAD ATH910 (EACH)
010=102410042	EAR PAD ATHM2X/ATHM3X (EACH)
010=135300210	EAR PAD HD40/ATHM40FS/ATHD40FS
010=1454-05950	EAR PAD PRO8HE (EACH)

### BEYER DYNAMIC

014=907.003	EARPAD DT108/DT109 (PAIR)
014=431.532	EAR PAD DT150/180/190 (PAIR)
014=304.956	EAR PAD DT48 (EACH)
014=442.704	EAR PAD,VELOUR DT200 SERS (PR)
014=407.097	EAR PAD,VINYL DT770 (PAIR)

### CLEAR COM

017=500115	EAR PAD CC26
017=505000	EAR PAD CC85
017=506007	EAR PAD CC95 (EACH)
017=140011	EAR SOCK ES-1 (PAIR)

### CROWN

024=D8399-4	CHEEK PAD CM311A/CM312
-------------	------------------------

### FOSTEX

035=14169001100	EAR PAD T20RP (EACH)
035=1416902600	EAR PAD (OVAL) T20RPMKII/T20

### GENTNER

546=910-402-101	EAR BUD ASSY, RX1A/DIGITAL 6
546=910-402-102	EAR BUD ASSY, DUAL RX1A

### MAXON

114=830-680	EAR TIP, LARGE 49FX
114=830-685	EAR TIP, SMALL 49FX

### SENNHEISER

081=HD222-03	EAR PAD HD230 (PAIR)
081=40179	EAR PAD HD25 (PAIR)
081=HD250-03	EAR PAD HD250 (PAIR)
081=H-19545	EAR PAD HD414 (PAIR)
081=HD424-03	EAR PAD HD424 (PAIR)
081=H-50757	EAR PAD HD433/HD435 (PAIR)
081=37893	EAR PAD HD450/480/490 (PAIR)
081=HD450-03-II	EAR PAD HD480 (PAIR)
081=H-75527	EAR PAD HMD25 (PAIR)
081=H-40179	EAR PAD HMD25-1/HD25SP (PAIR)
081=85733	EAR PAD HMD280 (PAIR)
081=33175	EAR PAD HMD410/HD410SL (PAIR)
081=533175	EAR PAD N400-04AQ (PAIR)
081=69417	EAR PAD, VELOUR HMD25/HD25 (PAIR)

### SHURE

084=FY2600	EAR PAD SM2 (EACH)
------------	--------------------

### SONY

161=2-115-668-03	EAR PAD MDR7506/MDRV6 (EACH)
161=4-954-041-11	EAR PAD (L) MDRV600
161=4-954-042-11	EAR PAD (R) MDRV600
161=X-2113-123-1	EAR PAD MDR7502
161=X-2113-111-1	EAR PAD, MDR7504/MDRV4 (EACH)

### TELEX

097=64301-000	EAR FOAM,EACH,FOR PH8
097=800024-001	EAR PAD HR1
097=560353001	EAR PAD HR2/HR2R5 (EACH)
097=590097000	EAR PAD OH1V
097=800027-003	EAR PAD PH SERIES (PAIR)
097=63444-001	EAR PAD PH1 (EACH)
097=590402-002	EAR PAD PH4/PH5/PH8 (EACH)
097=590626-001	EAR PAD PH88/PH44 (EACH)
097=59840-006	EAR PAD SEB1 (12 PACK)
097=590000-000	EAR PAD V-SERIES

### WILLIAM SOUND

043=EAR031	EAR PAD WIRRX95 (PAIR)
043=HED003	EAR PADS (PAIR) HED001 OLDER

We have parts for every manufacturer's product that we sell.  
Call and ask for extension 1358.

Full Compass. SERVICE AMPLIFIED