

**DBX / DOD**

025=34-0159-A  
025=PHOENIX 6P  
025=34-0160-A  
025=26-0268-A

CAP,FADER 2231/IEQ3102  
CONNECTOR,6P PHOENIX ZONE PRO  
KNOB W/POINTER 166XL/2215  
POWER TRANS 166XL/223/410/234

**DENON**

162=2124775905  
162=2125604907

SWITCH,TACT DN-650F  
SWITCH,TACT EJECT SW203 DNT620

**EASTERN ACOUSTIC WORKS [VIEW ONLINE](#)**

394=15410104  
394=15410073  
394=15410083  
394=806061  
394=806023  
394=15410065  
394=0001386  
394=152001  
394=11460008  
394=102017  
394=804097  
394=0010572  
394=0012338  
394=805005  
394=805016  
394=105007  
394=105008  
394=105061  
394=804095  
394=804052  
394=804041  
394=804104  
394=11186029  
394=804003  
394=804056

DIAPHRAGM AS460/490 HF DRIVER  
DIAPHRAGM AS690I  
DIAPHRAGM CD3501 SM122E DM2521  
DIAPHRAGM DM2522 FR129Z/FR159  
DIAPHRAGM DM5001 LA325 KF650  
DIAPHRAGM HF DRIVER JF80/JF80Y  
FLY CLIP W/RING FOR FLY RAIL  
FOOT,RUBBER SM/LA/FR SERIES  
RECONE KIT LC1523/LC15542K  
SCREW JF60 BRACKET  
SPEAKER 10" DC1 KF650Z  
TWEETER ASSY VR51/VR21  
TWEETER JF60Z/JF60/UB80  
TWEETER UB12S  
TWEETER UB12SE  
WASHER,FLAT JF60 BRACKET  
WASHER,LOCK JF60 BRACKET  
WASHER,NEOPRENE JF60 BRACKET  
WOOFER 12" FR129Z/SM129Z  
WOOFER 15" SB250P/SB600E/SB150  
WOOFER 18" LC1814 SB180R/SB850  
WOOFER 18" LC1816 SB180Z/SB850  
WOOFER 18" SB1000E LC1815  
WOOFER 6.5" JF80/JF80Y/JF60  
WOOFER LC0532 UB12SE

**ELATION [VIEW ONLINE](#)**

077=SY2504F-B20

OMEGA BRACKET DESIGN SPOT 250

**ELECTRO-VOICE [VIEW ONLINE](#)**

031=591183000  
215=450372  
031=63105CP  
031=0355117  
031=71241  
031=500574000  
031=14-09-032487  
031=560426220  
031=539173000  
031=701432000  
031=800688001  
031=560206000  
031=83850  
031=85551  
031=89486A  
031=591237001  
031=591244001  
031=591238002  
031=560343011  
031=591235001  
031=81161XX  
031=81498XX  
031=81514XX  
031=89858XX  
031=81320XX  
031=85558XX  
034=85615XX  
031=81256XX  
031=89222A  
031=84234XX  
031=84233XX  
031=89753A  
031=301052101  
031=833PD990  
031=28308  
031=28261  
031=71944

ADAPTER,HORN HB640 TO DH7/ND6  
BATTERY COVER MT2000A/MT2500  
BOLT,MB300 MOUNTING KIT  
BRONZ CLIPS 100MM  
BUMPER RING (GOLD) GRILL ND767  
CASTER W/WHEEL POCKET QRX218  
COLLAR INSERT COBRAFLEX III  
CONNECTOR,CABLE 4P PHOENIX ZXI  
CONNECTOR,PHOENIX 4P C4.2/C8.2  
CORNER,CABINET 90 DEG FORCE SR  
CROSSOVER EVID 6.2  
CROSSOVER EVID C 8.2  
CROSSOVER NETWORK SX500/SX500+  
CROSSOVER W/SPKON FORCE-I SERS  
DIAPH.TWEETER T35/S1503/ST350  
DIAPHRAGM 1828 CDP848AT/BK315  
DIAPHRAGM 1829  
DIAPHRAGM 1829BT/1823M 16 OHM  
DIAPHRAGM 1829T/CDP850T  
DIAPHRAGM 7110XC/ID30C8/ID32T  
DIAPHRAGM DH2A/DH2T T252(+)+CBR  
DIAPHRAGM DH3 8330997/8331428  
DIAPHRAGM ELIMINATOR/SX SERIES  
DIAPHRAGM FM1502/S1202 DH1202  
DIAPHRAGM FOR DH1A-16  
DIAPHRAGM ID60CT/ID60C8  
DIAPHRAGM ID60DT  
DIAPHRAGM KIT DH1A/DH2012  
DIAPHRAGM SENTRY/FM12/MUSICSTR  
DIAPHRAGM,HF DH7 QRX112/QRX115  
DIAPHRAGM,HF ND6-16 XI1152  
DIAPHRAGM,TWEETER S200  
DRIVER ASSY HF ND6 160HM  
DRIVER ASSY,HF DH3 SX200/SX300  
FOOT,RUBBER SX200A/ELIMINATOR  
FOOT,RUBBER T52/T52+  
FOOT,TILT BACK SX200/SX300

031=56676020  
031=73997FT  
031=20558  
031=74144  
031=570255000  
031=PLASTIC NUT  
031=28012  
031=81386XX  
031=84591XX  
031=83523XX  
031=85117XX  
031=520028-011  
150=70383  
031=71220X  
031=603215BAD  
031=78297  
031=361376  
031=56-05-022109  
031=560045000  
031=591655000  
031=KIT000005001  
031=38829  
031=74098  
031=500745000  
031=500717000  
031=812PD3283  
031=812WPD3283  
031=301583101  
031=301206101  
031=301207101  
031=560459100  
031=560042000  
031=82129  
031=560056101  
031=85604CPD  
031=815PD3010  
031=73028C

FUSE 3.15A SXA100+  
GRILLE S40 WHITE  
HANDLE SXA250/ELIMINATOR  
INPUT PANEL SX80B W/SPEAKON  
LOGO,GRILLE QRX218  
NUT,PLASTIC 1/4" JACK ELIMINATR  
O-RING,FOOT SX300  
RECONE KIT 818PD2492 DL18T  
RECONE KIT 818PD2883 18" WOOF  
RECONE KIT EVX180  
RECONE KIT,EVX155  
RESISTOR,.1 OHM 5W 5% SXA250  
RUBBER BANDS, 313A  
RUBBER HAND GRIP ND757/ND457..  
SCREW,TERMINAL BLOCK RE20  
SHOCKMOUNT BAND 309A (EACH)  
SPEAKER,MID 4" C8  
TRANSFORMER 70V 30W 7110XC ID3  
TWEETER EVID 6.2/4.2  
U-CHANNELS,GRILLE SBA760  
WALL MOUNT KIT ZX1-90/ZX11-90  
WASHER SX300  
WINDSCREEN POLAR CHOICE 18  
WINDSCREEN US1718/RE90P (EACH)  
WINDSCREEN,FOAM PCXL/PC+  
WOOFER 12" SX200/SX300/100S  
WOOFER 12" WEATHERPROOF SX300  
WOOFER 15" ZX560B/90B DVX3150  
WOOFER 18" (BLACK) DL18MT ISUB  
WOOFER 18" COBRAII PWH EVX180B  
WOOFER 8" ZX190 XI1082/SX80PI  
WOOFER EVID 6.2  
WOOFER FOR S40/S40W  
WOOFER SENTRY 100A/100EL/MS802  
WOOFER SXA100/SXA100+/SX100+E  
WOOFER T252+/T251+/QRX115-75  
XLR CONNECTOR HOUSING RE90L

**EMINENCE SPEAKER [VIEW ONLINE](#)**

744=APT3  
744=PSD2002-8DIA  
744=APT50  
744=PSD2002-8  
744=PSD2002S-8  
744=LEGEND-CB15  
744=ALPHA-6A  
744=ALPHA-10A  
744=BETA-10A  
744=ALPHA-12A  
744=BETA-12A-2  
744=DELTA-12A  
744=KAPPA-12A  
744=ALPHA-15A  
744=DELTA-15A  
744=KAPPA PRO-15A  
744=KAPPA PRO-15LF-2  
744=OMEGA PRO-15A  
744=KILOMAX PRO-18A  
744=OMEGA PRO-18A  
744=ALPHA-8A

ADAPTER,SCREW-ON(SEE 509=APT3)  
DIAPHRAGM 1" 80HM PSD2002  
DRIVER ASSY,HF 45W 80HM  
DRIVER,HF 80W 80HM BOLT-ON 1"  
DRIVER,HF 80W 80HM SCREW-ON  
SPEAKER 15" 300W BASS GUITAR  
SPEAKER 6" 100W 8 OHM PA  
WOOFER 10" 150W 80HM PA  
WOOFER 10" 250W 80HM PA  
WOOFER 12" 150W 8 OHM PA  
WOOFER 12" 250W 80HM PA  
WOOFER 12" 400W 80HM PA  
WOOFER 12" 500W 80HM PA  
WOOFER 15" 200W 8 OHM PA  
WOOFER 15" 400W 80HM PA  
WOOFER 15" 500W 80HM PA  
WOOFER 15" 600W 80HM PA  
WOOFER 15" 800W 80HM PA  
WOOFER 18" 1250W 80HM PA  
WOOFER 18" 800W 8 OHM PA  
WOOFER 8" 125W 80HM PA

**ETC [VIEW ONLINE](#)**

558=HW5125  
558=HW5193  
558=7060A3058  
558=7081A2202-2A  
558=4110A-4036  
558=P120  
558=F113  
558=X196-F  
558=7060A3043  
558=7061A3007  
558=7060B7003  
558=Z1458-F  
558=7060A4008-01  
558=HW8112  
558=7060A4008-02  
558=HW8201  
558=7060A4033

BOLT,T-HANDLE KNOB SOURCE 4  
BOLT,ZINC BLACK SOURCE 4  
BRACKET,YOKE BLACK SOURCE 4  
COVER,2 BUTTON STATION (IVORY)  
FADER SF2496  
FADER,CHANNEL MICROVISN/ACCLAIM  
FUSE 1.25A 250V  
FUSE HOLDER SMARTBAR  
GEL FRAME 6.25" BLACK SRC 4 JR  
GEL FRAME PAR BLACK  
GROUND WIRE #16 ASSY SOURCE 4  
IC  
KNOB SET WITH MALE INSERT S4  
KNOB,CHANNEL FADER ACCLAIM  
KNOB,F INSERT TO Z  
KNOB,ZOOM LENS SOURCE 4/JR  
LABEL,LENS TUBE 19 DEGREE S4

558=7060A4034 LABEL, LENS TUBE 26 DEGREE S4  
 558=7060A2008 LAMP BURNER ASSY BLACK SRC 4  
 558=7060A1033 LAMP RETAINER RETROFIT KIT S4  
 558=7060A3085 LAMP RETAINER WIRE SOURCE 4  
 558=7061A2001 LAMP SOCKET ASSY (BLACK) PAR  
 558=RT114 LAMP SOURCE 4/JR EXTENDED LIFE  
 558=W330-01TP22CLCM LEAD WIRE, PAR SOCKET SOURCE 4  
 558=7061A4012 LENS ROTATION RING, BLACK S4PAR  
 558=7060A4077 LENS, ASPHERIC 19 DEG SOURCE 4  
 558=7061A4002 LENS, VERY NARROW SOURCE 4 PAR  
 558=7060A4012 PAD LENS SUPPORT SOURCE 4  
 558=7099A1201B PANNEL MOUNT STAGE PIN CONN.  
 558=Q141 POWER CUBE D20  
 558=Q210 POWER CUBE SMARTPAK 2-10A 6PIN  
 558=Q211 POWER CUBE SMARTPAK 4-10A 8PIN  
 558=4105K1004 POWER SUPPLY 2-PORT TNODE 24V  
 558=7060A4037 REAR HANDLE BLACK SOURCE 4  
 558=7060A4015 REFLECTOR 19 DEGREE SOURCE 4  
 558=7060-A3085 RETAINER WIRE, LAMP  
 558=7060A2025 SHUTTER BLADE ASSY SOURCE 4  
 558=W6195 SLEEVE, FIBREGLASS 39" BLACK  
 558=7060B7019 SOCKET ASSY TP22 SOURCE 4/JR  
 558=M706 SOCKET ASSY, TP22 SOURCE 4 PAR  
 558=W330-04 SOCKET/LEAD WIRE HPL575 SOURC4  
 558=7061A3013 SPRING CLIP RETAINER SOURCE 4  
 558=HW750 SPRING CLIP RETAINER SOURCE 4  
 558=7060A3012 SPRING, LAMP RETAINER SOURCE 4  
 558=HW8144 T-HANDLE KNOB SOURCE 4 YOKE  
 558=HW8209 TINNERMAN CLIP, WIRE SOURCE 4  
 558=HW5126 WASHER, T-HANDLE KNOB SOURCE 4

### EVENT

420=1099  
 420=1825  
 420=1100

TWEETER 2020 TR8/PS6  
 TWEETER ASP8N/STUDIO PRES  
 WOOFER 8" 2020BAS/II/PS8/TR8

### FBT

724=19455

DIAPHRAGM, HF JOLLY SERIES

### FENDER PRO AUDIO [VIEW ONLINE](#)

933=0057531000  
 933=0070564000  
 933=005-7535-000  
 933=0070370000  
 933=70553

CORD, POWER PASSPORT P10  
 LATCH KIT, SPEAKER PASSPORT 150  
 RECHARGEABLE BATTERY P10  
 TWEETER PASSPORT PD150/PD250  
 WOOFER 6.5 INCH PASSPORT P150

### FOSTEX [VIEW ONLINE](#)

035=1445900000  
 035=1412000700  
 035=1412000300  
 035=1445800100  
 035=8240273000  
 035=1412000501  
 035=8253135002  
 035=L810F07CA4

CABLE T20/T40 REMOVABLE  
 CONNECTOR A  
 CONNECTOR C  
 JACK, STEREO W/NUT  
 POT, VOL CONTROL, 6301B, TAIWAN  
 SLIDER HOLDER, REAR T20/T40RP  
 SWITCH, TACT TRANSPORT MR8/VF80  
 WOOFER SPA11

### FURMAN [VIEW ONLINE](#)

620=401003-392  
 620=986001-1429  
 620=390688-3993  
 620=E-543  
 620=E-590  
 620=E-411

CAP, LIGHT TUBE PL8  
 KEYS, QUARTER SIZE (PAIR) CODE?  
 LED ASSY, LIGHT PL8II/PL PLUSII  
 POT, MONO 10K VOLUME HR6  
 POT, STEREO 10K MON/EFF/VOL HR6  
 VARISTOR, METAL OXIDE ACD100

### GALAXY AUDIO [VIEW ONLINE](#)

954=S5N-8  
 954=SAGVC  
 954=PHSI  
 954=SS5C160-8

DRIVER, NEOLITE 5" HOTSPOT/MICR  
 GRILLE, FOAM HOTSPOT W/VOLUME  
 INSERT, STAND ADAPTER HOT SPOT  
 SPEAKER, HOT SPOT VENTED MAGNET

### GENTNER

546=910-200-001  
 546=592158003  
 546=41-6041  
 546=41-6015

BATTERY DOOR RX1A DIGITAL ONE  
 BATTERY, MAX WIRELESS PHONE  
 EAR PAD (LEFT) DMH220  
 EAR PAD (RIGHT) DMH220

### JBL [VIEW ONLINE](#)

050=361858-002  
 050=179-00002-00  
 050=424-00092-00  
 050=73393-011  
 050=73364-011  
 050=73423-011  
 050=73392-011  
 050=73392-041  
 050=73392-021  
 050=73392-031  
 050=C1006  
 050=C5006  
 050=336836-001  
 050=338142-001  
 050=129-20020-01  
 050=350261-001  
 050=129-20052-01  
 050=364248-001  
 050=D16R2405  
 050=D8R2407  
 050=D8R2408  
 050=D8R2417  
 050=D8R2418-1  
 050=D16R2425  
 050=D8R2425  
 050=D16R2445  
 050=D16R2450  
 050=D8R2452  
 050=D8R2416-1  
 050=315436-001X  
 050=2416H-1  
 050=125-10000-00X  
 050=339013-001X  
 050=888-00025-00  
 050=EB-6X12  
 050=924-00002-01  
 050=321902-003  
 050=453-13402-00  
 050=SK3  
 050=473002  
 050=128-00163-61  
 050=128-00400-00  
 050=337841-001  
 050=923-00021-00  
 050=923-00020-00  
 050=126-00023-00  
 050=229-0009-01  
 050=65076  
 050=350049-003X  
 050=885-00050-00  
 050=364994-001  
 050=350316-001  
 050=339555-001  
 050=888-00026-00  
 050=659-00007-00  
 050=513-00046-00  
 050=824-41110-10  
 050=804-01110-16  
 050=804-41110-16  
 050=729-90001-16  
 050=803-41000-07  
 050=882-51110-12  
 050=129-10000-03  
 050=705-90000-16  
 050=123-00001-00  
 050=337663-001  
 050=C1002  
 050=123-10002-00  
 050=350245-001  
 050=C5002  
 050=123-10003-00X  
 050=114-21001-00X  
 050=336961-001X  
 050=73284-01X  
 050=67071-01X  
 050=C1003  
 050=124-58001-00  
 050=337646-001

BALL LOCK PIN VRX932LA  
 BALL MOUNT, BLACK CONTROL 25/28  
 CONNECTOR CONTROL 24CT/26C  
 CORNER PROTECTOR SR4719/4691B  
 CORNER, L/R LOWER MIDDLE MR905  
 CORNER, L/R UPPER REAR MR905  
 CORNER, TOP L/BOTTOM R FRONT  
 CORNER, TOP L/BOTTOM R REAR  
 CORNER, TOP R/BOTTOM L FRONT  
 CORNER, TOP R/BOTTOM L REAR  
 CROSSOVER CONTROL 1  
 CROSSOVER CONTROL 5  
 CROSSOVER NETWORK ASSY MP215  
 CROSSOVER NETWORK CONTROL 25T  
 CROSSOVER NETWORK CONTROL 28WH  
 CROSSOVER NETWORK CONTROL 30  
 CROSSOVER NETWORK EON 1500  
 CROSSOVER NETWORK JRX125  
 DIAPHRAGM 2405/2404H DRIVERS  
 DIAPHRAGM 2406H-1/2407H AM4215  
 DIAPHRAGM 2408H MRX512 MRX515  
 DIAPHRAGM 2417H  
 DIAPHRAGM 2418H EONG2/EON15G2  
 DIAPHRAGM 2425J/2426J/2427J  
 DIAPHRAGM 2426H/2425H/2425HS  
 DIAPHRAGM 2445J 160HM  
 DIAPHRAGM 2446J/2447J/2450J  
 DIAPHRAGM 2452H SRX725/VRX915M  
 DIAPHRAGM SR4722/G734/MR802  
 DRIVER 2418H MR900/EON SERIES  
 DRIVER ASSY MR SERIES/OTHERS..  
 DRIVER, HF 2412H TR/EON10/MS28  
 DRIVER, HF 2412H-1 JRX/SF SERIE  
 ENCLOSURE PLATE CONTROL 25/28  
 EYEBOLT, TOP/BOTTOM CONTROL29AV  
 FOOT, SOUND FACTOR SERIES  
 FUSE 2A TIME LAG EON POWER 10  
 FUSE 4A TIME LAG EON15P  
 FUSE LAMP, CROSSOVERS  
 FUSE, PICO 2A SLOBLO CONTROL 28  
 GRILLE ASSY CONTROL 25 WHITE  
 GRILLE EON1500/EON15/EON15P  
 GRILLE W/FOAM, WHITE CONTROL 29  
 HANDLE BACK MR/TR SERIES  
 HANDLE BAR MR/TR SERIES FRONT  
 HORN LENS 60X50 15"X10.5"X6.5"  
 INSTALL KIT SP215/9  
 JACK, INPUT SR4738/SR4722  
 MID-RANGE SPEAKER VERTEC 4887  
 MOUNTING TAB CONTROL 24  
 NUT, PLASTIC 1/4" JACK MP SERIE  
 PCB, INPUT SIGNAL EON10G2  
 PCB, MAIN AMP EON15PG2  
 PIVOT CONTROL 25/CONTROL 28  
 POT, SLIDE 10K STEREO EON MIXER  
 POT, VOLUME LSR25P  
 SCREW, GRILL MP415  
 SCREW, WOOFER  
 SCREW, CABINET EON POWER 10  
 SCREW, FOOT JRX SERIES  
 SCREW, GRILLE EON1500  
 SCREWS, INPUT PANEL MP215  
 TERMINAL CUP, NETWORK CONTRLSB2  
 THUMBSCREW FOR EON SERIES  
 TWEETER ASSY CONTROL 25  
 TWEETER ASSY CONTROL 29AV  
 TWEETER CONTROL 1  
 TWEETER CONTROL 28  
 TWEETER CONTROL 30  
 TWEETER CONTROL 5  
 TWEETER LSR32/MS26/LSR28P  
 WOOFER 10" CONTROL SB2  
 WOOFER 12" M112 8 JRX112M 212  
 WOOFER 4208 508G-3S/6208/MS28  
 WOOFER 4301B/4408/4408A  
 WOOFER CONTROL 1  
 WOOFER CONTROL 28  
 WOOFER CONTROL 29/C29AV-1

