

MACKIE

659=090-008-00	RACKEAR 1202 (PAIR)
659=RM1642-VLZ	RACKEAR 1642-VLZ-PRO (PAIR)
659=550-005-00	RACKEAR CR1604 (EACH)
659=550-030-00	RACKEAR CR1604 ROTOPOD LEFT
659=550-029-00	RACKEAR CR1604 ROTOPOD RIGHT
659=550-177-00	RACKEAR CR1604VLZ (EACH)

NUMARK

036=F-BK-042-00	RACK EAR (EACH) 5000FX
-----------------	------------------------

PANASONIC

298=RYQ0059-2	RACKEAR SV3800/SV3700 (PAIR)
---------------	------------------------------

QSC

115=FG-000031-00	REAR RACK RAILS (PAIR) PLX/PL
115=FG-0000-31-00	RACK EARS, REAR (PAIR) MX3000A
115=FG000081-00	REAR RACK EAR KIT 7

SAMSON

083=470007	RACK EAR (EACH) S700
083=470124	RACK EAR S1000
083=492097	RACK EAR (EACH) SERVO 120

SHURE

084=53A8252	RACK EAR FP410 LEFT
084=53A8253	RACK EAR FP410 RIGHT
084=53A8381	RACK EAR, LONG LX/SC (EACH)
084=53A8481	RACK EAR, LONG UC4/P6T (SINGLE)
084=53A8350	RACK EAR, SHORT SC/LX (EACH)
084=53B8484	RACK EAR, SHORT SCM262/ULX
084=53A8611	RACK EAR, SHORT SLX RECEIVER
084=53A8459	RACK EAR, SHORT UC4/P6T
084=53A8425	RACKMOUNT KIT LX88

SONY

161=3-920-800-21	RACKMOUNT TCWR565 (NEED 2)
------------------	----------------------------

SPRINT

266=RW1255	RACKMOUNT KIT RW8000
------------	----------------------

TEAC

095=3M0026600B	RACK EAR (EACH) CDA500
095=9260293700	RACK EAR 302 (EACH)

TELEX

215=378224	RACK MOUNT BRACKET BTR200/300
------------	-------------------------------

TOA

250=MB931A	RACKMOUNT KIT A912A
------------	---------------------

EMINENCE RAW FRAME SPEAKERS

PRO-AUDIO APPLICATION	SIZE	RMS	POWER (OHMS)
744=ALPHA-8A	8"	125W	8
744=ALPHA-10A	10"	150W	8
744=HL10	10"	300W/SUB	8
744=BETA-12A	12"	250W	8
744=BETA-12CX	12"	250W/COAX	8
744=GAMMA-12A	12"	300W	8
744=KAPPA-12A	12"	450W	8
744=GAMMA-15A	15"	300W	8
744=DELTA-15A	15"	400W	8
744=KAPPA-15A	15"	450W	8
744=KAPPA PRO-15A	15"	500W	8
744=KAPPA PROLFA-2	15"	600W	8
744=OMEGA PRO-15A	15"	800W	8
744=KILOMAX PRO-18A	18"	1250W	8
744=KAPPA-18A	18"	500W	8

GUITAR APPLICATION

744=LEGEND MODLNG 12	12"	120W/GUITAR	8
744=LEGEND-V12 8	12"	120W/GUITAR	8
744=SWAMP THING	12"	GUITAR	8
744=LEGEND-B15	15"	300W / BASS	8

REMOTE CONTROLS**CANON**

438=D83-0502	REMOTE CONTROL ELURA-ORIGINAL
438=D83-0592	REMOTE CONTROL WLD3000 XL1S

DENON

162=2042656025	REMOTE CABLE 8PIN DN2500F/MK2
162=3990628007	REMOTE CONTROL DNC550R

JVC

051=YQ20922U	REMOTE CONTROL RM-V712U
051=LP21036-038B	REMOTE CONTROL HR-XVC26U

MARANTZ

060=ZK386K0010	REMOTE CONTROL CDR500/CDR510
060=482221910574	REMOTE CONTROL CDR630
060=ZK21AW0010	REMOTE CONTROL PMD910
060=PMD930	REMOTE CONTROL PMD930

PANASONIC

298=VEQ2063	REMOTE CONTROL AG1330
298=LP20878-022C	REMOTE CONTROL AG3200
298=N2QAE000003	REMOTE CONTROL AGDVC7/AGEZ50
298=EUR7615LBO	REMOTE CONTROL AGVP300P
298=EUR501450	REMOTE CONTROL CT2089VYD
298=EUR511112	REMOTE CONTROL CT27G13
298=N2AQAE000015	REMOTE CONTROL FOR PTL735U
298=N2QAE000023	REMOTE CONTROL PTD3500/PTD5500
298=TNQE239	REMOTE CONTROL PTL501/701/711U
298=LRQ90017	REMOTE CONTROL PTL556U/555U
298=N2QAE000003	REMOTE CONTROL PTL6510/6500UL
298=N2QAE000011	REMOTE CONTROL PTL780NTU/750U
298=N2QAE000022	REMOTE CONTROL PTL785U
298=N2QADC000008	REMOTE CONTROL PTLB20U/PTLB10U
298=LSSQ0333	REMOTE CONTROL PVD4742
298=EUR7724KFOR	REMOTE CONTROL PVD4745
298=EUR7724020	REMOTE CONTROL PVD62704
298=LSSQ0286	REMOTE CONTROL PVV4611
298=EUR501371	REMOTE CONTROL CT2086Y,CT20R15
298=TNQE003	REMOTE CONTROL PTL592U,390U
298=EUR7724020R	REMOTE CONTROL PVD62035K/2735/04
298=VSQS1563	REOMTE CONTROL PVM1368

PIONEER

751=VXX2702	REMOTE CONTROL DV333
-------------	----------------------

SONY

161=1-476-255-11	REMOTE CONTROL CDRW33
161=1-475-1416-1	REMOTE CONTROL DSRV10
161=1-473-780-21	REMOTE CONTROL MDSJE510
161=1-476-303-11	REMOTE CONTROL MZR700DPC
161=1-477-723-11	REMOTE CONTROL RMT-D152A
161=1-479-361-11	REMOTE CONTROL RDRHX715
161=1-473-028-11	REMOTE CONTROL RM-D3M
161=RMTV501C	REMOTE CONTROL SLVD350P
161=9-885-079-55	REMOTE CONTROL SLVD360P RMT-V501E
161=1-465-369-11	REMOTE CONTROL TCWR565

TEAC/TASCAM

095=3E0139300A	REMOTE CONTROL AD600
095=3E0063500A	REMOTE CONTROL CDA500/CDA700
095=CEC4U10002601	REMOTE CONTROL CDP1120
095=4U10001409	REMOTE CONTROL RC305A/CD305
095=3E0103100A	REMOTE CONTROL RC32 MD301MKII

SPEAKERS, TWEETERS, WOOFERS**AKG**

001=2030Z0010	SPEAKER K240M
---------------	---------------

ALESIS

383=7-02-0028	TWEETER MONITOR 1 MKII
383=7-10-1205	TWEETER MONITOR 1/MONITOR 2
383=7-02-0002	WOOFER MONITOR 1
383=7-02-0023	WOOFER MONITOR 1 ACTIVE
383=7-02-0029	WOOFER MONITOR 1 MKII
383=7-02-0030	WOOFER MONITOR 1 MKII ACTIVE

ALTEC

746=399-16A	DRIVER ASSY 399-16A
-------------	---------------------

ANCHOR

002=498-0039-000	TWEETER AN100/AN100X/AN130
002=498-0038-000	WOOFER 8 LIBERTY EXTREME
002=498-0041-000	WOOFER AN1000X

BAG END

941=E-500	TWEETER TA15/TA5000
941=E-10	WOOFER 10 D10
941=SE1280	WOOFER 12 TA12/TA1200 (6 YRS)
941=E-15	WOOFER 15 TA15/TA5000

BEHRINGER

713=00TH-252	WOOFER 15 B1520
--------------	-----------------

BOGEN COMMUNICATIONS

835=HFDA6	DRIVER, HF NEAR A6/A8
835=LFDA8	WOOFER A8/A8WHIT

BOSE

505=187233-001	SPEAKER 203
505=123561-5D	SPEAKER 4.5 40HM 70V 101/102

We have parts for every manufacturer's product that we sell.
Call and ask for extension 1358.

Full Compass. SERVICE AMPLIFIED