

## INTRODUCTION

Thank you for purchasing the ikan V5600 Deluxe Kit. We know that you will be satisfied with our “V” series monitors. Please visit [www.ikancorp.com](http://www.ikancorp.com) for more information on our current and future products including our award-winning fluorescent studio lights and light accessories.

## PACKAGE INCLUDES


- V5600 5.6” TFT LCD Monitor
- AC Power Adapter
- Component Breakout Cable
- AV Breakout Cable
- Shoe Mount
- SC56 Soft Case
- Compatible DV Battery
- Compatible DV Battery Charger
- AC107 DV Battery Adapter (Check one)
  - AC107S** Sony "L" Series
  - AC107S-U** Sony "BP-U" Series
  - AC107C** Canon "900" Series
  - AC107P** Panasonic "D54" Series
- Mounting Plate
- 1 x M4x.07 x 8mm Metric Socket Head Screws
- 2 x Phillips Head Screw
- Hex Key



## GETTING STARTED


1. Powering The Monitor.
  - Plug the AC adapter into the power input jack located on the right side of the rear of the monitor.
  - AC107 DV battery adapter is included to provide for an additional power option.
2. Connecting The Video Source
  - The V5600 allows you to connect your video cables directly to the rear of the monitor, with support for SD/HD Component, Composite (A/V), and HDMI.

## MONITOR DIAGRAMS




1.	POWER	Power switch
2.	MENU	Access to all monitor settings: Brightness, Hue, etc.
3.	>	Volume up. In MENU mode, toggle as up adjust setting
4.	<	Volume down. In MENU mode, toggle as down adjust setting
5.	ASPECT	Aspect ratio: 4:3 or 16:9
6.	INPUT	A/V (Composite), SD/HD Component, HDMI
7.	GUIDES	On-screen guide: 4:3 or 16:9
8.		Headphone out
9.	AV	AV Connector
10.	LAMP	Power signal indicator

1.	DC 12V-24V Power Connection
2.	Component YUV
3.	HDMI Input
4.	Mounting Plate Holes



## ASSEMBLY INSTRUCTION



### CONDITIONS OF WARRANTY SERVICE

- Free service for one year from the day of purchase if the problem is caused by manufacturing errors.
- The components and maintenance service fee will be charged if the warranty period has expired.

Free Service will not be Provided in the Following Situations: (\*\* Even if the product is still within the warranty period.)

- Damage caused by abuse or misuse, dismantling, or changes to the product not made by the company.
- Damage caused by natural disaster, abnormal voltage, and environmental factors etc.