


Portable Bookshelf Speaker With Lithium Rechargeable Battery, Stereo, USB/SD Card Playback Aux In For iPod Android iPhone iPad

Features:

- USB/SD Card Support To Play Back Your Favorite Music
- 3.5mm Auxiliary Input to Connect iPod, iPhone, iPad, Android, MP3 Players
- Remote Control for Easy Operation
- Built-In Rechargeable Battery
- 5V DC Charger Included
- FM Radio
- Dimensions: 5.5'' X 4.7'' X 11.0''
- Speaker Power: 15 Watts X 2
- Frequency Response: 200 Hz-20 kHz
- Battery Capacity: 800mah

Instruction for appearance and key:



- 1. Infrared receiving window.
- 2. Menu
- 3. Last song/voice decrease (short press/long press).
- 4. Play/Pause
- 5. Next song/voice increase (short press/long press)
- 6. Power button ON-1 / OFF / ON-2. (ON-1 for the Build-in battery, ON-2 for the spare battery)
- 7. Audio input slot
- 8. Charging slot
- 9. Charging state indicator light.
- 10. Charging slot

- 11. USB card slot
- 12. Working state indicator light (red).
- 13. SD card slot
- 14. Spare battery cassette.

How to operate:

- 1. Turn the Power button to "ON-1", the working indicator light is red.
- 2. Insert SD/MMC card or USB flash disk into slot or connect MP3/MP4 or PC to speaker, audio files play automatically.
- 3. Under playing mode, short press LAST or NEXT to select songs you like, long press to adjust the voice up or down.
- 4. Press PLAY/PAUSE to play or pause.
- 5. Please turn the Power button to "OFF" while without use.

How to Use FM Radio:

- 1. Turn the power button to "ON" without SD or USB Card inserted.
- 2. Under playing mode, short press "Play/pause" button to auto search.
- 3. Press LAST or NEXT button to change another frequency.

Remarks:

- 1. Line-in prior, in the "MUSIC" mode, Line-in function is prior to SD/MMC card or U flash disk.
- 2. All the functions mentioned above can be operated by remote control. When use remote control, please aim at the infrared receiving window.
- 3. Turn the power button to "off" to cut off the power supply while without use.
- 4. While using the audio input function to connect other devices such as MP3/MP4/PC, all functions now could only be controlled on the devices.

How to charge:

- 1. Connect to PC or other charge device for charging by the charge cable, then charging indicator light shines.
- 2. Charge time: 3-8 hours.(Note: Charging time should not exceed 8 hours)