

Frequenztabelle / Frequency Chart Opus 600

02/2011



506-530 MHz

Kanal / Channel	Frequenz / Frequency
0	506.675
1	507.275
2	508.075
3	508.675
4	509.675
5	510.275
6	511.075
7	511.675
8	512.875
9	523.525
A	524.825
B	525.925
C	526.825
D	528.125
E	529.025
F	529.625

Antenna Code	5A
--------------	-----------

598-622 MHz ^{(1) (2)}

UK only

Kanal / Channel	Frequenz / Frequency	Comment
0	606.900	UK CH 38
1	607.550	UK CH 38
2	609.700	UK CH 38
3	610.975	UK CH 38
4	613.375	UK CH 38
5	598.150	UK CH 37
6	599.800	UK CH 37
7	600.825	UK CH 37
8	602.275	UK CH 37
9	603.175	UK CH 37
A	604.375	UK CH 37
B	605.075	UK CH 37
C	617.325	UK CH 39
D	618.850	UK CH 39
E	620.625	UK CH 39
F	621.775	UK CH 39

Antenna Code	6A-B
--------------	-------------

598-622 MHz

USA / NA excl. NTSC CH 37

Kanal / Channel	Frequenz / Frequency
0	598.675
1	599.275
2	600.075
3	600.675
4	601.675
5	602.275
6	603.075
7	603.675
8	604.875
9	615.525
A	616.825
B	617.925
C	618.825
D	620.125
E	621.025
F	621.625

Antenna Code	6A-B
--------------	-------------

668-692 MHz

Kanal / Channel	Frequenz / Frequency
0	669.525
1	670.050
2	671.025
3	671.450
4	674.150
5	674.675
6	675.725
7	676.175
8	683.675
9	684.100
A	685.275
B	685.825
C	688.400
D	688.925
E	690.050
F	690.475

Antenna Code	6C-7A
--------------	--------------

716-734 MHz

Kanal / Channel	Frequenz / Frequency
0	711.525
1	712.050
2	713.025
3	713.450
4	716.150
5	716.675
6	717.725
7	718.175
8	725.675
9	726.100
A	727.275
B	727.825
C	730.400
D	730.925
E	732.050
F	732.475

Antenna Code	7B-C
--------------	-------------

734-758 MHz

Kanal / Channel	Frequenz / Frequency
0	734.675
1	735.275
2	736.075
3	736.675
4	737.675
5	738.275
6	739.075
7	739.675
8	740.875
9	751.525
A	752.825
B	753.925
C	754.825
D	756.125
E	757.025
F	757.625

Antenna Code	7B-C
--------------	-------------

758-782 MHz

Kanal / Channel	Frequenz / Frequency
0	759.525
1	760.050
2	761.025
3	761.450
4	764.150
5	764.675
6	765.725
7	766.175
8	773.675
9	774.100
A	775.275
B	775.825
C	778.400
D	778.925
E	780.050
F	780.475

Antenna Code	7D
--------------	-----------

774-798 MHz

Kanal / Channel	Frequenz / Frequency
0	775.525
1	776.050
2	777.025
3	777.450
4	780.150
5	780.675
6	781.725
7	782.175
8	789.675
9	790.100
A	791.275
B	791.825
C	794.400
D	794.925
E	796.050
F	796.475

Antenna Code	7D
--------------	-----------

790-814 MHz

Kanal / Channel	Frequenz / Frequency
0	791.325
1	792.925
2	793.875
3	797.550
4	799.700
5	800.300
6	804.625
7	810.650
8	812.550
9	813.800
A	790.875
B	791.475
C	793.425
D	796.825
E	804.775
F	806.925

Antenna Code	8A
--------------	-----------

841-865 MHz ⁽³⁾

Kanal / Channel	Frequenz / Frequency	Comment
0	864.075	ISM
1	864.750	ISM
2	854.900	UK shared
3	856.575	UK shared
4	861.750	UK shared
5	842.700	E
6	844.325	E
7	846.750	E
8	848.125	E
9	850.150	E
A	852.825	E
B	859.575	E
C	860.475	E
D	845.075	D
E	850.550	D
F	852.850	D

Antenna Code	8B
--------------	-----------

(1) Receiver channels 0-4, 5-6, A, C-F are fully compatible
Die Kanäle 0-4, 5-6, A, C-F sind vollständig kompatibel

(2) If UK CH 38 is not used, receiver channels 5-F are fully compatible

(3) All channels with same colours are fully compatible
Farbig markierte Kanäle sind vollständig kompatibel