



# FLIGHTCASING THE CONSOLE

If the console is to be regularly moved we recommend that it is installed in a foam-lined flightcase. At all times avoid applying excessive force to any knobs, switches or connectors.

Dimensions for flightcasing the console are shown below:



- GL2200 - 412.....width 548mm
- GL2200 - 416.....width 668mm
- GL2200 - 424.....width 920mm
- GL2200 - 432.....width 1160mm



## DIMENSIONS

	Unpacked				Packed			
	Width	depth	height	weight(kg)	Width	depth	height	weight(kg)
GL2200-412.....	548.....	572.....	155.....	16.....	700.....	750.....	280.....	20.....
GL2200-416.....	668.....	572.....	155.....	18.....	815.....	750.....	280.....	23.....
GL2200-424.....	920.....	572.....	155.....	24.....	1065.....	750.....	280.....	29.....
GL2200-432.....	1160.....	572.....	155.....	30.....	1325.....	750.....	280.....	35.....
RPS9 power supply.....	483.....	140.....	96.....	6.....	540.....	270.....	180.....	8.....