



Action Control

Definition

Action

Noun, *AK-shun*
Macro, Shortcut, QuickKey, Global Preset, Config Recall

Actions

An Action is a collection of Presets for different control groups, plus (if desired) a Salvo. Actions can be used to change a single parameter, or to completely reconfigure the product.

Action Tally

Choose colors for High and Low Tally conditions.

High Tally indicates that all of the controls in all of the enabled groups match the preset. In other words, the conditions of this Action are currently in force.


If any of the controls have been changed, this Action will show Low Tally.

Presets

Controls in BrightEye NXT Compact Routers are organized in Preset Groups. In the NXT 450, for example, Preset Groups include:

- TSGs
- Clean Switches
- PIP-Efx
- High Resolution Encoder
- Low Resolution Encoder
- Unicast A, B
- Multicast Decoder

Users can create multiple presets within each group



Enable ■ High Tally ■ Low Tally

Name:

TSG 1

TSG 2

CS 1

CS 2

PiP-Efx

Hi Res

Lo Res

Uni A

Uni B

Multi

Decode


Salvo

Actions give Users fast, single button recall of any set of parameters.

Construct an Action with as many or as few Presets as desired.

Salvos

A Salvo captures crosspoint selections to any number of destinations



10 Action Keys
Access from
Web or 5835 Panel



Quality Buttons

Full travel, sculpted cap
Legendable
Programmable Color



Ethernet



5835 Router and Action Control Panel

Source/Destination Preview

Manual Crosspoint Control

Use Action Keys to give Operators exactly the control they need. Label them to precisely describe their function.