



# CHAVVET 2

## TABLE OF CONTENTS

1. Before You Begin	. 1
What Is Included	1
Unpacking Instructions	1
Claims	1
Text Conventions	
Symbols	
Disclaimer	
Product at a Glance	
Safety Notes	
2. Introduction	
Product Overview	
Product Dimensions	4
3. Setup	. 5
AC Power	5
Fuse Replacement	5
4. Operation	. 6
Control Priority	6
Control Panel Operation	6
Menu Map	6
DMX Linking	
Starting Address	
DMX Values	6
5. Maintenance and Storage	. 7
Hazer Maintenance	7
Storage	
6. Technical Specifications	. 8
7. Returns	. 9
8. Contact Us	. 10



## **1. BEFORE YOU BEGIN**

#### What Is Included

- Hurricane Haze 1DX
- Power Cord

#### **Unpacking Instructions**

s

Warranty Card

**Quick Reference Guide** 

Carefully unpack the product immediately and check the container to make sure all the parts are in the package and are in good condition.

#### Claims

If the box or the contents (the product and included accessories) appear damaged from shipping, or show signs of mishandling, notify the carrier immediately, not Chauvet. Failure to report damage to the carrier immediately may invalidate your claim. In addition, keep the box and contents for inspection. For other issues, such as missing components or parts, damage not related to shipping, or concealed damage, file a claim with Chauvet within 7 days of delivery.

### **Text Conventions**

CONVENTION	MEANING	
1–512	A range of values	
50/60	A set of values of which only one can be chosen	
Settings	A menu option not to be modified	
<enter></enter>	A key to be pressed on the product's control panel	
ON	A value to be entered or selected	

#### Symbols

SYMBOL	MEANING
<u>A</u>	Electrical warning. Not following these instructions may cause electrical damage to the product, accessories, or the user.
	Critical installation, configuration, or operation information. Not following these instructions may make the product not work, cause damage to the product, or cause harm to the operator.
<b>(i</b> )	Important installation or configuration information. The product may not function correctly if this information is not used.
	Useful information.

### Disclaimer

Chauvet believes that the information contained in this manual is accurate in all respects. However, Chauvet assumes no responsibility and specifically disclaims any and all liability to any party for any loss, damage or disruption caused by any errors or omissions in this document, whether such errors or omissions result from negligence, accident or any other cause. Chauvet reserves the right to revise the content of this document without any obligation to notify any person or company of such revision, however, Chauvet has no obligation to make, and does not commit to make, any such revisions. Download the latest version from <u>www.chauvetdj.com</u>.

The works of authorship contained in this manual, including, but not limited to, all design, text and images are owned by Chauvet.

#### © Copyright 2017 Chauvet & Sons, LLC. All rights reserved.

Electronically published by Chauvet in the United States of America.

CHAUVET, the Chauvet logo, and Hurricane Haze 1DX are registered trademarks or trademarks of Chauvet & Sons LLC (d/b/a Chauvet and Chauvet Lighting) in the United States and other countries. Other company and product names and logos referred to herein may be trademarks of their respective companies.

# CHAVVET 2

## Product at a Glance

Use on Dimmer	$\Diamond$	Auto Programs	$\bigotimes$
Outdoor Use	$\Diamond$	Auto-ranging Power Supply	$\otimes$
Sound-Active	$\Diamond$	Replaceable Fuse	~
DMX	~	User-Serviceable	$\Diamond$
Master/Slave	$\Diamond$		

## Safety Notes

- Not intended for permanent installations.
- Always connect the product to a grounded circuit to avoid the risk of electrocution.
- Always disconnect this product from the power source before cleaning it or replacing the fuse.
- Make sure the power cord is not crimped or damaged.
- Never disconnect the power cord by pulling or tugging on the cord.
- · Make sure there are no flammable materials close to the unit while operating
- Do not touch the output nozzle on this product. It is very hot during operation and it may remain hot for several hours after turning the unit off.
- Do not drink the haze fluid. If you do, call your local emergency service (911 in the US) for help.
- Do not add perfume, alcohol, gasoline, or any other flammables to the haze fluid.
- Depending on the amount of haze generated, all haze machines may set off smoke detectors.
- In certain environments, haze fluid-based machines may leave a slippery residue on floors and surfaces.
- Do not use for space heating purposes.
- Use only CHAUVET DJ water-based haze fluid.
- Drain the tank before transporting the product.
- Always make sure that the voltage of the outlet to which you are connecting the product is within the range stated in the decal or rear panel of the product.
- This product is for indoor use only! To prevent risk of fire or shock, do not expose this product to rain or moisture.
- Always install this product in a location with adequate ventilation, at least 20 in (50 cm) from adjacent surfaces.
- Be sure that no ventilation slots on the unit's housing are blocked.
- Never connect this product to a dimmer or rheostat.
- Make sure to replace the fuse with another of the same type and rating.
- Never carry the product from the power cord or any moving part. Always use the hanging/ mounting bracket.
- The maximum ambient temperature (Ta) is 104 °F (40 °C). Do not operate this product at higher temperatures.
- In the event of a serious operating problem, stop using the product immediately.
- Never try to repair this product. Repairs carried out by unskilled people can lead to damage or malfunction. Please contact the nearest authorized technical assistance center.
- To eliminate unnecessary wear and improve its lifespan, during periods of non-use completely disconnect the product from power via breaker or by unplugging it.




Keep this User Manual for future use. If you sell the product, be sure that the purchaser receives this document.






## 2. INTRODUCTION Product Overview





## **Product Dimensions**





# 3. Setup

### **AC Power**

The Hurricane Haze 1DX has a fixed voltage power supply and it can work with an input voltage of either 120 VAC, 60 Hz or 230 VAC, 50 Hz, depending on the specific model.



To eliminate wear and improve its lifespan, during periods of non-use completely disconnect the product from power via breaker or by unplugging it.


While operating the Hurricane Haze 1DX, make sure there is adequate haze fluid in the machine to prevent pump and heater damage. When the haze fluid level becomes low, simply add more haze fluid to continue using the Hurricane Haze 1DX.



This product may NOT be tilted. This product should be level when on a surface.

#### **Fuse Replacement**

- 1. Wedge the tip of a flat-head screwdriver into the slot of the fuse holder.
- 2. Pry the fuse holder out of the housing.
- 3. Remove the blown fuse from the holder and replace with a fuse of the exact same type and rating.
- 4. Insert the fuse holder back in place and reconnect power.





Disconnect the product from the power outlet before replacing the fuse.



## 4. OPERATION

## **Control Priority**

The Hurricane Haze 1DX operates according to the following priority control levels:

### **Control Panel Operation**

To access the control panel functions, use the four buttons located underneath the display, and the two manual control knobs located to the right of the display. Please refer to the <u>Product Overview</u> to see the button and knob locations on the control panel.

BUTTON	FUNCTION	
<menu></menu>	Press to find an operation mode or to back out of the current menu option	
<up></up>	Press to scroll up the list of options or to find a higher value	
<down></down>	Press to scroll down the list of options or to find a lower value	
<enter></enter>	Press to activate a menu option or a selected value	
<haze volume=""></haze>	Controls the volume of the haze output, from H 1–3	

#### Menu Map

Mode	PROGRAMMING LEVELS	DESCRIPTION
Haze Volume	H (1-3)	Displays current manual haze volume.
DMX Address	d 1-512	Sets the DMX address.

### **DMX** Linking

The Hurricane Haze 1DX can work with a DMX controller. Instructions for connecting and configuring this product for DMX operation are in the User Manual. If you are not familiar with DMX, download the DMX Primer from

www.chauvetdj.com.

### Starting Address

To ensure full access to all channels available in DMX mode, the highest recommended DMX address is 512.

### **DMX Values**

CHANNEL	FUNCTION	VALUE	PERCENT/SETTING
1	Haze Volume	000 ⇔ 010	No function
•		011 ⇔ 255	Haze volume, low to high



Allow the Hurricane Haze 1DX one minute to heat up before continuing.



## 5. MAINTENANCE AND STORAGE

#### Hazer Maintenance

Do not allow the hazer to become clogged. After every 40 hours of continuous operation, use CHAUVET Fog Cleaner Quart (FCQ) through the system to prevent the accumulation of particulate matter in the heating element.

The recommended cleaning procedure is as follows.

- 1. Unplug the product from power.
- 2. Empty all haze fluid from the machine.
- 3. Add cleaning solution to the tank.
- 4. Connect the product to power and allow it to warm up.
- 5. Run the unit in a well-ventilated area until the tank is almost empty. Do not allow the pump to run dry.
- 6. Refill with haze fluid to continue using the hazer. Run the machine briefly to clear any remaining cleaning solution from the pump and heater.



Never operate this product without fluid.

Fog Cleaner Quart (FCQ) was specifically developed by Chauvet to clean your Hurricane Haze 1DX. Make sure you use FCQ regularly, no longer than 90 days between cleanings, to increase the life of your product.

#### Storage

Before storing the hazer, run FCQ through the system as described in the cleaning procedure above; however, only follow steps 1 through 5. **Do not refill the tank with haze fluid if storing the hazer**. Cleaning the system prior to storage will help prevent any particles from condensing inside the pump or heater while not in use.



Test-run your Hurricane Haze 1DX on a monthly basis to achieve the best performance.

### Powering off the unit for transport

Follow these instructions to prevent leaks, and allow the air pump to entirely clear the fluid line and heater of the haze fluid before power off.

# To prevent spills or leaks before, during, or after transport, Chauvet recommends the following steps for your Hurricane Haze 1DX:




- 1. Turn the "Haze Volume" output to off.
- 2. Wait 30-45 seconds.
- 3. When there is no more haze fluid in the output line, turn off the machine by pressing the power switch.



# 6. TECHNICAL SPECIFICATIONS

#### Dimensions and Weight

Dimensions and weight			
LENGTH	WIDTH	Неіднт	WEIGHT
11 in (278 mm)	6 in (150 mm)	9 in (223 mm)	7.2 lb (3.3 kg)
lote: Dimensions in inches rour	nded to the nearest o	lecimal digit.	
Power			
POWER SUPPLY TYPE		NGE	VOLTAGE SELECTION
Fixed	120 VAC, 60 Hz,	or 230 VAC, 50 Hz	Fixed
PARAMETER	120 V	, 60 Hz	230 V, 50 Hz
Consumption	18	8 W	188 W
Operating Current	1.	5 A	0.75 A
Fuse	F 5 A	250 V	F 5 A, 250 V
Power I/O	U.S./Wo	ORLDWIDE	UK/EUROPE
Power input connector	IE	EC	IEC
Power Cord plug	Edisor	า (U.S.)	Local Plug
Operation			
HEAT-UP TIME	ΤΑΝΚ Ο	APACITY	FLUID CONSUMPTION
1 min	0.4 ga	l (1.5 L)	4 ml/min
Fog Output			
Ουτρυτ			
800 cfm			
Thermal			
MAXIMUM EXTERNAL TEMPERATU	IRE COOLING	G SYSTEM	
104 °F (40 °C)	Conv	rection	
DMX			
I/O CONNECTOR	CHANNE	L RANGE	
3-pin XLR		1	
Ordering			
PRODUCT NAME	Ітем	CODE	UPC NUMBER
Hurricane Haze 1DX (120 V)	0907	71413	781462217617
Hurricane Haze 1DX (230 V)	0907	71415	781462217631





#### RETURNS

## RETURNS

In case you need to get support or return a product:

- If you are located in the U.S., contact Chauvet World Headquarters.
- If you are located in the UK or Ireland, contact Chauvet Europe Ltd.
- If you are located in Mexico, contact Chauvet Mexico.
- If you are located in Benelux, contact Chauvet Europe BVBA.
- If you are located in any other country, DO NOT contact Chauvet. Instead, contact your local distributor. See <u>www.chauvetdj.com</u> for distributors outside the U.S., UK, Ireland, Mexico, or Benelux.



If you are located outside the U.S., UK, Ireland, Mexico, or Benelux, contact your distributor of record and follow their instructions on how to return Chauvet products to them. Visit our website <u>www.chauvetdi.com</u> for contact details.

Call the corresponding Chauvet Technical Support office and request a Return Merchandise Authorization (RMA) number before shipping the product. Be prepared to provide the model number, serial number, and a brief description of the cause for the return.

Send the merchandise prepaid, in its original box, and with its original packing and accessories. Chauvet will not issue call tags.

Clearly label the package with the RMA number. Chauvet will refuse any product returned without an RMA number.



# Write the RMA number on a properly affixed label. DO NOT write the RMA number directly on the box.

Before sending the product, clearly write the following information on a piece of paper and place it inside the box:

- Your name
- Your address
- Your phone number
- RMA number
- A brief description of the problem

Be sure to pack the product properly. Any shipping damage resulting from inadequate packaging will be your responsibility. FedEx packing or double-boxing are recommended.



# Chauvet reserves the right to use its own discretion to repair or replace returned product(s).

# CHAVVET 2

## **CONTACT US**

World Headquarters	
General Information	Technical Support
Address: 5200 NW 108th Ave.	Voice: (844) 393-7575
Sunrise, FL 33351	Fax: (954) 756-8015
Voice: (954) 577-4455	Email: <a href="mailto:chauvetlighting.com">chauvetlighting.com</a>
Fax: (954) 929-5560	Website
Toll Free: (800) 762-1084	www.chauvetlighting.com
EUROPE	
General Information	Technical Support
Address: Stokstraat 18	Email: eutech@chauvetlighting.eu
9770 Kruishoutem	Website
Belgium	www.chauvetlighting.eu
Voice: +32 9 388 93 97	
General Information	Technical Support
Address: Unit 1C	Email: uktech@chauvetlighting.com
Brookhill Road Industrial Estate	
Pinxton, Nottingham, UK	Website
NG16 6NT	www.chauvetlighting.co.ul
Voice: +44 (0) 1773 511115	
Fax: +44 (0) 1773 511110	
MEXICO	
	Technical Support
General Information	reennear oupport
General Information Address: Av. de las Partidas, 34-3B, Zona Industrial Lerma (Entrance by Calle 2)	Email: <u>servicio@chauvet.com.m</u>
Address: Av. de las Partidas, 34-3B, Zona	••

Visit the applicable website above to verify our contact details and instructions to request support. Outside the U.S., United Kingdom, Ireland, Mexico or Benelux, contact the dealer of record.