© KOMPLETE KONTROL A-SERIES

Logic/GarageBand

BROWSER CONTROL

Select a Browser field



Scroll Browser tags and **Presets**



Select Browser tag



Load selected Preset in Results list



Clear Browser Filters



Set Preset as Favorite in Results list









Results list Toggle between User Content

Sort by Favorites in

and Factory Content



PLUG-IN CONTROL

Control Instrument and Plug-in parameters





Navigate Plug-in chain



Add Effect Plug-in on empty Plug-in slot











PLUG-IN CONTROL

Bypass selected Plug-in in Plug-in chain




Remove selected Plug-in from Plug-in chain



TRACK CONTROL



Select region











Adjust panorama for selected Track

Solo/unsolo selected Track

Adjust Track volume



EDIT CONTROL

Undo action

Redo action





Quantize to grid value



Toggle automation between Read mode and Touch mode





TRANSPORT CONTROL

Start playback



Restart playback



Punch out while recording



Start recording



Punch in while playback is running



Enable/disable count-in





Stop playback/recording at current position



Relocate playhead position to song start when stopped



Scroll playhead position



Enable/disable loop mode



Move loop by its own length



Enable/disable metronome



Tap tempo



© KOMPLETE KONTROL A-SERIES

Ableton Live

BROWSER CONTROL

Select a Browser field



Scroll Browser tags and Presets



Select Browser tag



Load selected Preset in Results list



Clear Browser Filters



Set Preset as Favorite in Results list



Toggle between User Content and Factory Content

PLUG-IN CONTROL

Control Instrument and

Navigate Plug-in chain

Plug-in parameters





PLUG-IN CONTROL

Bypass selected Plug-in in Plug-in chain



Remove selected Plug-in from Plug-in chain



TRACK CONTROL

Select Track



Switch Instance



Select Clip or Scene Slot in Track



Start/stop selected Clip or Scene



Mute/unmute selected Track



Solo/unsolo selected Track



Adjust panorama for selected Track



EDIT CONTROL

Undo action



Redo action



- UNDO Redo

Quantize to grid value

QUANTIZE Auto

Toggle automation between Read mode and Touch mode





TRANSPORT CONTROL

Start playback



Enable Clip recording



Start Arranger recording together with playback



Oount-In

Scroll playhead position



Stop playback/recording at current position



Relocate playhead position to song start when stopped



Enable/disable loop mode



Enable/disable metronome


Tap tempo




ТЕМРО

Add Effect Plug-in on empty















© KOMPLETE KONTROL A-SERIES

MASCHINE

BROWSER CONTROL

Select a Browser field



Scroll Browser tags and Presets



Select Browser tag



Load selected item in Results list



Clear Browser Filters



Set Preset as Favorite in Results list



Sort by Favorites in Results list



Toggle between User Content and Factory Content



PLUG-IN CONTROL

Control Instrument and Plug-in parameters



Navigate Plug-in chain



Add Effect Plug-in on empty Plug-in slot



Select previous/next Preset



Navigate parameter pages



PLUG-IN CONTROL

Bypass selected Plug-in in Plug-in chain



Remove selected Plug-in from Plug-in chain



IDEAS CONTROL

Select Group



Select Scene



Create new Scene



Select Pattern



Create new Pattern



TRACK CONTROL

Select Group



Select another Sound of that Group





TRANSPORT CONTROL

Start/stop playback



Restart playback at the beginning of the Loop Range



Enable/disable recording



Record with count-in



Stop playback/recording



Enable/disable metronome







Enable/disable loop mode



EDIT CONTROL

Undo action

Adjust tempo



Redo action



Quantize to grid value







Enable/disable Scale engine

Enable/disable automation



Edit Scale engine parameters



Enable/disable Apeggiator



Edit Arpeggiator parameters





