


Worship System Installation



To set up the Worship Communication System:

- Remove all components from the box.
- 2. Connect power to FM +Transmitter, Wireless Access Point, Router, and POE Injector.
- 3. Connect a Cat5e cable from the **Power Over Ethernet (POE) Injector In Port** on the Wireless Access Point to **Data Out Port** of the POE Injector.
- 4. Connect a Cat5e cable from **Data In Port** on the POE Injector to the **LAN 1 Port** on the Router.
- 5. Connect Cat5e cable from **LAN 2 Port** of the Router to the **Ethernet Port** on the FM+.
- 6. Use the provided bracket to attach the Wireless Access Point onto the folding stand.
- 7. Adjust the folding stand to the tallest setting.
- 8. Follow instructions for setting up your FM + system and wireless network.

To listen to WaveCAST Audio on Personal Devices:

- 1. Listeners will need to download the WaveCAST App to their personal device from the Apple App Store or Google Play Store (App is iOS and Android compatible)
- 2. On a personal device with the WaveCAST App installed, join the worship communications system's WaveCAST Wi-fi Network.
- 3. Tap on the WaveCAST Audio Receiver app on the personal device and select a channel to listen to the audio.

If personal devices are not available, distribute FM or WaveCAST Receivers (purchased separately) and select a channel to listen to the audio.

