



MKE 200

Quick Guide

Kurzanleitung

Guide de démarrage rapide

Guida rapida

Instrucciones resumidas

Instruções resumidas

Beknopte gebruiksaanwijzing

Krótką instrukcja obsługi

Snabbguide

Kort vejledning

Pikaohje

Γρήγορος οδηγός

Kısa Kılavuz

Краткая инструкция

快速指南

快速使用指南

クイックガイド

퀵 가이드



Sennheiser electronic GmbH & Co. KG

Am Labor 1, 30900 Wedemark, Germany
www.sennheiser.com

Publ. 01/20, 587400/A01


SENNHEISER

In the box




Setup



1.




2.




3.



Setup




Accessory



Specifications

Transducer principle	pre-polarized condenser
Frequency response	40 to 20,000 Hz
Pick-up pattern	super cardioid
Sensitivity at 1 kHz	- 33 dB V/Pa
Max. SPL at 1 kHz	120 dB SPL
Equivalent noise level	20 dB SPL(A)
Plug-in power required	2 - 10V
Color	black
Connector	3.5 mm jack
Dimensions	69 x 60 x 39 mm
Weight	48 g

Cleaning



Polar pattern and frequency response

