Marshall

CV-H20-HF

Compact Weatherproof Camera Housing with Fan & Heater



User Manual



Marshall

CAUTION

WARNING

To reduce the risks of an electric shock, do not expose inside of this unit to rain or moisture.



Installation on a rainy day may also cause fog around the capsule.



Installation

Installation shall be done by qualified installer only and should conform to all local codes.



Ensuring Strength of Supporting Dome Housing Unit

The unit must be properly and securely mounted to a supporting structure capable of sustaining the weight of the unit. Recommended use of 3/8" stainless screws x three (3).



Prohibit Changes or Modifications of Equipment

You are cautioned that any changes or modifications not expressly approved in these instructions could void your authority to operate this equipment.



Basic Operating Environment Condition

We provide warranty for the products that are installed under normal outdoor -20°C ~ +50°C conditions. We are unable to provide warranty for the products which are installed indoor and exposed to constant high temperature over +50°C and over 90% humidity.

Operating temperature and humidity of camera varies from camera to camera. You are requested to confirm to camera specification with camera manufacturer and housing specification with us in advance.


i.e. -20°C or below, you are requested to use additional heater and +50°C or above you are requested to use two blowers and sunshield.

Fasten wires tightly.


Attention: Keep wires away from the Fan / Heater, and do not disturb Fan/Heater's performance

1. Installation

The unit must be properly and securely mounted to a supporting structure capable of sustaining the weight of unit. We recommend using stainless screws.



2. Camera and Wall Mount Bracket Assembly _




Assembly of the Cables

- 1. AC 24V HEATER
- 2. AC 24V IN
- 3. AC 24V OUT
- 4. DC 12V OUT
- 5. DC 12V FAN
- 6. AC 24V OUT
- 7. AC 24V POWER IN

Marshall

3. Dimensions



4. Safeguards_

- Read Instructions All the safety and operating instructions should be read before operating the unit. 1.
- Retain Instructions The safety and operating instructions should be retained for future reference. 2.
- 3. All warnings on the unit and in the operating instructions should be adhered to.
- Follow Instructions 4.
- 5. Electrical Connections - Only a qualified electrician should make the electrical connections.
- Attachments Do not use attachments not recommended by the product manufacturer as they may cause 6. hazards.
- Cable Runs All cable runs must be within permissible distance. 7.
- Mounting This unit must be properly and securely mounted to a supporting structure capable of sustaining the 8. weight of the unit. Accordingly:
 - a. The installation should be made by gualified installer.
 - The installation should be in compliance with local codes. b.
 - c. Care should be exercised to select suitable hardware to install the unit, taking into account both the composition of the mounting surface and the weight of the unit. Be sure to periodically examine the unit and the supporting structure to make sure that the integrity of the installation is intact. Failure to comply with the foregoing could result in the unit separating from the support structure and falling, with resultant damages or injury to anyone or anything struck by the falling unit.

Warranty _

Marshall Electronics warranties to the first consumer that this device will, under normal use, be free from defects in workmanship and materials, when received in its original container, for a period of two years from the purchase date. This warranty is extended to the first consumer only, and proof of purchase is necessary to honor the warranty. If there is no proof of purchase provided with a warranty claim, Marshall Electronics reserves the right not to honor the warranty set forth above. Therefore, labor and parts may be charged to the consumer. This warranty does not apply to the product exterior or cosmetics. Misuse, abnormal handling, alterations or modifications in design or construction void this warranty. No sales personnel of the seller or any other person is authorized to make any warranties other than those described above, or to extend the duration of any warranties on behalf of Marshall Electronics, beyond the time period described above.

Due to constant effort to improve products and product features, specifications may change without notice.



20608 Madrona Avenue, Torrance, CA 90503 Tel: (800) 800-6608 / (310) 333-0606 • Fax: 310-333-0688

Marshall

www.marshall-usa.com

support@marshall-usa.com