



WS 110
MCM windscreen soft

KK 14
MCM capsule head KK 14 cardioid

SH 150
MCM gooseneck 150 mm

KC 1
MCM cable brace

AC 31
MCM cable mini jack 1.8 m

MCM 100 (works with AC 31 only)
MCM output stage XLR

optional accessories:

- AC 32
MCM cable LEMO 3 pin 1.8 m
- AC 33
MCM cable MicroDot 1.8 m
- AC 34
MCM cable mini XLR 4 pin 1.8 m

▶ bodypack transmitter

MC 1
MCM clip high strings

MC 2
MCM strings clip cello

MC 3
MCM strings clip double bass

MC 4
MCM rib clip double bass

MC 5
MCM universal strap clip

MC 6
MCM universal clamp clip

MC 7
MCM clip drum rims

MC 8
MCM magnetic piano clip

MC 9
MCM clip guitar