

# FP-E50 Tone List/Style List

## Tone List

Category	No.	Tone Name
Ac.Piano	SN001	Concert Piano
Ac.Piano	SN002	Ballad Piano
Ac.Piano	SN003	Bright Piano
Ac.Piano	SN004	Mellow Piano
Ac.Piano	SN005	Piano Performer
Ac.Piano	SN006	Rock Piano
Ac.Piano	SN007	Ragtime Piano
Ac.Piano	PR001	Dynamic JD-Piano
Ac.Piano	PR002	Magical Piano
Ac.Piano	PR003	Piano+Str Layer
Ac.Piano	CM001	Piano 1
Ac.Piano	CM002	Piano 1 w
Ac.Piano	CM003	Piano 1 d
Ac.Piano	CM004	Piano 1 Bright
Ac.Piano	CM005	Piano 1 Amp
Ac.Piano	CM006	Piano 1 w 2
Ac.Piano	CM007	Piano + Str 1
Ac.Piano	CM008	Piano + Str 2
Ac.Piano	CM009	Piano + Choir 1
Ac.Piano	CM010	Piano + Choir 2
Ac.Piano	CM011	Piano + Pad 1
Ac.Piano	CM012	Piano + Pad 2
Ac.Piano	CM013	Healing Piano
Ac.Piano	CM014	Piano Vib
Ac.Piano	CM015	Piano Dly
Ac.Piano	CM016	Piano 2
Ac.Piano	CM017	Piano 2 w
Ac.Piano	CM018	JD Piano
Ac.Piano	CM019	JD Piano w
Pop Piano	PR004	SA Piano
Pop Piano	PR005	Mixture Piano
Pop Piano	CM023	Honky-tonk
Pop Piano	CM024	Honky-tonk w
Pop Piano	CM025	Honky-tonk w 2
E.Grand Piano	PR006	70s E.Grand
E.Grand Piano	CM020	Piano 3
E.Grand Piano	CM021	Piano 3 w
E.Grand Piano	CM022	Piano 3 w 2
E.Piano1	PR008	70s Suitcase
E.Piano1	PR009	Lite Tine EP
E.Piano1	PR010	Lite Pop EP
E.Piano1	PR011	Wurly Vibrato
E.Piano1	PR012	Soft Stage EP
E.Piano1	PR013	Phase EP Mix
E.Piano1	PR017	Vortex EP
E.Piano1	CM026	E.Piano 1
E.Piano1	CM027	E.Piano 1 w
E.Piano1	CM028	E.Piano 1 Trem
E.Piano1	CM029	Detuned EP 1
E.Piano1	CM030	Vintage EP
E.Piano1	CM031	60s E.Piano
E.Piano1	CM032	60s E.Piano w

Category	No.	Tone Name
E.Piano1	CM033	60s E.Piano Trem
E.Piano1	CM034	Tremolo EP
E.Piano1	CM035	Tremolo EP w
E.Piano1	CM036	Curly Wurly
E.Piano1	CM037	Sinus EP
E.Piano2	PR014	More Tine EP
E.Piano2	PR015	80s FM EP
E.Piano2	PR016	MK-80 Bright EP
E.Piano2	PR018	Mixture EP
E.Piano2	CM038	E.Piano 2
E.Piano2	CM039	E.Piano 2 w
E.Piano2	CM040	Detuned EP 2
E.Piano2	CM041	St.FM EP
E.Piano2	CM042	St.FM EP w
E.Piano2	CM043	EP Legend
E.Piano2	CM044	EP Legend w
E.Piano2	CM045	EP Phaser 1
E.Piano2	CM046	EP Phaser 2
E.Piano2	CM047	EP Phaser 3
E.Piano2	CM048	EP Belle
Solo Strings	PR031	String Solo
Solo Strings	CM307	Violin
Solo Strings	CM308	Slow Violin
Solo Strings	CM309	Violin w
Solo Strings	CM310	Violin Amp
Solo Strings	CM311	Viola
Solo Strings	CM312	Viola Amp
Solo Strings	CM313	Cello
Solo Strings	CM314	Cello Amp
Solo Strings	CM315	Contrabass
Solo Strings	CM316	Contrabass Amp
Solo Strings	CM750	Fiddle
Solo Strings	CM751	Fiddle w
Ensemble Strings	PR023	Rich Strings
Ensemble Strings	PR024	Full Strings
Ensemble Strings	PR025	Decay Strings
Ensemble Strings	PR026	Strings/Pizz
Ensemble Strings	PR027	CharacterStrings
Ensemble Strings	PR030	Chamber Strings
Ensemble Strings	CM317	Tremolo Str
Ensemble Strings	CM318	Pizzicato Str
Ensemble Strings	CM319	Pizzicato Str w
Ensemble Strings	CM320	Pizz
Ensemble Strings	CM321	Pops Seq 4
Ensemble Strings	CM322	Pops Seq 4 w
Ensemble Strings	CM331	Strings
Ensemble Strings	CM332	Orchestra
Ensemble Strings	CM333	60s Strings
Ensemble Strings	CM334	Small Strings
Ensemble Strings	CM335	Hybrid Strings
Ensemble Strings	CM336	Small Str Stacc
Ensemble Strings	CM337	Strings Stacc

## FP-E50 Tone List/Style List

Category	No.	Tone Name
Ensemble Strings	CM338	Strings Stacc w
Ensemble Strings	CM339	Strings Amp
Ensemble Strings	CM340	Slow Strings
Ensemble Strings	CM341	Mood Strings
E.Organ	PR032	B.Organ
E.Organ	PR033	Dist B.Organ
E.Organ	PR034	Perc Jazz Organ
E.Organ	PR035	Soft Jazz Organ
E.Organ	PR036	Whisper Organ
E.Organ	PR037	Gospel Organ
E.Organ	PR038	Full Draw
E.Organ	PR039	Lower Organ
E.Organ	PR040	Light Organ
E.Organ	CM105	Organ 1
E.Organ	CM106	Organ 1 Rtry
E.Organ	CM107	Tremolo Organ
E.Organ	CM108	Tremolo Organ w
E.Organ	CM109	60s Organ
E.Organ	CM110	60s Organ Cho
E.Organ	CM111	Organ 2
E.Organ	CM112	Organ 2 Rtry
E.Organ	CM113	Ana Organ 1
E.Organ	CM114	Ana Organ 1 Rtry
E.Organ	CM115	Ana Organ 2
E.Organ	CM116	Ana Organ 3
E.Organ	CM117	Ana Organ 4
E.Organ	CM118	Perc.Organ 1
E.Organ	CM119	Perc.Organ 1Rtry
E.Organ	CM120	Chorus Organ
E.Organ	CM121	Perc.Organ 2
E.Organ	CM122	E.Organ 1
E.Organ	CM123	E.Organ 1 w
E.Organ	CM124	E.Organ 1 Rtry
E.Organ	CM125	E.Organ 2
E.Organ	CM126	E.Organ 2 Trem
E.Organ	CM127	E.Organ 3
E.Organ	CM128	Mad Organ
E.Organ	CM129	Rock Organ 1
E.Organ	CM130	Rock Organ Amp
E.Organ	CM131	Rock Organ 2
E.Organ	CM132	Rock Organ w
E.Organ	CM133	Full Organ Rtry
E.Organ	CM134	Full Organ OD
E.Organ	CM135	Rotary Organ
E.Organ	CM136	Rotary Organ Cho
Pipe Organ	PR041	Soft Pipe Organ
Pipe Organ	PR042	Positive Organ
Pipe Organ	PR043	Classical Organ
Pipe Organ	PR044	Grand Organ
Pipe Organ	CM137	Church Organ 1
Pipe Organ	CM138	Church Organ 1 w
Pipe Organ	CM139	Church Organ 2
Pipe Organ	CM140	Church Organ 2 w
Pipe Organ	CM141	Church Organ 3
Pipe Organ	CM142	Church Organ 3 w
Pipe Organ	CM145	Puff Organ
Pipe Organ	CM146	Puff Organ w
Reed Organ	CM143	Reed Organ

Category	No.	Tone Name
Reed Organ	CM144	Reed Organ w
Synth Pad/Str	PR054	Legend Pad
Synth Pad/Str	PR055	Voice Heaven
Synth Pad/Str	PR056	New Jupiter
Synth Pad/Str	PR057	Chord Of Canada
Synth Pad/Str	PR058	Super SynPad
Synth Pad/Str	PR059	JP8 Slow Strings
Synth Pad/Str	PR060	Soft Warm Pad
Synth Pad/Str	PR061	Air Pad
Synth Pad/Str	PR062	Boreal Pad
Synth Pad/Str	CM342	Syn Strings 1
Synth Pad/Str	CM343	Syn Strings 1 w
Synth Pad/Str	CM344	Syn Strings 3
Synth Pad/Str	CM345	Syn Strings 3 w
Synth Pad/Str	CM346	Syn Strings 2
Synth Pad/Str	CM347	Syn Strings 2 w
Synth Pad/Str	CM586	Warm Pad
Synth Pad/Str	CM587	Warm Pad Dly
Synth Pad/Str	CM588	Sine Pad
Synth Pad/Str	CM589	JP8 Strings 1
Synth Pad/Str	CM590	Soft Pad
Synth Pad/Str	CM591	JP8 Strings 2
Synth Pad/Str	CM592	JUNO Str
Synth Pad/Str	CM593	JUNO Str w
Synth Pad/Str	CM594	Oct Strings
Synth Pad/Str	CM595	Brite Str
Synth Pad/Str	CM596	Voyager
Synth Pad/Str	CM597	Voyager w
Synth Pad/Str	CM598	JP8 Strings 3
Synth Pad/Str	CM599	PWM Str 1
Synth Pad/Str	CM600	PWM Str 2
Synth Pad/Str	CM601	Fading Str
Synth Pad/Str	CM602	Vintage Str
Synth Pad/Str	CM603	Vintage Str Amp
Synth Pad/Str	CM604	Analog Str
Synth Pad/Str	CM618	Space Voice
Synth Pad/Str	CM619	Space Voice Dly
Synth Pad/Str	CM620	Itopia
Synth Pad/Str	CM621	Itopia Dly
Synth Pad/Str	CM622	JP8 Hollow 1
Synth Pad/Str	CM623	JP8 Hollow 2
Synth Pad/Str	CM624	Hollow Pad
Synth Pad/Str	CM625	Strobe Pad
Synth Pad/Str	CM626	Heaven Pad
Synth Pad/Str	CM627	Itopia w
Synth Pad/Str	CM628	Bowed Glass
Synth Pad/Str	CM629	Bowed Glass Dly
Synth Pad/Str	CM630	Brite Wine
Synth Pad/Str	CM631	Bell Pad
Synth Pad/Str	CM632	Wine Pad
Synth Pad/Str	CM633	Fine Wine Pad
Synth Pad/Str	CM634	Organ Pad
Synth Pad/Str	CM635	Brite Wine w
Synth Pad/Str	CM636	Metallic Pad
Synth Pad/Str	CM637	Metallic Pad Dly
Synth Pad/Str	CM638	Chime Pad
Synth Pad/Str	CM639	Halo Pad
Synth Pad/Str	CM640	Halo Pad w

## FP-E50 Tone List/Style List

Category	No.	Tone Name
Synth Pad/Str	CM641	Halo Pad Dly
Synth Pad/Str	CM642	Sweep Pad 1
Synth Pad/Str	CM643	Sweep Pad 1 Dly
Synth Pad/Str	CM644	Trns Sweep Pad w
Synth Pad/Str	CM645	Trns Sweep Pad
Synth Pad/Str	CM646	Giant Sweep
Synth Pad/Str	CM647	Sweep Pad 2 w
Synth Pad/Str	CM648	Sweep Pad 2
Synth Pad/Str	CM649	Reso Pad
Synth Pad/Str	CM650	Ice Rain
Synth Pad/Str	CM651	Ice Rain Dly
Synth Pad/Str	CM652	Healing Pad
Synth Pad/Str	CM653	Healing Pad w
Synth Pad/Str	CM654	Soundtrack
Synth Pad/Str	CM655	Soundtrack Dly
Synth Pad/Str	CM656	Random Str
Synth Pad/Str	CM657	Fairy's Song
Synth Pad/Str	CM732	Star Theme
Synth Pad/Str	CM733	Star Theme Dly
Synth Bellpad	PR051	D50 Fantasia
Synth Bellpad	PR052	D50 Stac Heaven
Synth Bellpad	PR053	D50 Stack Pad
Synth Bellpad	PR072	Dreaming Harp
Synth Bellpad	CM571	Fantasia
Synth Bellpad	CM572	D50 Bell
Synth Bellpad	CM573	D50 Bell w
Synth Bellpad	CM574	Fantasy 1
Synth Bellpad	CM575	D50 Fantasy
Synth Bellpad	CM576	D50 Fantasy w
Synth Bellpad	CM577	Soft Bell
Synth Bellpad	CM578	Dreambell
Synth Bellpad	CM579	Dreambell w
Synth Bellpad	CM580	Dreaming Box
Synth Bellpad	CM581	Dreaming Box w
Synth Bellpad	CM582	Fantasy 2
Synth Bellpad	CM583	Fantasy 2 w
Synth Bellpad	CM584	Stacc Heaven
Synth Bellpad	CM585	Stacc Heaven w
Synth PolyKey	PR063	Trance-Touch
Synth PolyKey	CM605	Polysynth
Synth PolyKey	CM606	Polysynth Dly
Synth PolyKey	CM607	Digitalless
Synth PolyKey	CM608	Analog Saws
Synth PolyKey	CM609	Super Saws
Synth PolyKey	CM610	Super Saws Atk
Synth PolyKey	CM611	Dance Saws 2
Synth PolyKey	CM612	S-Saw Pad
Synth PolyKey	CM613	S-Saw Pad w
Synth PolyKey	CM614	DOC Stack
Synth PolyKey	CM615	Trance Saws
Synth PolyKey	CM616	Trance Saws w
Synth PolyKey	CM617	PWM Pad
Synth PolyKey	CM701	Atmosphere
Synth PolyKey	CM702	Atmosphere Cho
Synth PolyKey	CM703	Analog Dream
Synth PolyKey	CM704	Analog Dream Atk
Synth PolyKey	CM705	Choir Key
Synth PolyKey	CM706	Choir Key Echo

Category	No.	Tone Name
Synth PolyKey	CM707	Brass Key
Synth PolyKey	CM708	Harpsi Key
Synth PolyKey	CM709	Harpsi Key w
Synth PolyKey	CM710	Brightness
Synth PolyKey	CM711	Brightness Cho
Synth PolyKey	CM712	Vox Key
Synth PolyKey	CM713	Air Key 1
Synth PolyKey	CM714	Air Key 2
Synth PolyKey	CM715	Digital Key
Synth PolyKey	CM716	Dreamheaven 1
Synth PolyKey	CM717	Dreamheaven 2
Harpsichord	PR007	Elegant Harpsi
Harpsichord	CM049	Harpsichord
Harpsichord	CM050	Coupled Harpsi.
Harpsichord	CM051	Harpsichord w
Harpsichord	CM052	Harpsichord w 2
Harpsichord	CM053	Harpsichord o
Clav	PR021	Natural Clav
Clav	PR022	Clav Phase
Clav	CM054	Clav 1
Clav	CM055	Clav 1 w
Clav	CM056	Clav 1 Phaser
Clav	CM057	Clav 2
Clav	CM058	Clav 2 w
Clav	CM059	Pulse Clav 1
Clav	CM060	Pulse Clav 1 w
Clav	CM061	Pulse Clav 1 w 2
Clav	CM062	Pulse Clav 2
Clav	CM063	Biting Clav
Clav	CM064	Analog Clav
Celesta	CM065	Celesta
Celesta	CM066	Celesta w
Accordion	PR045	Nostalgic Accord
Accordion	PR046	Bright Musette
Accordion	CM147	Accordion 1
Accordion	CM148	Accordion 1 w
Accordion	CM149	Accordion 2
Accordion	CM150	Accordion It
Accordion	CM151	Vodkakordion
Accordion	CM154	Bandoneon
Accordion	CM155	Bandoneon w
Harmonica	PR047	Blues Reed
Harmonica	CM152	Harmonica
Harmonica	CM153	Harmonica w
Bell	CM097	Tubular Bells
Bell	CM098	Tubular Bells w
Bell	CM099	Church Bell
Bell	CM100	Church Bell w
Bell	CM101	Carillon
Bell	CM102	Carillon w
Bell	CM754	Tinkle Bell
Bell	CM755	Tinkle Bell w
Bell	CM756	Agogo
Bell	CM757	Agogo w
Mallet	PR019	Fine Marimba
Mallet	PR020	Fat SynMallet
Mallet	CM067	Glockenspiel
Mallet	CM068	Glockenspiel w

## FP-E50 Tone List/Style List

Category	No.	Tone Name
Mallet	CM073	Vibraphone
Mallet	CM074	Vibraphone w
Mallet	CM075	Vibraphone w 2
Mallet	CM076	Vibraphone Trem
Mallet	CM077	Jazz Vib
Mallet	CM078	Jazz Vib w
Mallet	CM079	Marimba
Mallet	CM080	Marimba w
Mallet	CM081	Marimba w 2
Mallet	CM082	Bs Marimba 1
Mallet	CM083	Bs Marimba 2
Mallet	CM084	Xylophone 1
Mallet	CM085	Xylophone 1 w
Mallet	CM086	Xylophone 1 w 2
Mallet	CM087	Xylophone 2
Mallet	CM088	Kalimbells
Mallet	CM089	Pops Seq 2
Mallet	CM090	Pops Seq 2 w
Mallet	CM091	Pops Seq 2 Atk
Mallet	CM092	Pops Seq 3
Mallet	CM093	Pops Seq 3 Atk
Mallet	CM094	Ethno Keys
Mallet	CM095	Ethno Keys Dly
Mallet	CM096	Toy Box
Mallet	CM103	Santur
Mallet	CM104	Santur w
Mallet	CM325	Yang Qin
Mallet	CM326	Yang Qin w
Ac.Guitar	PR065	Bright Atk Nylon
Ac.Guitar	PR066	Steel Guitar/Hrm
Ac.Guitar	PR067	Comp'd Steel/Sld
Ac.Guitar	CM156	Nylon Gtr 1
Ac.Guitar	CM157	Ukulele
Ac.Guitar	CM158	Nylon Gtr o
Ac.Guitar	CM159	Nylon Gtr 2
Ac.Guitar	CM160	Nylon Gtr w
Ac.Guitar	CM161	Nylon Gtr Amp
Ac.Guitar	CM162	Steel-str.Gtr
Ac.Guitar	CM163	Steel-str.Gtr w
Ac.Guitar	CM164	Steel-str.GtrAmp
Ac.Guitar	CM165	Steel-str.GtrDst
Ac.Guitar	CM166	Stl Gtr Trem
Ac.Guitar	CM167	12-str.Guitar
Ac.Guitar	CM168	12-str.Guitar w
Ac.Guitar	CM169	Mandolin
Ac.Guitar	CM170	Steel+Body
Ac.Guitar	CM171	Reso Guitar w
Ac.Guitar	CM172	Reso Guitar Amp
E.Guitar	PR068	JC ST Guitar
E.Guitar	PR069	Nice Oct Guitar
E.Guitar	CM173	Jazz Guitar
E.Guitar	CM174	Jazz Guitar w
E.Guitar	CM175	Jazz Guitar Atk
E.Guitar	CM176	Hawaiian Gtr
E.Guitar	CM177	Clean Guitar
E.Guitar	CM178	Clean Guitar w
E.Guitar	CM179	Clean Gtr Chorus
E.Guitar	CM180	Chorus Gtr 1

Category	No.	Tone Name
E.Guitar	CM181	Soft Clean Gtr
E.Guitar	CM182	Soft Clean Gtr w
E.Guitar	CM183	Soft Clean Atk
E.Guitar	CM184	Soft Dist Gtr
E.Guitar	CM185	Mid Tone Gtr
E.Guitar	CM186	Mid Tone Gtr Dly
E.Guitar	CM187	Mid Tone GtrTrem
E.Guitar	CM188	Muted Guitar
E.Guitar	CM189	Muted Guitar w
E.Guitar	CM190	Muted Guitar Atk
E.Guitar	CM191	Muted Guitar Dst
E.Guitar	CM192	Funk Guitar 1
E.Guitar	CM193	Funk Guitar 2
E.Guitar	CM194	Chorus Gtr 2
E.Guitar	CM195	Chorus Gtr2 Echo
E.Guitar	CM196	Chorus Gtr2 Step
Dist.Guitar	PR070	Searing Lead Gtr
Dist.Guitar	CM197	Overdrive Gtr 1
Dist.Guitar	CM198	Overdrive Gtr 2
Dist.Guitar	CM199	Overdrive Chorus
Dist.Guitar	CM200	Guitar Pinch
Dist.Guitar	CM201	Distortion Gtr 1
Dist.Guitar	CM202	Distortion Gtr 2
Dist.Guitar	CM203	Distortion Gtr 3
Dist.Guitar	CM204	Distortion Gtr 4
Dist.Guitar	CM205	Distortion Gtr 5
Dist.Guitar	CM206	Gtr Feedback 1
Dist.Guitar	CM207	Dist.Rhy Gtr
Dist.Guitar	CM208	Dist.Rhy Gtr Amp
Dist.Guitar	CM209	Gtr Harmonics
Dist.Guitar	CM210	Gtr Harmonics w
Dist.Guitar	CM211	Gtr Feedback 2
Dist.Guitar	CM212	Gtr Feedback 2 w
Ac.Bass	PR073	Mild Ac.Bass
Ac.Bass	PR075	Bass+Cymbal
Ac.Bass	CM213	Acoustic Bass
Ac.Bass	CM214	Acoustic Bass w
E.Bass	PR074	Comp'd JzBs /Slp
E.Bass	CM215	Fingered Bass
E.Bass	CM216	FingeredBass Atk
E.Bass	CM217	Finger Slap
E.Bass	CM218	Finger Slap Atk
E.Bass	CM219	Picked Bass
E.Bass	CM220	Picked Bass Atk1
E.Bass	CM221	Picked Bass Atk2
E.Bass	CM222	Fretless Bass
E.Bass	CM223	Fretless Bass w
E.Bass	CM224	Slap Bass 1
E.Bass	CM225	Slap Bass 1 Atk
E.Bass	CM226	Slap Bass 2
E.Bass	CM227	Slap Bass 2 Amp
Synth Bass	PR076	Syn Bass Hook
Synth Bass	PR077	Fat Synth Bass
Synth Bass	CM228	Synth Bass 1
Synth Bass	CM229	Synth Bass 1 w
Synth Bass	CM230	Warm Syn Bass
Synth Bass	CM231	Synth Bass 3
Synth Bass	CM232	Clav.Bass

## FP-E50 Tone List/Style List

Category	No.	Tone Name
Synth Bass	CM233	Clav.Bass w
Synth Bass	CM234	Hammer Bass
Synth Bass	CM235	Hammer Bass Atk
Synth Bass	CM236	Juno Sqr Bass
Synth Bass	CM237	MKS-50 Bass
Synth Bass	CM238	R&B Bass 1
Synth Bass	CM239	R&B Bass 1 w
Synth Bass	CM240	R&B Bass 1 Atk
Synth Bass	CM241	MC202 Bass
Synth Bass	CM242	Compu Bass 1
Synth Bass	CM243	Compu Bass 1 Atk
Synth Bass	CM244	Muffled Bass
Synth Bass	CM245	R&B Bass 2
Synth Bass	CM246	R&B Bass 2 w
Synth Bass	CM247	R&B Bass 2 Atk
Synth Bass	CM248	R&B Bass 3
Synth Bass	CM249	R&B Bass 3 w
Synth Bass	CM250	R&B Bass 4
Synth Bass	CM251	MG Bass 1
Synth Bass	CM252	MG Bass 1 w
Synth Bass	CM253	MG Bass 1 Atk
Synth Bass	CM254	MG Bass 2
Synth Bass	CM255	MG Bass 2 w
Synth Bass	CM256	MG Bass 3
Synth Bass	CM257	MG Bass 4
Synth Bass	CM258	MG Bass 5
Synth Bass	CM259	New Reso Bs 1
Synth Bass	CM260	New Reso Bs 1 w
Synth Bass	CM261	New Reso Bs 2
Synth Bass	CM262	Reso Bass 1
Synth Bass	CM263	Rubber Bass
Synth Bass	CM264	Reso Bass 2
Synth Bass	CM265	Reso Bass 3
Synth Bass	CM266	Reso Bass 4
Synth Bass	CM267	Acid Bass 1
Synth Bass	CM268	Acid Bass 2
Synth Bass	CM269	Acid Bass 3
Synth Bass	CM270	TB Bass 1
Synth Bass	CM271	TB Bass 2
Synth Bass	CM272	Flat Bass
Synth Bass	CM273	Sub Bass
Synth Bass	CM274	Sub Bass Atk
Synth Bass	CM275	Garage Bass
Synth Bass	CM276	Synth Bass 2
Synth Bass	CM277	Synth Bass 5
Synth Bass	CM278	Synth Bass 4
Synth Bass	CM279	Synth Bass 6
Synth Bass	CM280	Rubber Syn Bs
Synth Bass	CM281	Attack Pulse
Synth Bass	CM282	Seq Bass
Synth Bass	CM283	106 Bass 1
Synth Bass	CM284	106 Bass 2
Synth Bass	CM285	Juno Bass
Synth Bass	CM286	Filter Env Bs
Synth Bass	CM287	Unison Syn Bs
Synth Bass	CM288	Unison Syn Bs w
Synth Bass	CM289	Alpha Bass
Synth Bass	CM290	Alpha Bass w

Category	No.	Tone Name
Synth Bass	CM291	Detune Bs
Synth Bass	CM292	Detune Bs w
Synth Bass	CM293	Ramp Bass
Synth Bass	CM294	Ramp Bass Atk
Synth Bass	CM295	Pedal Bass 1
Synth Bass	CM296	Pedal Bass 2
Synth Bass	CM297	Compu Bass 2
Synth Bass	CM298	Sqr Bass w
Synth Bass	CM299	Modular Bs 1
Synth Bass	CM300	Modular Bs 2
Synth Bass	CM301	Synth Bass 7
Synth Bass	CM302	Pedal Bass 3
Synth Bass	CM303	Monster Bass 1
Synth Bass	CM304	Monster Bass 2
Synth Bass	CM305	Growl Bass 1
Synth Bass	CM306	Growl Bass 2
Plucked/Stroke	PR071	Harpiness
Plucked/Stroke	CM069	Music Box
Plucked/Stroke	CM070	Music Box w
Plucked/Stroke	CM071	Pops Seq 1
Plucked/Stroke	CM072	Pops Seq 1 Atk
Plucked/Stroke	CM323	Harp
Plucked/Stroke	CM324	Aerial Harp
Plucked/Stroke	CM734	Sitar 1
Plucked/Stroke	CM735	Sitar 1 w
Plucked/Stroke	CM736	Sitar 2
Plucked/Stroke	CM737	Sitar 2 w
Plucked/Stroke	CM738	Banjo
Plucked/Stroke	CM739	Banjo w
Plucked/Stroke	CM740	Shamisen
Plucked/Stroke	CM741	Shamisen w
Plucked/Stroke	CM742	Koto
Plucked/Stroke	CM743	Koto w
Plucked/Stroke	CM744	Taisho Koto
Plucked/Stroke	CM745	Taisho Koto w
Plucked/Stroke	CM746	Kalimba
Plucked/Stroke	CM747	Kalimba w
Orchestral	PR028	Orch Str Brass
Orchestral	PR029	Orchestra Brass
Solo Brass	PR078	Clear Trumpet
Solo Brass	PR079	HM Mute Tp
Solo Brass	PR080	Soft Trombone
Solo Brass	CM382	Trumpet
Solo Brass	CM383	Trumpet Echo
Solo Brass	CM384	Dark Trumpet
Solo Brass	CM385	Dark Trumpet w
Solo Brass	CM386	Romantic Tp
Solo Brass	CM387	Romantic Tp Echo
Solo Brass	CM388	Trombone 1
Solo Brass	CM389	Trombone 1 w
Solo Brass	CM390	Trombone 2
Solo Brass	CM391	Bright Tb
Solo Brass	CM392	Bright Tb w
Solo Brass	CM393	Tuba
Solo Brass	CM394	Tuba Atk
Solo Brass	CM395	Mute Trumpet 1
Solo Brass	CM396	Mute Trumpet 1 w
Solo Brass	CM397	Mute Trumpet 2

## FP-E50 Tone List/Style List

Category	No.	Tone Name
Solo Brass	CM398	Mute Trumpet 2 w
Solo Brass	CM401	French Horn 2
Solo Brass	CM402	FrenchHorn2 Echo
Ensemble Brass	PR081	Light Brass Sect
Ensemble Brass	PR082	Pop Brass Sect
Ensemble Brass	PR083	Soft Brass Sect
Ensemble Brass	PR084	Swelling Horns
Ensemble Brass	CM399	French Horn 1
Ensemble Brass	CM400	French Horn 1 w
Ensemble Brass	CM403	Brass 1
Ensemble Brass	CM404	Brass 1 w
Ensemble Brass	CM405	Brass 2
Ensemble Brass	CM406	Brass Atk
Ensemble Brass	CM407	Brass Atk w
Wind	PR089	Clarinet Vib
Wind	CM452	Oboe
Wind	CM453	Oboe w
Wind	CM454	English Horn
Wind	CM455	Bassoon
Wind	CM456	Clarinet
Wind	CM748	Bagpipe
Wind	CM749	Bagpipe w
Wind	CM752	Shanai
Wind	CM753	Shanai w
Flute	PR088	Flute Principal
Flute	CM457	Piccolo
Flute	CM458	Flute
Flute	CM459	Flute w
Flute	CM460	Flute Echo
Flute	CM462	Pan Flute
Flute	CM463	Pan Flute w
Flute	CM464	Pan Flute Dly
Flute	CM465	Bottle Blow
Flute	CM466	Bottle Blow w
Flute	CM467	Bottle Blow Dly
Flute	CM468	Shakuhachi
Flute	CM469	Shakuhachi w
Flute	CM470	Shakuhachi Amp
Sax	PR085	Dynamic Sop Sax
Sax	PR086	Dynamic Alto Sax
Sax	PR087	Dynamic Tnr Sax
Sax	CM444	Soprano Sax
Sax	CM445	Soprano Sax Amp
Sax	CM446	Alto Sax
Sax	CM447	Alto Sax Amp
Sax	CM448	Tenor Sax
Sax	CM449	Tenor Sax Amp
Sax	CM450	Baritone Sax
Sax	CM451	Baritone Sax Atk
Recorder	PR090	Twin Air Lead
Recorder	CM461	Recorder
Recorder	CM471	Whistle
Recorder	CM472	Whistle Dly
Recorder	CM473	Ocarina
Recorder	CM474	Ocarina Echo
Vox/Choir	PR048	Choir Aahs
Vox/Choir	PR049	Angels Voices
Vox/Choir	CM348	Choir 1

Category	No.	Tone Name
Vox/Choir	CM349	Choir 2
Vox/Choir	CM350	Choir 3
Vox/Choir	CM352	Humming
Vox/Choir	CM353	Synth Voice
Vox/Choir	CM354	Analog Voice 1
Vox/Choir	CM355	Analog Voice 2
Vox/Choir	CM358	Aerial Choir
Vox/Choir	CM359	Aerial Choir w
Vox/Choir	CM360	DJ Soft Vox
Vox/Choir	CM361	DJ Soft Vox w
Vox/Choir	CM362	Syn Vox
Vox/Choir	CM363	Syn Vox w
Vox/Choir	CM364	VP-330 Choir
Vox/Choir	CM365	VP-330 Choir w
Vox/Choir	CM366	FXM Voice
Vox/Choir	CM367	Cat Voice
Vox/Choir	CM368	Cat Voice Wah
Scat	PR050	Jazz Scat Layer
Scat	CM351	Voice Doos
Scat	CM356	Jazz Scat
Scat	CM357	Jazz Scat w
Synth Lead	PR091	Dual SuperSaw Ld
Synth Lead	PR092	Tight Saw Lead
Synth Lead	PR093	Wind Syn Lead
Synth Lead	PR094	Clear Dual Saws
Synth Lead	PR095	Windy Synth
Synth Lead	PR096	Dual Sqr Lead
Synth Lead	PR097	Blow Lead
Synth Lead	CM475	Square Lead 1
Synth Lead	CM476	Square Lead 2
Synth Lead	CM477	Sine Lead
Synth Lead	CM478	Porta Sine Lead
Synth Lead	CM479	Pure Lead Dly
Synth Lead	CM480	Dist Flt TB 2
Synth Lead	CM481	Dist Flt TB 1
Synth Lead	CM482	DistFlt TB 1 Dly
Synth Lead	CM483	80's Tech Lead
Synth Lead	CM484	Sqr Buzz Lead
Synth Lead	CM485	Ana Vox Lead
Synth Lead	CM486	CS Lead
Synth Lead	CM487	Classic GR
Synth Lead	CM488	Therasaw
Synth Lead	CM489	Bell Lead
Synth Lead	CM490	Bell Lead w
Synth Lead	CM491	Simple Tri
Synth Lead	CM492	Spooky Lead
Synth Lead	CM493	Soft Lead
Synth Lead	CM494	Sqr Lead 1
Synth Lead	CM495	Sqr Lead 2
Synth Lead	CM496	Sqr Lead 3
Synth Lead	CM497	Saw Lead 1
Synth Lead	CM498	Saw Lead 1 w
Synth Lead	CM499	Saw Lead 2
Synth Lead	CM500	Doctor Solo
Synth Lead	CM501	Natural Lead
Synth Lead	CM502	Sequenced Saw
Synth Lead	CM503	Sequenced Saw w
Synth Lead	CM504	Ah Super Saw

## FP-E50 Tone List/Style List

Category	No.	Tone Name
Synth Lead	CM505	Ah SuperSaw Dst1
Synth Lead	CM506	Ah SuperSaw Dst2
Synth Lead	CM507	Porta Super Saw
Synth Lead	CM508	S-Saw Stac Ld
Synth Lead	CM509	S-Saw Stac Ld w
Synth Lead	CM510	Tekno Lead 1 Atk
Synth Lead	CM511	Tekno Lead 1 Bit
Synth Lead	CM512	OSC-Sync Ld 1
Synth Lead	CM513	Wave Shape Ld
Synth Lead	CM514	Wave Shape Ld w
Synth Lead	CM515	Legato Tkno
Synth Lead	CM516	Legato Tkno w
Synth Lead	CM517	Tekno Lead 2
Synth Lead	CM518	Buzz Lead
Synth Lead	CM519	Buzz Lead Dist
Synth Lead	CM520	Saw Buzz Ld
Synth Lead	CM521	Saw Buzz Ld w
Synth Lead	CM522	Saw Lead 3
Synth Lead	CM523	Saw Lead 4
Synth Lead	CM524	Classic Lead
Synth Lead	CM525	Ramp Lead
Synth Lead	CM526	Saw Lead 5
Synth Lead	CM527	Jupiter Lead 1
Synth Lead	CM528	JupiterLead1 Atk
Synth Lead	CM529	Jupiter Lead 2
Synth Lead	CM530	Saw Lead 6
Synth Lead	CM531	On Air
Synth Lead	CM532	Saw Lead 7
Synth Lead	CM533	Saw Lead 8
Synth Lead	CM534	Warm Lead
Synth Lead	CM535	Saw Lead 9
Synth Lead	CM536	Saw Lead 10
Synth Lead	CM537	EQ Lead
Synth Lead	CM538	Saw Lead 11
Synth Lead	CM539	Saw Lead 12
Synth Lead	CM540	Waspy Lead
Synth Lead	CM541	Octa Square
Synth Lead	CM542	Octa Juice
Synth Lead	CM543	Fat GR Lead
Synth Lead	CM544	Octa Saw
Synth Lead	CM545	Juicy Lead
Synth Lead	CM546	OSC-Sync Ld 2
Synth Lead	CM547	OSC-Sync Ld 3
Synth Lead	CM548	Syn.Calliope
Synth Lead	CM549	Syn.Calliope w
Synth Lead	CM550	Syn.Calliope Dly
Synth Lead	CM551	Chiffer Lead
Synth Lead	CM552	Chiffer Lead w
Synth Lead	CM553	Charang
Synth Lead	CM554	Wire Lead
Synth Lead	CM555	Wire Lead Cho
Synth Lead	CM556	Solo Vox
Synth Lead	CM557	Solo Vox w
Synth Lead	CM558	Solo Vox Cho
Synth Lead	CM559	OB Lead
Synth Lead	CM560	5th Saw Lead
Synth Lead	CM561	5th Saw Lead Dly
Synth Lead	CM562	Housechord

Category	No.	Tone Name
Synth Lead	CM563	Ju-D Fifths
Synth Lead	CM564	Major 7
Synth Lead	CM565	Dance Saws 1
Synth Lead	CM566	Bass+Lead
Synth Lead	CM567	Bass+Lead w
Synth Lead	CM568	Delayed Lead
Synth Lead	CM569	Delayed Lead w
Synth Lead	CM570	Delayed Lead Cho
Synth Brass	PR064	Trad Syn Brass
Synth Brass	CM408	Synth Brass 1
Synth Brass	CM409	Synth Brass 3
Synth Brass	CM410	Synth Brass 3 w
Synth Brass	CM411	Analog Brass 1
Synth Brass	CM412	Analog Brass 1 w
Synth Brass	CM413	Analog Brs 1 w 2
Synth Brass	CM414	Jump Brass
Synth Brass	CM415	Jump Brass Amp
Synth Brass	CM416	JP8 Brass 1
Synth Brass	CM417	JP8 Brass 1 w
Synth Brass	CM418	Syn Brass
Synth Brass	CM419	Syn Brass w
Synth Brass	CM420	JP8 Brass 2
Synth Brass	CM421	80's Brass 1
Synth Brass	CM422	80's Brass 2
Synth Brass	CM423	Synth Brass 2
Synth Brass	CM424	Synth Brass 4
Synth Brass	CM425	Analog Brass 2
Synth Brass	CM426	Analog Brass 3
Synth Brass	CM427	Analog Brass 3 w
Synth Brass	CM428	Reso Brass
Synth Brass	CM429	Poly Brass
Synth Brass	CM430	Soft Brass
Synth Brass	CM431	FM Brass
Synth Brass	CM432	Warm Syn Brass
Synth Brass	CM433	Dual Saw Brass
Synth Brass	CM434	Soft Syn Brass
Synth Brass	CM435	Vintage Brass
Synth Brass	CM436	Vintage Brass w
Synth Brass	CM437	Euro Express
Synth Brass	CM438	Mix Brass
Synth Brass	CM439	Brite Syn Brass
Synth Brass	CM440	JP8 Brass 3
Synth Brass	CM441	Synth Brass 5
Synth Brass	CM442	80's Brass 3
Synth Brass	CM443	80's Brass 4
Synth FX	CM718	Goblins
Synth FX	CM719	Cosmic Drops
Synth FX	CM720	Echo Drops
Synth FX	CM721	Echo Drops Cho
Synth FX	CM722	Echo Bell
Synth FX	CM723	Echo Bell Cho
Synth FX	CM724	Echo Bell Dly
Synth FX	CM725	Echo Pan
Synth FX	CM726	Echo Pan Cho
Synth FX	CM727	LFO Saw
Synth FX	CM728	Keep Going
Synth FX	CM729	Electrostar
Synth FX	CM730	Scream at me

## FP-E50 Tone List/Style List

Category	No.	Tone Name
Synth FX	CM731	Scream at me w
Synth Seq/Pop	PR098	Flip Pluck
Synth Seq/Pop	PR099	Thin PW Pluck
Synth Seq/Pop	PR100	Octave Pluck
Synth Seq/Pop	CM658	Crystal
Synth Seq/Pop	CM659	Crystal w
Synth Seq/Pop	CM660	Synth Mallet
Synth Seq/Pop	CM661	Synth Mallet w
Synth Seq/Pop	CM662	Synth Mallet Dly
Synth Seq/Pop	CM663	Sine Mallet
Synth Seq/Pop	CM664	Seq Saw
Synth Seq/Pop	CM665	Seq 1
Synth Seq/Pop	CM666	Seq 1 w
Synth Seq/Pop	CM667	Seq 2
Synth Seq/Pop	CM668	Seq 3
Synth Seq/Pop	CM669	Seq Sqr 1
Synth Seq/Pop	CM670	Seq Sqr 1 Atk
Synth Seq/Pop	CM671	Seq Sqr 2
Synth Seq/Pop	CM672	Seq Tri
Synth Seq/Pop	CM673	Seq Tri w
Synth Seq/Pop	CM674	Synth Seq 1
Synth Seq/Pop	CM675	Synth Seq 2
Synth Seq/Pop	CM676	Synth Seq 3
Synth Seq/Pop	CM677	Analog Seq
Synth Seq/Pop	CM678	Detune Seq
Synth Seq/Pop	CM679	Uni-G
Synth Seq/Pop	CM680	Seq 4
Synth Seq/Pop	CM681	Analog Poly
Synth Seq/Pop	CM682	Analog Poly Dly
Synth Seq/Pop	CM683	Saws Key
Synth Seq/Pop	CM684	Vintage Key
Synth Seq/Pop	CM685	Analog Key w
Synth Seq/Pop	CM686	Analog Key
Synth Seq/Pop	CM687	Bell 1
Synth Seq/Pop	CM688	Bell 1 Atk
Synth Seq/Pop	CM689	Bell 2
Synth Seq/Pop	CM690	Bell 3
Synth Seq/Pop	CM691	Bell 3 Amp
Synth Seq/Pop	CM692	MusicBox Key w
Synth Seq/Pop	CM693	MusicBox Key
Synth Seq/Pop	CM694	Music Bells
Synth Seq/Pop	CM695	Music Bells w
Synth Seq/Pop	CM696	Dreaming Bell
Synth Seq/Pop	CM697	FingBell Key
Synth Seq/Pop	CM698	FingBell Key w
Synth Seq/Pop	CM699	Org Bell
Synth Seq/Pop	CM700	Pluck Synth
Hit	CM369	Orchestra Hit
Hit	CM370	Bass Hit
Hit	CM371	Bass Hit w
Hit	CM372	6th Hit
Hit	CM373	6th Hit w
Hit	CM374	Euro Hit
Hit	CM375	Euro Hit w
Hit	CM376	Cheezy Movie
Hit	CM377	Cheezy Movie w
Hit	CM378	Tao Hit
Hit	CM379	Tao Hit w

Category	No.	Tone Name
Hit	CM380	House Hit
Hit	CM381	House Hit w
Sound FX	CM774	Gtr Fret Noise
Sound FX	CM775	Gtr Cut Noise
Sound FX	CM776	Bass String Slap
Sound FX	CM777	Breath Noise
Sound FX	CM778	Flute Key Click
Sound FX	CM779	Seashore
Sound FX	CM780	Rain
Sound FX	CM781	Thunder
Sound FX	CM782	Thunder Dly
Sound FX	CM783	Wind
Sound FX	CM784	Stream
Sound FX	CM785	Stream w
Sound FX	CM786	Bubble 1
Sound FX	CM787	Bubble 1 w
Sound FX	CM788	Bubble 2
Sound FX	CM789	FX Scene
Sound FX	CM790	Tuned Winds
Sound FX	CM791	Tuned Winds w
Sound FX	CM792	Sand Noise
Sound FX	CM793	Bird 1
Sound FX	CM794	Dog
Sound FX	CM795	Horse Gallop
Sound FX	CM796	Bird 2
Sound FX	CM797	Telephone 1
Sound FX	CM798	Telephone 2
Sound FX	CM799	Door Creaking
Sound FX	CM800	Door
Sound FX	CM801	Scratch
Sound FX	CM802	Wind Chimes
Sound FX	CM803	FX Close
Sound FX	CM804	Helicopter
Sound FX	CM805	Car Engine
Sound FX	CM806	Car Stop
Sound FX	CM807	Car Pass
Sound FX	CM808	Car Crash
Sound FX	CM809	Siren
Sound FX	CM810	Train
Sound FX	CM811	Jetplane
Sound FX	CM812	Jetplane Dly
Sound FX	CM813	Starship
Sound FX	CM814	Starship Dly
Sound FX	CM815	Burst Noise
Sound FX	CM816	Passing By
Sound FX	CM817	FX Pass 1
Sound FX	CM818	FX Pass 2
Sound FX	CM819	FX Pass 3
Sound FX	CM820	FX Pass 4
Sound FX	CM821	FX Pass 5
Sound FX	CM822	Poly Sweep Nz
Sound FX	CM823	Reso Sweep Dn
Sound FX	CM824	Applause
Sound FX	CM825	Applause w
Sound FX	CM826	Laughing
Sound FX	CM827	Screaming
Sound FX	CM828	Punch
Sound FX	CM829	Heart Beat

Category	No.	Tone Name
Sound FX	CM830	Footsteps
Sound FX	CM831	Gun Shot
Sound FX	CM832	Machine Gun
Sound FX	CM833	Laser Gun
Sound FX	CM834	Explosion
Sound FX	CM835	Explosion Dly
Sound FX	CM836	Explosion Dist
Sound FX	CM837	FX Hit w
Drums	CD001	Standard Kit
Drums	CD002	Room Kit
Drums	CD003	Power Kit
Drums	CD004	Electric Kit
Drums	CD005	Analog Kit
Drums	CD006	Jazz Kit
Drums	CD007	Brush Kit
Drums	CD008	Orchestra Kit
Drums	CD009	SFX Kit
Drums	CD010	Standard Kit w
Drums	CD011	Room Kit w
Drums	CD012	Power Kit w
Drums	CD013	Electric Kit w
Drums	CD014	Analog Kit w
Drums	CD015	Jazz Kit w
Drums	CD016	Brush Kit w
Drums	CD017	Orchestra Kit w
Drums	CD018	SFX Kit w
Drums	CD019	Studio Kit
Drums	CD020	Studio Kit w
Drums	CD021	Pop Kit
Drums	CD022	Pop Kit w
Drums	CD023	Pop Kit Lim
Drums	CD024	90's Kit
Drums	CD025	90's Kit comp
Drums	CD026	90's Kit w comp
Drums	CD027	80's Kit
Drums	CD028	80's Kit comp
Drums	CD029	80's Kit w comp
Drums	CD030	EDM Kit
Drums	CD031	EDM Kit w
Drums	CD032	EDM Kit Lim
Drums	CD033	Drum&Bass Kit
Drums	CD034	Drum&Bass Kit
Drums	CD035	Drum&Bass KitLim
Drums	CD036	Techno Kit
Drums	CD037	Techno Kit w
Drums	CD038	House Kit
Drums	CD039	House Kit w
Drums	CD040	HipHop Kit
Drums	CD041	HipHop Kit comp
Drums	CD042	HipHop Kit w cmp
Drums	CD043	R&B Kit
Drums	CD044	R&B Kit w
Drums	CD045	TR-909
Drums	CD046	TR-909 comp
Drums	CD047	TR-909 w comp
Drums	CD048	TR-808
Drums	CD049	TR-808 comp
Drums	CD050	TR-808 w comp

Category	No.	Tone Name
Drums	CD051	TR-707&727
Drums	CD052	TR-707&727 comp
Drums	CD053	TR-707&727 w cmp
Drums	CD054	CR-78
Drums	CD055	CR-78 comp
Drums	CD056	CR-78 w comp
Drums	CD057	TR-606
Drums	CD058	TR-606 comp
Drums	CD059	TR-606 w comp
Drums	CD060	TR-626
Drums	CD061	TR-626 comp
Drums	CD062	TR-626 w comp
Drums	CD063	Kick
Drums	CD064	Kick w
Drums	CD065	Snare
Drums	CD066	Snare w
Drums	CD067	RimStickClapTom
Drums	CD068	RimStickClapTm w
Drums	CD069	HiHat Cymbal
Drums	CD070	HiHat Cymbal w
Drums	CD071	Other Perc 1
Drums	CD072	Other Perc 1 w
Drums	CD073	Other Perc 2
Drums	CD074	Other Perc 2 w
Percussion	CM327	Timpani
Percussion	CM328	Timpani w
Percussion	CM329	Timpani Low
Percussion	CM330	Timpani Atk
Percussion	CM758	Steel Drums
Percussion	CM759	Steel Drums w
Percussion	CM760	Steel Drums w 2
Percussion	CM761	Woodblock
Percussion	CM762	Castanets
Percussion	CM763	Taiko
Percussion	CM764	Concert BD
Percussion	CM765	Concert BD w
Percussion	CM766	Melodic Tom 1
Percussion	CM767	Melodic Tom 2
Percussion	CM768	Synth Drum
Percussion	CM769	Synth Drum w
Percussion	CM770	TR-808 Tom
Percussion	CM771	Elec.Perc.
Percussion	CM772	Reverse Cym
Percussion	CM773	Reverse Cym Atk

Symbol	Explanation
SN	SuperNATURAL Piano
PR	Preset
CM	Common
CD	Common Drums

## Style List

Category	No	Style Name	Tempo	Beat
Pop	PR001	Disco Pop	115	4/4
Pop	PR002	Synth Pop	170	4/4
Pop	PR003	Cynical 8 Beat	135	4/4
Pop	PR004	Light Guitar Pop	90	4/4
Pop	PR005	Teen Pop	160	4/4
Pop	PR006	Kids Pop	112	4/4
Pop	PR007	Alternative Pop	120	4/4
Pop	PR008	Bouncing Pop	91	4/4
Pop	PR009	Acoustic 8 Beat	67	4/4
Pop	PR010	Easy 8 Beat	88	4/4
Pop	PR011	Electro Pop	102	4/4
Pop	PR012	J-Pop 16 Beat	98	4/4
Pop	PR013	J-Electro Pop	130	4/4
Pop	PR014	Funk K-Pop	120	4/4
Pop	PR015	Space Pop	101	4/4
Pop	PR016	Orchestra Pop	82	4/4
Pop	PR017	Pop R&B	94	4/4
Pop	PR018	Shuffle Pop Soul	118	4/4
Pop	PR019	Country Pop	94	4/4
Pop	PR020	City Pop	105	4/4
Pop	PR021	Chill Out	108	4/4
Pop	PR022	Neo Soul	86	4/4
Pop	PB001	Steppin' Pop	168	4/4
Pop	PB002	Cosmic Pop	105	4/4
Pop	PB003	Star Pop	125	4/4
Pop	PB004	Digital Pop	174	4/4
Pop	PB005	Dark Pop	126	4/4
Pop	PB006	Lucky Hop	160	4/4
Pop	PB007	Dream Hop	92	4/4
Pop	PB008	City Shuffle	71	4/4
Pop	PB009	Synth Hip Pop	156	4/4
Pop	PB010	Pop Rock	140	4/4
Pop	PB011	Piano Pop	98	4/4
Pop	PB012	MOR Pop	80	4/4
Pop	PB013	Melodic Pop	102	4/4
Ballad	PR023	Folk Rock Ballad	96	4/4
Ballad	PR024	Power Ballad	120	4/4
Ballad	PR025	Piano Ballad	65	4/4
Ballad	PR026	Cinematic Ballad	61	4/4
Ballad	PR027	Brit Pop Ballad	68	4/4
Ballad	PR028	Electro Ballad	84	4/4
Ballad	PR029	Slow Jazz Ballad	66	4/4
Ballad	PR030	Broadway Ballad	94	4/4
Ballad	PR031	6/8 Folk Pop	60	6/8
Ballad	PR032	6/8 Slow Ballad	31	6/8
Ballad	PR033	Folk Ballad	76	4/4
Ballad	PR034	Latin Romance	117	4/4
Ballad	PR035	Latin Pop Ballad	91	4/4
Ballad	PR036	Electro Chill	84	4/4
Ballad	PB021	Romance Ballad	63	4/4
Ballad	PB022	Forever Ballad	82	4/4
Ballad	PB023	Timeless Ballad	71	4/4
Ballad	PB024	Jazzy Pop	88	4/4
Ballad	PB025	Lush Ballad	62	4/4
Ballad	PB026	Brazilian Ballad	59	4/4

Category	No	Style Name	Tempo	Beat
Ballad	PB027	Hometown	64	4/4
Dance	PR037	Nu Disco	118	4/4
Dance	PR038	Electro Disco	116	4/4
Dance	PR039	Dance Pop	100	4/4
Dance	PR040	Happy Disco	113	4/4
Dance	PR041	Electro Dance	98	4/4
Dance	PR042	Modern Funk	111	4/4
Dance	PR043	Disco House	128	4/4
Dance	PR044	Deep House	120	4/4
Dance	PR045	Funk Pop	120	4/4
Dance	PR046	Euro House	130	4/4
Dance	PR047	UK House	124	4/4
Dance	PR048	Carib Dance	106	4/4
Dance	PR049	Tropical Pop	96	4/4
Dance	PR050	Electro Swing	125	4/4
Dance	PR051	Electro Latin Pop	122	4/4
Dance	PB014	Candy Trance	132	4/4
Dance	PB015	Neo Euro Beat	128	4/4
Dance	PB016	East Dance	128	4/4
Dance	PB017	Dreamy Dance	126	4/4
Dance	PB018	Synth Dancer	132	4/4
Dance	PB019	Crossover House	122	4/4
Dance	PB020	Chill House	112	4/4
Latin	PR052	Reggaeton 1	94	4/4
Latin	PR053	Reggaeton 2	84	4/4
Latin	PR054	Reggaeton 3	190	4/4
Latin	PR055	Reggaeton 4	89	4/4
Latin	PR056	Classic Reggae	121	4/4
Latin	PR057	Pop Samba	102	4/4
Latin	PR058	Salsa	189	4/4
Latin	PR059	Moody Latin Pop	132	4/4
Latin	PR060	Electro Cumbia	182	4/4
Latin	PR061	Cumbia Romantica	172	4/4
Latin	PR062	Xote	85	4/4
Latin	PR063	Fast Bossa Nova	84	2/4
Latin	PR064	Medium Bossa	64	2/4
Latin	PR065	Mariachi	126	4/4
Latin	PR066	Classic Banda	108	4/4
Latin	PB028	Cuban Smile	116	4/4
Latin	PB029	Electro Ska	98	4/4
Latin	PB030	Latin Electro	98	4/4
Latin	PB031	Tango	130	4/4
Latin	PB032	Mambo-billy	88	4/4
R&B	PR067	Diva Groove	150	4/4
R&B	PR068	Tasty R&B	146	4/4
R&B	PR069	Kawaii Hip Hop	91	4/4
R&B	PR070	Dramatic Hip Hop	65	4/4
R&B	PR071	Acid Jazz	92	4/4
R&B	PR072	Boogie Funk	112	4/4
R&B	PR073	Hip Folk	68	4/4
R&B	PR074	Philly Pop	96	4/4
R&B	PB033	Power Pop	92	4/4
R&B	PB034	Early Pop Soul	132	4/4
R&B	PB035	80's Simple Beat	106	4/4
R&B	PB036	Dark R&B	70	4/4

## FP-E50 Tone List/Style List

Category	No	Style Name	Tempo	Beat
Rock	PR075	UK Alternative	130	4/4
Rock	PR076	Indie Rock	132	4/4
Rock	PR077	Funky Rock	140	4/4
Rock	PR078	US Punk Rock	174	4/4
Rock	PR079	Shuffle Rock	170	4/4
Rock	PR080	Alternative Rock	84	4/4
Rock	PR081	Teledrama Rock	170	4/4
Rock	PB037	Power Synth Rock	123	4/4
Rock	PB038	Sweetheart Rock	120	4/4
Rock	PB039	Country Band	128	4/4
Traditional	PR082	Country Dance	80	2/4
Traditional	PR083	Easy Country	100	4/4
Traditional	PR084	Up-Tempo Waltz	176	3/4
Traditional	PR085	Dixieland	94	4/4
Traditional	PR086	Boogie Woogie	173	4/4
Traditional	PR087	Small March	118	4/4
Traditional	PR088	Soundtrack	110	4/4
Traditional	PB040	Country Ballad	70	4/4
Traditional	PB041	Jazz Manouche	138	4/4
Traditional	PB042	Lyric Gospel	104	4/4
Traditional	PB043	12/8 Rockin' Gospel	50	12/8
Traditional	PB044	Country Boogie	130	4/4
Traditional	PB045	Spanish Festa	116	4/4
Traditional	PB046	Pop Waltz	76	3/4
Contemporary	PR089	Latin Fusion	120	4/4
Contemporary	PR090	Hip Jazz	75	4/4
Contemporary	PR091	Nu Electro Jazz	92	4/4
Contemporary	PR092	Urban Jazz	153	4/4
Contemporary	PR093	Jazz Funk	88	4/4
Contemporary	PR094	Psychedelic Jazz	136	4/4
Contemporary	PR095	Contemporary Waltz	160	3/4
Contemporary	PB047	Cruise Fusion	113	4/4
Contemporary	PB048	Pop Fusion	105	4/4
Contemporary	PB049	Pier Breeze	88	4/4
Contemporary	PB050	Chilly Night	120	4/4
Contemporary	PB051	Neo Latin Pop	115	4/4
Jazz	PR096	Kansas Jazz	136	4/4
Jazz	PR097	Holiday Jazz	118	4/4
Jazz	PR098	Bigband Jazz	145	4/4
Jazz	PR099	Medium Brush	120	4/4
Jazz	PR100	Medium Fast Jazz	190	4/4
Jazz	PR101	Jazz Samba	108	4/4
Jazz	PR102	5/4 Jazz	170	5/4
Jazz	PR103	Fast Swing	204	4/4
Jazz	PR104	Brush Swing	130	4/4
Jazz	PR105	Jazz Ballad	60	4/4
Jazz	PR106	Jazz Waltz Fast	165	3/4
Jazz	PR107	Jazz Waltz Medium	116	3/4
Jazz	PB052	Slow Bigband Jazz	76	4/4
Jazz	PB053	Cabaret Jazz	158	4/4
Jazz	PB054	Jazz Waltz Ballad	72	3/4
World	PB055	Epic Sky	116	4/4
World	PB056	East Bank Pop	112	4/4
World	PB057	Mumbai Dance	103	4/4
World	PB058	Village Pop	107	4/4
World	PB059	Asian Sunset	95	4/4
World	PB060	Bolly Charm	132	4/4
Piano Style	PB061	Pf Ballad 1	68	4/4

Category	No	Style Name	Tempo	Beat
Piano Style	PB062	Pf Ballad 2	68	4/4
Piano Style	PB063	Pf 6/8 Ballad	66	6/8
Piano Style	PB064	Pf Pop Classic	106	6/4
Piano Style	PB065	Pf Light Rock	148	4/4
Piano Style	PB066	Pf MOR Rock	124	4/4
Piano Style	PB067	Pf Blue Boogie	132	4/4
Piano Style	PB068	Pf Soft Pop	70	4/4
Piano Style	PB069	Pf Boogaloo	105	4/4
Piano Style	PB070	Pf Waltz Cocktail	152	3/4