## **Installation Instructions**

## Models M5CX / M4F M4F710 / M4F725 M5CX710 / M5CX725

#### **BATHROOM / SHOWER / KITCHEN SPEAKERS**



M5CX



M4F



Established 1978

#### **OWI Incorporated**

17141 Kingsview Ave. Carson CA 90746 USA Tel. 310-515-1900 www.owi-inc.com

Technical Support: 310-515-1900






# **B**•**S**•**K** Speakers

#### Bathroom • Shower • Kitchen



## Loudspeaker Mounting Instructions

Models: M5CX / M4F Weatherized Loudspeakers



#### **Parts List**


- A Speaker Housing
- B Speaker Grill
- C #8 X 1 1/8" Stainless Steel Screw

Optional items (not included with speaker)



#8-10 plastic anchor (4)









Tools required: Drill motor, skill saw or equivalent, ½" drill bit, 3/32" drill bit, Phillips screw driver, pencil or pen.

Remove all parts from package and compare to parts list.

Using the template printed on back of box that speaker came in, determine best mounting location. Mark speaker hole diameter and screw mounting hole locations using a pencil or pen. Using the ½" drill bit, drill a hole inside the area marked for the speaker. This will allow you to insert the blade of the skill saw to cut hole. Once completed, drill the (4) mounting screw holes using the 3/32" drill bit. (You may want to use a plastic anchor which will require a larger hole to accept the plastic anchor.)



Check fit of speaker into hole that you have cut in the wall. It is important that the speaker rest flush against surface. Run your speaker wiring and connect to back of speaker accordingly. (If the speaker is being used in a vibration type atmosphere (boat) put a little silicone on the wiring connector to insure they do not loosen.) For a watertight seal, we recommend using waterproof silicone around the speaker hole and screw holes. This will prevent any moisture from entering beyond the speaker.



Both the M5CX and M4F weatherized speakers are held in place by (4) #8 stainless steel screws. Locate the speaker grill covers and put a small amount of silicone in screw holes. This will seal the screws. Using the Philips screw driver, install the (4) #8 screws carefully aligning speaker in wall. (It is not necessary to seal the speaker grill cover - only the screw holes.)

#### OWI INCORPORATED

17141 KINGSVIEW AVE. CARSON CA 90746 Tel. 310-515-1900

www.owi-inc.com info@owi-inc.com



01/13/16



# M4F-RIK MOUNTING KIT INSTRUCTIONS

(NEW CONSTRUCTION KIT FOR THE M4F SHOWER SPEAKER)

17141 Kingsview Ave, Carson CA 90746 / Tel. 310-515-1900 / info@owi-inc.com /WWW.OWi-inc.com








Mounting frame


Cup

Each mounting kit consists of:

- A one mounting frame
- B one cup



frame A on the wall using screw or staple.





Place cup B on the hole of the mounting frame A.



Place drywall, cement or material on front side.


Do not cover cup.







Install the BSK Speaker.






## **M5CXRIK**

(M5TB + M5CX-CUP)

# MOUNTING KIT INSTRUCTIONS (NEW CONSTRUCTION KIT FOR THE M5CX SPEAKERS)


17141 Kingsview Ave, Carson CA 90746 / Tel. 310-515-1900 / info@owi-inc.com /WWW.OWi-inc.com




Each mounting kit M5CXRIK is consists of:

- 1) One each cup model M5CX-CUP
- 2) One each mounting frame model M5TB














# OWI BSK SPEAKER DRY WALL/SHEET ROCK **CEILING ASSEMBLY** Backcan **Enclosure** www.owi-inc.com **OWI Incorporated** 17141 Kingsview Avenue Carson, CA 90746-1207 USA Tel: 310.515.1900 **Tile Bridge** M5TB CEILING (Dry Wall or Sheet Rock) PLASTIC CUP M5CX-CUP 1. Place the plastic cup in hole as shown. 2. Remove cup after the Dry Wall or Sheet Rock is set. 3. Install the speaker. Transformer if needed.

**BSK SPEAKER** 

#### OWI SPEAKER SYSTEM LIMITED WARRANTY REGISTRATION

(Save this portion for your records)

- 1. Your OWI Speaker System has been thoroughly tested and inspected at the factory. It is warranted for 5 years from date of purchase. IT IS THE OWNERS' RESPONSIBILITY TO ESTABLISH THE DATE OF PURCHASE BY ACCEPTABLE EVIDENCE AT TIME SERVICE IS SOUGHT.
- 2. WHAT WE WILL PAY FOR AND WHAT YOU MUST PAY FOR:
  OWI INC. will repair or replace unit(s) covered by this warranty, without charge to the consumer for labor or materials. YOU ARE
  RESPONSIBLE FOR ANY INSTALLATION OR REMOVAL CHARGES AND FOR ANY INITIAL SHIPPING CHARGES, if
  the unit(s) must be shipped for warranty service. However, we will pay the return shipping charges to any destination within the
  U.S.A. if the repairs are covered by the warranty.
- 3. Any unit which in the judgement of OWI Inc. is defective or develops defects under normal use will be replaced or repaired without cost within the warranty period.
- 4. This warranty will be considered void if unit has been dropped, misused, abused or altered in any manner, overdriven with excessive amplification exceeding manufacturer's specifications, improperly serviced or accidental damage. Warranty will also be voided if speakers are used in "SAUNAS".
- 5. OWI Inc. shall have no liability whatsoever for consequential damage. The sole responsibility of OWI Inc. under this warranty shall be limited to the repair of the product or replacement thereof is the sole discretion of OWI Inc.
- 6. IMPORTANT: This warranty is void unless the attached card is completed and mailed to OWI Inc. within 10 days following the date of purchase.

Units for warranty repair must be sent to OWI Inc., or to the dealer where purchased, postage prepaid.

OWI INCORPORATED 17141 Kingsview Ave Carson, CA 90746 Tel: 310-515-190 Fax: 310-515-1606		Date Purchased:  Model Number:  Serial Number: (Cut here)
PLACE STAMP HERE	OWI INCORPORATED. 17141 KINGSVIEW AVE. CARSON, CA 90746	LIMITED WARRANTY REGISTRATION CARD  Wodel No.  Wodel Name  Lot number  Date of Purchase: Month  Address  City  Cit

Page 6 of 6 Filename: BSK MANUAL