



## Important safety and mounting instructions

**EN**

- Read and follow the safety and mounting instructions, keep these instructions easily accessible and always include them when passing the LH 65 on to third parties.
- Also read and follow the installation instructions contained in the operating manual of the mounted studio monitor.
- When mounting, follow the local, national and international regulations and standards.

### Intended use

The LH 65 is a table stand for decoupling a studio monitor from the installation surface and for optimum orientation. The LH 65 is only suitable for Neumann 2-way monitors and must only be used in dry and clean interiors such as studios and on desktops.

The LH 65 must not be used for other purposes or in other environments. In case of any damage or any deviation from the safety and mounting instructions, immediately dismount the studio monitor from the LH 65.

### Required qualifications

Have the studio monitor mounted to the LH 65 by a specialist. Due to his/her technical training, know-how and experience as well as knowledge of relevant provisions, regulations and standards, the specialist must be able to assess assigned tasks, recognize potential hazards and ensure appropriate safety measures.

### Safety instructions for mounting

- Only mount one Neumann 2-way studio monitor to the LH 65 and proceed as described in this mounting manual.
- Always use the enclosed original accessories.
- Check every 3 months if all screws are properly tightened and if the LH 65, the studio monitor and the surface on which the LH 65 is placed are in proper condition.

### Safety instructions for installation

- Do not install the LH 65 in locations where it is exposed to externally generated vibrations.
- Place the LH 65 with the mounted studio monitor on a horizontal and slip-resistant surface that can carry at least the weight of the LH 65 with the mounted monitor. Make sure that the LH 65 with the mounted monitor cannot tip over or drop down, even if the power or audio cables are pulled.
- Do not place the LH 65 on delicate surfaces, as these might get stained when they come into contact with the self-adhesive feet.

## Package contents

- |  |  |
|--|--|
| <b>A:</b> 1 x bracket for height adjustment      | <b>H:</b> 2 x M8x12 screws                 |
| <b>B:</b> 1 x bracket for inclination adjustment | <b>I:</b> 5 x self-adhesive feet           |
| <b>C:</b> 1 x base plate                         | <b>J:</b> 1 x M8x20 countersunk screw      |
| <b>D:</b> 1 x tube                               | <b>K:</b> 1 x height bracket locking clamp |
| <b>E:</b> 2 x plastic washers                    | <b>L:</b> 1 x cover cap                    |
| <b>F:</b> 2 x metal washers                      | <b>M:</b> 1 x 4 mm Allen key               |
| <b>G:</b> 6 x M6x12 screws                       | <b>N:</b> 1 x 5 mm Allen key               |

## Specifications

Weight without packaging	3.6 kg
Dimensions (assembled)	507 x 185 x 285 mm (H x W x D)
Max. Load	10 kg

## Guarantee

For the current terms and conditions of the product guarantee please visit [www.neumann.com](http://www.neumann.com).



# LH 65 Mounting manual



