

LH 64

Mounting manual

Important safety and mounting instructions



- Read and follow the safety and mounting instructions, keep these instructions easily accessible and always include them when passing the LH 64 on to third parties.
- Also read and follow the installation instructions contained in the operating manual of the studio monitor to be mounted.
- When mounting, follow the local, national and international regulations and standards.

Intended use

The LH 64 is a holder for fastening a studio monitor to a wall. The LH 64 is only suitable for 2-way studio monitors and must only be used indoors in clean, dry rooms such as studios.

To properly mount the LH 64 together with a studio monitor, you need additional products from the OmniMount or VESA Mount range of accessories, as well as additional fastening elements for mounting on a wall.

The LH 64 must not be used for other purposes or in other environments. In case of any damage or any deviation from the safety and mounting instructions, immediately dismount the studio monitor and the LH 64.

Required qualifications

Only skilled personnel may attach the LH 64 to the studio monitor and mount it on the wall. Due to his/her technical training, know-how and experience as well as knowledge of relevant provisions, regulations and standards, the specialist must be able to assess assigned tasks, recognize potential hazards and ensure appropriate safety measures.

Safety instructions for mounting

- Mount only one LH 64 to one studio monitor, as described in these assembly instructions.
- Place something soft underneath the studio monitor so that you do not scratch its surface while performing the work.
- Always use the enclosed original accessories.
- The wall must be able to support the weight of the studio monitor and all accessories used, such that no parts will fall even if someone pulls hard on the power or audio cables. When calculating the weight, also take into account the additional leverage.
- When mounting the LH 64 on the wall, use products from the Omni-Mount or VESA Mount range of accessories, as well as fastening elements (not included with delivery) that are sufficiently dimensioned to ensure that the entire weight is held securely.
- Mount the LH 64 together with the attached studio monitor and mounting accessories on a flat, non-slip wall.
- Tighten all screws by hand. Once you have finished mounting and aligning the studio monitor, ensure that all screws are firmly tightened.
- Do not use the LH 64 in environments that are exposed to external vibrations.
- Every 3 months, check that all screws are properly tightened and that the LH 64, the studio monitor, the mounting accessories and the wall on which the LH 64 is mounted are in the proper condition.

Delivery includes

A: 1 x adapter plate

B: 2 x Allen screws, M8x12 C: 2 x Allen screws, M6x12

D: 1 x Allen key, 4 mm

E: 1 x Allen key, 5 mm

Specifications

Veight 0.2 kg

Dimensions when assembled 16 x 98 x 98 mm (H x W x D)

Max. load 10 kg

Warranty

For the current terms and conditions of the warranty, please visit www.neumann.com.



LH 64 Mounting manual







