

NEWFANGLED AUDIO

Eventide®

Copyright 2016, Newfangled Audio

P/N: 141301

Eventide is a registered trademark of Eventide Inc.

Newfangled Audio and Elevate are trademarks of Orthogonal Art and Science, LLC.

AAX and Pro Tools are trademarks of Avid Technology. Names and logos are used with permission.

Audio Units is a trademark of Apple, Inc.

VST is a trademark of Steinberg Media Technologies GmbH.

All other trademarks contained herein are the property of their respective owners.

Elevate proudly uses the Eigen C++ library, which is available at <http://eigen.tuxfamily.org>.

Elevate also proudly uses the PFFFT library, which is available at <https://bitbucket.org/jpommier/pffft>.

Newfangled Audio

www.newfangledaudio.com

Eventide Inc.

One Alsan Way

Little Ferry, NJ 07643

201-641-1200
www.eventide.com

Contents

1	Newfangled Audio Elevate	1
1.1	A Word About Loudness	2
2	Installation and Instantiation	3
2.1	Registering Your Plug-in	3
2.2	Activating Your License	4
2.3	Installing Your Plug-In	4
2.4	Moving or Removing an Activation	4
3	Preset Bar	6
3.1	Preset Selector	6
3.2	Preset Load and Save Buttons	6
3.3	Compare	7
3.4	Gain Lock	7
3.5	Info	7
3.6	Settings	7
3.7	Color Scheme	7
4	Parameters and Metering	8
4.1	Controls	8
4.2	Global Parameters	9
4.2.1	ACTIVE	9
4.2.2	MATCH LEVEL	9
4.2.3	INPUT AND OUTPUT LEVEL and BAR METERS	10
4.3	PARAMETER PAGES	11
4.4	MAIN PARAMETERS PAGE	11
4.4.1	LIMITER SECTION	11
4.4.2	TRANSIENT EMPHASIS SECTION	13
4.4.3	SPECTRAL CLIPPER SECTION	14
4.5	FILTER BANK SUB-MODULE PAGE	14
4.5.1	AUDITORY FILTER BANK	15
4.5.2	MEL/CUSTOM	15
4.5.3	SOLO BUTTONS	16
4.5.4	INSERT FILTER	16
4.5.5	REMOVE FILTER	16
4.5.6	FILTER CENTER FREQUENCIES	16
4.5.7	FILTER BANK DISPLAY	16
4.6	LIMITER/EQ SUB-MODULE PAGE	17

4.6.1	GAIN PER BAND	17
4.6.2	RESET GAINS	17
4.6.3	BAND SOLO	17
4.6.4	DRAW CURVE	18
4.6.5	METERING	18
4.7	TRANSIENT SUB-MODULE PAGE	18
4.7.1	TRANSIENT EMPHASIS PER BAND	19
4.7.2	RESET TRANS	19
4.7.3	BAND SOLO	19
4.7.4	DRAW CURVE	19
4.7.5	METERING	19
4.8	CLIPPER SUB-MODULE PAGE	19
4.9	METERS	20
4.9.1	INPUT and OUTPUT BAR METERS	21
4.9.2	CENTER SECTION METER	21
4.9.3	SCROLLING INPUT/OUTPUT METER	22
4.9.4	SCROLLING GAIN REDUCTION METER	23
4.9.5	FILTER BANK METER	24
5	Conclusion	25
6	About Newfangled Audio	26

Chapter 1

Newfangled Audio Elevate



Newfangled Audio's Elevate plug-in is a professional audio grade mastering limiter and audio maximizer designed to transparently increase the loudness of your audio signal while maintaining or improving the dynamic perception and tonal balance of your mix. The Elevate limiter uses several new technologies to achieve this goal, but the central idea is to use an auditory filter bank to separate the audio into frequency bands similar to the frequency curve in the human ear, it then uses adaptive algorithms to recombine these frequency bands to give you maximum flexibility while avoiding artifacts like distortion, pumping, or shifts in the stereo image or tonal balance. In addition to the adaptive algorithms the MULTIBAND parameter pages allow you to tweak this mixture, giving you control over the tonal balance and transients even after the final limiting stage. Finally, the UI has been designed to give you fast and easy control over every aspect of the final master, as well as giving you clear and accurate metering to help you make good decisions quickly.

1.1 A Word About Loudness

Audio maximizers are designed to increase and balance the loudness profile of your audio while maintaining a high quality sound. This is an important audio processing step, especially when the quality of sound reproduction systems and listening environments can vary. However, there is such a thing as too loud. When audio is consistently too loud it can lead to listening fatigue for the user and a sub par experience. While an audio maximizer can be an essential tool which will help you get a good audio mix across a range of listening systems it's wise to pay attention to the overall mix levels and aim for the best sound quality not necessarily just the loudest audio when determining the setting of Elevate's parameters.

Chapter 2

Installation and Instantiation

Like other plug-ins Eventide distributes, Elevate uses PACE's iLok.com licensing system, with or without an iLok hardware dongle. Each license provides two activations which can reside on either your computer or on an iLok license dongle. Once you've purchased your plug-in, you'll need to register it on Eventide's website, activate your license, and install the plug-in on to your computer.

2.1 Registering Your Plug-in

When you purchase Elevate, you'll receive a Serial Number and License Key. The Serial Number will be two letters followed by 6 numbers. If you have an individual Elevate license, the Serial Number will start with NL (i.e. NL-#####). The License Key will be 3 sets of 4 characters, a letter or a number, each; like XXXX-XXXX-XXXX.

Once you've received these codes, you can register your plug-in on the Eventide website. To do so, please log in to <http://www.eventideaudio.com>, navigate to My Account in the top right corner, and select Register a New Product. Then, fill out the form by selecting Native Plug-in (VST, AU, AAX) in the Product Category field, select Elevate in the Product list, and enter your Serial Number, License Key, and iLok.com account name. If you don't yet have an iLok.com account, you can create one for free at <http://www.ilok.com>. Once you've done so, press Register.

Once you've entered this information and pressed the Register button, Eventide will send the applicable plug-in license to your iLok.com account, which you will need to activate to your computer or iLok dongle.

2.2 Activating Your License

To activate and manage your plug-in licenses you'll need to install PACE's iLok License Manager software which you can download from <http://www.ilok.com>. If you don't have this software installed, please download and install it now.

Once you have installed and launched iLok License Manager you should be able to log in to your account by clicking the large Sign In button in the upper left hand corner of the application. Once you have, you should be able to see available licenses by choosing the Available tab at the top of the iLok License Manager application. If you have successfully registered your plugin, your Elevate Native license will be available in this list. Please activate this license by dragging it to either your computer or iLok dongle listed on the left. When you do so, you will be asked to confirm the activation, and you will be able to see it by clicking on the location you have chosen. At this point your license is activated.

2.3 Installing Your Plug-In

You should have been given a link to the Elevate plug-in installer when you purchased your plug-in, but if you haven't, you can find downloads for all of Eventide's Native Plug-Ins at <http://www.eventideaudio.com/products/plugins>. Please download and launch the correct installer for your system.

Once you've launched the plug-in installer, it will take you through several pages of options. We have tried to choose defaults for these options which will best serve the majority of users, but it is worth a minute to make sure you understand these options before clicking through to the next page. A common issue with Windows VST plug-ins is choosing the correct VST directory, which can be different on each system. Please pay special attention to this setting. Once you have followed through the installer, your plug-ins and presets should be in your chosen locations, and you can hit finish to end the installer application.

At this point, you should be ready to use your Elevate Plug-In.

2.4 Moving or Removing an Activation


If at any point, you decide to move your plug-in activation, you can do so in iLok license manager. To move an activation between an iLok dongle and your computer, simply plug in the iLok, locate the license in its current location, and drag it to its new location. To deactivate a license, find it in its location, right click on it, and choose deactivate.

Remember that each Elevate Plug-In License comes with two activations, which can be used on either a computer or iLok dongle, meaning you can use Elevate in two locations at the same time.

Chapter 3

Preset Bar

At the very type of the Elevate plug-in is a preset bar which allows you to load and save preset, as well as a couple other features. These are the preset bar sections.



3.1 Preset Selector

On the far left is a drop-down menu which allows you to select preset from a tree structure. These presets are stored in your `Documents\Eventide\Elevate/Presets` folder if you need to access them on your computer.

Next to the preset drop-down menu is a left and right arrow, which allow you to quickly scroll through presets.

3.2 Preset Load and Save Buttons

To the right of the preset selection arrows is a LOAD and SAVE button. LOAD will allow you to load a .tide preset from anywhere on your computer. Save will allow you to save a new preset to anywhere on your computer, however, we suggest that you place it somewhere in the `Documents\Eventide\Elevate/Presets` folder so you can access it from the file dropdown.

3.3 Compare

The COMPARE button will allow you to toggle between the current settings and the last saved or loaded preset. If you have settings that you like, save them as a preset, and as you tweak you can always return to them using the COMPARE button.

3.4 Gain Lock

The purpose of Elevate is to add gain to your audio, however, the presets give you slightly different takes on this. For this reason, just flipping through presets can be jarring if they're all stored with different amounts of gain. The GAIN LOCK button solves this problem by locking all the gain related parameters so the total level settings in the plug-in won't change and you will get fair comparisons. Specifically, this button will cause the GAIN, DRIVE, CEILING, INPUT LEVEL, and OUTPUT LEVEL values to not be updated based on the preset settings so they will remain the same as you are currently listening to. The one exception is that the ratio of the GAIN to DRIVE setting will be updated based on the preset values but the total amount of GAIN + DRIVE will not be, so the sound will change, but the requested gain will not.

3.5 Info

The INFO button will open this manual for you to read about the plug-in.

3.6 Settings

The SETTINGS button will open a sub page with additional plug-ins settings. At the moment, these are settings related to the OpenGL meter behavior and Dithering options.

3.7 Color Scheme

On the far right is a drop-down labeled COLOR SCHEME. This will allow you to choose one of several different color schemes for your viewing pleasure.

Chapter 4

Parameters and Metering

Elevate is designed to be incredibly easy to use, but also incredibly powerful. The MAIN PARAMETERS page exposes ten core parameters which give you control over an adaptive limiter, transient engine, and final clipping stage. If you want to tweak further, Elevate also exposes band parameters for the filterbank and each band in the 4 Elevate sub modules. In addition to this, Elevate shows you several different kinds of metering to keep an eye on what's happening. Here are brief descriptions of these pages, along with some of the other features of the plug-in.

4.1 Controls

Elevate has several control types, including vertical and horizontal sliders, rotary knobs, drop-down menus, and toggle and radio buttons, all of which have tool-tips which will give you more information about their function if you hover your mouse above them.

In general, all sliders and knobs can be double clicked to type in a specific value, option-clicked to return them to their default value, or command-clicked or control-clicked to enter a vernier mode for fine tuning. In addition, some controls support special shift-click functionality, such as using shift-swipe to draw an EQ curve, or shift clicking the gain sliders to set output level compensation. Where available, these shift-click functions are mentioned in the tool-tips for the individual controls.

Where appropriate, most controls have a related on/off button which will deactivate this control, or even the entire section. Turning sections off when you're not using them can reduce the amount of processing power used by Elevate.

4.2 Global Parameters

4.2.1 ACTIVE




The ACTIVE button activates or bypasses all the processing in the plug-in. If the nearby Match Level button is on, the inactive state will apply the equivalent clean gain that you are asking for in the ACTIVE state. If you have enough headroom, this will allow you to compare the output of the Elevate plug-in at the same theoretical level to more easily hear what effects the processing is having on your sound. Realize that if you don't have enough headroom on your master fader this will cause the output of your DAW to clip.

4.2.2 MATCH LEVEL

As mentioned above, MATCH LEVEL will boost the dry signal when the plug-in is inactive in order to allow you to compare the limited signal to the non-limited signal with the same amount of gain. This can give you a fair comparison between the clean and effected audio and help you understand what artifacts the algorithm may be imparting. When MATCH LEVEL is on and the plug-in is inactive the output level will likely be much higher than 0 dBfs, so make sure you have appropriate headroom in your playback system to avoid clipping.

4.2.3 INPUT AND OUTPUT LEVEL and BAR METERS



Above the INPUT meter is a knob for the MASTER INPUT LEVEL, and above the OUTPUT meter is an AUTO button for setting the MASTER OUTPUT LEVEL. By default AUTO is off and adding gain will result in a louder sound. However, if you turn the AUTO output level button on, the MASTER OUTPUT LEVEL will be reduced by the total amount of GAIN and DRIVE added to the signal. This will allow you to easily compare the limited sound to the bypassed sound and determine that you are still getting transparent limiting. This is a very handy feature, but make sure to turn AUTO off before bouncing your final track, or else you will be reducing the peak gain, rather than increasing the RMS gain.

If you'd prefer not to use the AUTO button to set the MASTER OUTPUT LEVEL and would like to set it manually instead, clicking the down arrow next to the AUTO button will allow you to select a manual mode which will display a knob for the MASTER OUTPUT LEVEL. The MASTER INPUT LEVEL is just before the INPUT meter and the MASTER OUTPUT LEVEL is just before the OUTPUT meter, these controls should be used as TRIM controls only when you are targeting an input or output standard other than 0 dBfs, or when the input signal is too low or too high as indicated by the INPUT


or INPUT/OUTPUT meter.

4.3 PARAMETER PAGES

Most of Elevate's most important controls are on the MAIN PARAMETERS page. Many times you will be able to get the results you want without ever leaving this page. However, there are also four ELEVATE SUB-MODULE pages which are arranged to show the flow of audio through Elevate's sub-modules. We will discuss the parameters on each of these pages here.

4.4 MAIN PARAMETERS PAGE

The MAIN PARAMETERS page contains the primary parameters for making the input signal louder while avoiding artifacts. It contains 5 parameters for the LIMITER, 2 parameters for the TRANSIENT EMPHASIS section, and 2 for the SPECTRAL CLIPPER.



4.4.1 LIMITER SECTION

On the left hand side is the LIMITER section. You will see sliders for the standard limiter parameters GAIN and SPEED (sometimes called threshold and release) as well as a slider for CEILING. Below these parameters you will see knobs for ADAPTIVE GAIN and ADAPTIVE SPEED, these control the adaptive algorithms that reduce audible artifacts and make Elevate so powerful. Elevate works by using an auditory filter bank to split the signal into the critical bands of human hearing, then using these adaptive

algorithms to know when and where to best apply limiting. If you deactivate the ADAPTIVE parameters and the PER BAND parameters on the EQ and TRANSIENT pages, the LIMITER will act as a standard single band limiter, but that would be boring.

NUMBER OF FREQUENCY BANDS

The first stage of signal processing is the FILTER BANK and next to the LIMITER section label is a drop down that allows you to select the number of frequency bands being used by the adaptive algorithms in both the LIMITER and TRANSIENT sections. This can be viewed as a resolution parameter for the core Elevate algorithms, as is set to the maximum by default. However, this can use a lot of processing power, and the number of bands can often be reduced and still provide good results. If you find that you're running out of processing power, just select a smaller value.

More fine tuning of these frequency bands can be done on the FILTER BANK sub-module page.

GAIN

The GAIN is the amount of gain you wish the ELEVATE limiter to apply. In a nod to the compression that happens in mastering limiters this control is often called threshold, but we felt that GAIN was more appropriate given the purpose of this control. The ELEVATE limiter uses an optimally soft knee to allow very fast release times while producing minimal distortion. To the left of GAIN is a button which will allow you to deactivate this part of the algorithm.

ADAPTIVE GAIN

The ADAPTIVE GAIN parameter allows the algorithm to adapt the gain applied to each frequency band individually, allowing more gain reduction to be applied to the loudest bands if the signal is near the limit. Note that similar to a multi-band limiter this has the potential to effect the tonal balance of your mix if used too heavily. The setting is the number of dB by which each band can stray from the others. To the left of ADAPTIVE GAIN there is a button which will allow you to deactivate this part of the algorithm.

SPEED

The SPEED parameter is the combined attack and release time of the LIMITER. Moving this slider up speeds up the dynamics of the LIMITER and

allows higher output levels, but also introduces the possibility of distortion. The perception of distortion and therefore the best setting is highly program dependent so pick the best setting for your mix.

ADAPTIVE SPEED

The ADAPTIVE DYNAMICS parameter adapts the attack, release, and look-ahead parameters for each filter band and greatly reduces “pumping and breathing” artifacts as well as perceived distortion.

CEILING

The CEILING slider allows you to set the maximum output level of the plug-in. This affects the behavior of both the LIMITER and SPECTRAL CLIPPER.

4.4.2 TRANSIENT EMPHASIS SECTION

Look-ahead style mastering limiters have a tendency to squash transients and reduce the dynamic impact of music. Elevate alleviates this problem by re-emphasizing these transients and driving them into a clipper stage. The MAIN PARAMETERS page shows TRANSIENT EMPHASIS and ADAPTIVE TRANSIENT controls.

TRANSIENT EMPHASIS

The TRANSIENT EMPHASIS slider allows you to compensate for the squashing effect by allowing fast transients through the limiter or even emphasizing them for a more explosive sound. To the left of TRANSIENT EMPHASIS is a button which allows you to deactivate this part of the algorithm.

ADAPTIVE TRANSIENT

The ADAPTIVE TRANSIENT parameter allows the TRANSIENT EMPHASIS engine to be adapted to each filter band individually. Settings in between 0% and 100% make sure that adjacent bands are similarly emphasized, but that distant bands are not. This allows transients from kick drums, snares, and cymbals to maintain their impact while not effecting the entire mix or each other. TRANSIENT EMPHASIS and ADAPTIVE TRANSIENT are powerful parameters, so use with care. To the left of ADAPTIVE TRANSIENT is a button which allows you to deactivate this part of the algorithm.

4.4.3 SPECTRAL CLIPPER SECTION

The SPECTRAL CLIPPER sits at the end of the signal chain and allows you to clip transients, or even drive the entire signal into it. Its innovative design allows it to overdrive a signal without affecting the tonal balance or allowing the signal to get “tubby”, which makes it ideal for overdriving an entire mix. Clipping short transients is often the ideal way to increase level without introducing pumping, and using the DRIVE parameter will allow you to add an extra oomph to more aggressive styles of music. These parameters are duplicated on the CLIPPER page along with a graphical indication of their behavior.


DRIVE

The DRIVE parameter allows you to increase the LIMITER output into SPECTRAL CLIPPER to increase loudness and distortion. It does this according to a gain curve determined by the SHAPE parameter.

SHAPE

The SHAPE parameter changes the shape of the gain curve from soft to hard. This clipper uses an ideal set of shapes which allow for maximum boost with minimal added harmonic content. When DRIVE is 0 dB no gain is being provided and the soft and hard SHAPES are the same.

4.5 FILTER BANK SUB-MODULE PAGE



The Elevate plug-in uses a triangular filter bank to split the input signal into a number of frequency bands that resemble the critical bands in the human ear. The FILTER BANK parameter page allows you to control the filters that split the input signal into these frequency bands. This filter bank outputs a number of audio streams which the adaptive algorithm uses to set the gain reduction across bands. In general, the higher the number of bands, the more fine grained control the adaptive algorithms will have, and the more gain you can add before hearing artifacts. However, a larger numbers of bands does increase the algorithms processing requirements significantly, and increasing the number of bands may not always produce a noticeable increase in quality.

The number of bands selected in the auditory FILTER BANK will change the number and frequency of bands in the graphic EQ and TRANSIENT emphasis pages. Selecting the 1 BAND option will also deactivate the ADAPTIVE parameters, as these work across the bands. By selecting 1 BAND you are turning the limiter section into a standard look-ahead limiter, with transient emphasis.

4.5.1 AUDITORY FILTER BANK

This drop-down allows you to select the number of bands you are splitting the signal into. Setting the number of bands using this drop-down will automatically space them on the mel scale between the minimum value and the maximum value.

4.5.2 MEL/CUSTOM

This set of interactive radio buttons allow you to distribute the filter center frequencies using the MEL scale or a CUSTOM scale of your choosing. The MEL scale is an auditory scale based on the perceptual distance between pitches, selecting MEL will equally distribute the chosen number of filters between the current minimum frequency and current maximum on the MEL scale. CUSTOM is selected by either choosing the radio button, or by moving any of the filter center frequencies away from their MEL based values. By customizing the filter bank to your program material you can use the EQ and TRANSIENT pages to hone in on particular frequency ranges that are important in your program material. For instance you might choose one filter to focus on the resonant frequency of a kick drum, and another for the bass guitar and use the EQ and TRANSIENT pages to increase punch in just the bass drum without effecting the relative loudness of the bass guitar.

4.5.3 SOLO BUTTONS

There is a set of toggle buttons which allow you to solo the output of one band, or for a number of bands by shift-clicking or ctrl-clicking. These are the same solo buttons that appear on the EQ and TRANSIENT pages.

4.5.4 INSERT FILTER

The (+) button beneath the solo for the selected band will insert a new filter with a center frequency between the band chosen and the one to it's right. This can be especially helpful if you find you need more resolution in an area when fine tuning the filter center frequencies. If you are already using the maximum number of filters, the INSERT FILTER buttons will be greyed out.

4.5.5 REMOVE FILTER

The (-) button beneath the solo for the selected band will remove the current band without effecting the center frequencies of the surrounding bands. This can be helpful if you find one or more bands to be redundant while fine tuning center frequencies.

4.5.6 FILTER CENTER FREQUENCIES


There are also a set of text box sliders that allow you to set the CENTER FREQUENCY of each band. By default these are set to match the critical bands of the human ear, however these bands can be fine tuned to more closely match important frequency ranges in your program material as well. Doing so will allow you to use the band specific gain and transient sliders in the other sub-modules to fine tune your result.

4.5.7 FILTER BANK DISPLAY

The FILTER BANK DISPLAY shows you the relative distance and shape of each filter using the MEL scale. This will help you visualize how the filters are arranged across the auditory spectrum. The triangular shape of these filters help adjacent band have some amount of similarity, leading to a smoother overall sound.

4.6 LIMITER/EQ SUB-MODULE PAGE

The LIMITER/EQ sub-module page allows you to fine tune the GAIN settings for each frequency band and see the relative gain reduction being applied. The GAIN and ADAPTIVE GAIN parameters are the same as on the MAIN PARAMETERS page, but each filter band now also breaks out:



4.6.1 GAIN PER BAND

A GAIN slider which allows you to adjust the amount of additional gain or cut to be applied to the band, similar to the Equivocate graphic equalizer. You can set these slider individually by clicking and dragging, or draw a curve by shift-clicking and dragging across the parameter field. These gains can also be deactivated by clicking on toggle button to the left of the GAIN PER BAND title.

4.6.2 RESET GAINS

Clicking the RESET GAINS button will reset all gains to 0dB.

4.6.3 BAND SOLO

A SOLO button which allows you to hear the output of this or a combination of bands. This can allow you to zero in on the effects of the parameters from a specific band to either find problem spots, or better

understand what the algorithm is doing. When a SOLO is active the entire algorithm is still running across all bands, but you are simply changing what you can see and hear.

4.6.4 DRAW CURVE


Clicking the DRAW CURVE button will allow you to draw a single gain curve across all the GAIN sliders. Turning this off will allow you to fine tune each GAIN slider individually. Whichever mode you're in you can use the opposite behavior by pressing the shift key.

4.6.5 METERING

Drawn behind the sliders for each band is an input, output, and gain reduction meter for each band. These are the same meters shown in the FILTER BANK meter page in the top section of the GUI. Note that this meter is slowed down from the gain reduction actually applied to the signal to make it easier to view. This metering is a good way to see the effects of the ADAPTIVE GAIN control.

4.7 TRANSIENT SUB-MODULE PAGE

The TRANSIENT sub-module page allows you to fine tune the TRANSIENT EMPHASIS for each band. The TRANSIENT EMPHASIS and ADAPTIVE TRANSIENT parameters are the same as are on the MASTER PARAMETERS page, but each filter band now also breaks out:



4.7.1 TRANSIENT EMPHASIS PER BAND

A TRANSIENT EMPHASIS slider which goes from 0% to 200%. This allows you to reduce or increase the amount of TRANSIENT EMPHASIS being applied to each band. This can be helpful for bringing out just the transients in particular frequency ranges, like kick or snare drums. The effects of these additional transient emphasis controls can be turning off using the toggle button next to the TRANSIENT EMPHASIS PER BAND title.

4.7.2 RESET TRANS

Clicking the RESET TRANS button will reset all transient emphasis sliders to 100%.

4.7.3 BAND SOLO

A SOLO button which allows you to hear this output of this or a combination of bands. This is the same SOLO button available on the MULTIBAND GAIN parameter page and its state will transition across pages.

4.7.4 DRAW CURVE

Clicking the DRAW CURVE button will allow you to draw a single gain curve across all the TRANSIENT sliders. Turning this off will allow you to fine tune each TRANSIENT slider individually. Whichever mode you're in you can use the opposite behavior by pressing the shift key.


4.7.5 METERING

And a TRANSIENT EMPHASIS meter which shows the amount of TRANSIENT EMPHASIS being applied to each band. These meters will show you the effect of the ADAPTIVE TRANSIENT slider well. Similar to the FILTER BANK meters these are slowed down to give you a better sense of the spectral ramifications of the transient emphasis section. These meters are a good way to see the effects of the ADAPTIVE TRANSIENT control.

4.8 CLIPPER SUB-MODULE PAGE

The final stage of the Elevate plug-in is the SPECTRAL CLIPPER. This clipper is primarily designed for clipping the fast transients allowed through the transient emphasis section, but also allows you to add up to an additional 12 dB of distortion based gain. The SPECTRAL CLIPPER uses an


optimal soft clipping curve to add the minimal amount of harmonics for a particular gain setting, as well as a special frequency domain algorithm to avoid the low-passed “tubby” sound that can be produced when over-driving full bandwidth audio. The SPECTRAL CLIPPER parameter page allows you to control the DRIVE and CLIPPER SHAPE of the SPECTRAL CLIPPER using duplicates of the parameters found on the MAIN PARAMETERS page. An animated meter below indicates the shape of the clipper by mapping it’s output on the Y axis to it’s input on the X axis. A meter also shows what the level in to and out of the SPECTRAL CLIPPER is at any given moment.



4.9 METERS

In addition to the plug-ins parameters there are a selection of meters available.

4.9.1 INPUT and OUTPUT BAR METERS




The left and right hand sides of the plug-in have matching vertical bar meters which display the INPUT (on the left) and OUTPUT (on the right) levels in Peak (horizontal ticks), RMS (solid bar and numerical display), and Peak Hold (numerical display) formats. Additionally, the right hand side includes a global gain reduction meter, which shows the maximum gain reduction being applied across the bands at any given moment. These meters are always present in the display and clicking the Peak Hold section, or bypassing the plug-in will clear the held peak value.

4.9.2 CENTER SECTION METER


Additionally, the top center section allows you to see one of:

4.9.3 SCROLLING INPUT/OUTPUT METER




The scrolling INPUT/OUTPUT meter displays the input peak value overlaid with the output peak value over time. This allows you to visualize the INPUT level over time as the top of the solid color, the OUTPUT level over time as the top of the overlaid color, and the amount of GAIN being applied by the processing as the width between these. This meter also gives an indication of when the INPUT level exceeds the output when the input pokes out over the output. For instance, in the NEW-FANGLED color scheme, if the red input curve is poking out above the green curve it's an indication that you may want to use the MASTER INPUT LEVEL control to reduce the input level and make this up with the GAIN control.

4.9.4 SCROLLING GAIN REDUCTION METER



The scrolling GAIN REDUCTION meter displays a combination of GAIN REDUCTION and TRANSIENT EMPHASIS for each active band. It has two views. In "Stack Waveforms" view each individual GAIN meter is stacked on top of each other with the same dB scale. Lower frequencies are displayed in a darker color while higher frequencies are displayed in a lighter color. This meter give you a good view of the dynamics of each gain signal over time (they can be quite fast), and allows you to see how the parameters are effecting these gain signals. In "Spread Waveforms" view, each individual GAIN meter is has it's own waveform, with the low frequencies being represented on the bottom and the high frequencies being represented on top. This is good at showing relative gain and gain reduction for each band over time, and shows how the adaptive algorithms are working well. This is probably the best meter to show you what Elevate is doing over both time and frequency.

4.9.5 FILTER BANK METER



Finally, the FILTER BANK meter is a bar graph showing the input level, output level, and gain reduction for each individual band. These meters are slowed down to show you an average amount of level and gain reduction over time to get a better sense of the tonal effects of the processing being applied. While the GAIN REDUCTION meter gives a good indication of the dynamics of the Elevate algorithm, the FILTER BANK meter gives a good indication of the frequency distribution in the input and the output.

Chapter 5

Conclusion

We hope you enjoy Newfangled Audio's Elevate plug-in. If you have any questions, comments, or concerns please write us at support@eventide.com.

Chapter 6

About Newfangled Audio

The Oxford English Dictionary defines Newfangled as “objectionably new”.

Music technology can sometimes be a backward looking pursuit. This is understandable, the purpose of music technology should be to help musicians make great music. There have been many great pieces of gear in the past and we should seek to keep these pieces and make them available to people who want to use them, and the time and dedication required to master a musical instrument means that changes in their design are often evolutionary rather than revolutionary.

However, the great pieces of gear from yesteryear are more often than not those that contained new ideas in their time. The reverence we have for these pieces can sometimes turn into fetishism, and mindless re-creation of classic gear can fail to inspire musicians and artists to take new risks. It’s important to make sure artists and engineers have access to good tools that inspire them and don’t stand in their way, but these tools should never be used as a security blanket to stand in the way of an artist or engineers ears and taste.

Newfangled Audio seeks to only make gear that incorporates new ideas. We want to make gear that is great, but only using ideas that others are not. We realize that deviation from the norm might sometimes be objectionable. The Oxford English Dictionary defines Newfangled as “objectionably new”.