



EZT1011



EZI120

SET 810-S Personal TV Listening System

Set Set 810-S Personal Listening System is an easy-to-install, easy-to-use infrared system consisting of a TI810 infrared stereo/mono transmitter and an RI810-S infrared stereo/mono bodypack receiver. The TI810 transmitter is simply connected to the audio output socket of a television set or hi-fi system. The body pack receiver has a large, easy-to-use volume control. It can be coupled with an induction neck loop (hearing aid must have a telecoil), direct audio connection (to a behind-the-ear hearing aid) or headphones.

Features/Benefits

- Large volume control makes it easy to adjust to the desired level
- Compression driver attenuates loud passages (e.g. commercials) and boosts soft passages for a more even audio level and better speech intelligibility
- Stereo or mono operation for total integration with the sound source
- Includes external microphone for easy connection to TVs not equipped with an audio output socket
- Transmitter with charging cradle and a separate compartment for a spare battery
- Receiver battery includes a quick charge so it can be ready to use in 3 hours

Technical Data

Modulation:	FM, stereo
Carrier frequencies:	2.3/2.8 MHz
Signal-to-noise ratio:	60 dB(A) eff
THD, total harmonic distortion:	< 2 %
Sound pressure level (SPL):	> 125 dB(SPL)
Range:	40'
Coverage area:	600 sq. ft.
Audio-XLR connector:	3.5 mm, stereo/mono
Microphone connector:	2.5 mm
Operating time (Receiver):	4 hours
Weight (Transmitter):	3 oz
Dimensions (Transmitter):	5" D x 1 3/4" H
Weight (Receiver):	1.8 oz
Dimensions (Receiver):	3 1/2" H x 2 1/4" W x 1" D

Supplied Accessories:

- RI810-S Receiver
- BA151 Rechargeable battery
- TI810 Transmitter
- NT810 Power adapter, 24VDC
- S7797 Audio cable with 1/8" male mini plug and 1/4" adapter
- RCA cable, 1/8" female mini plug to dual male RCA plugs
- MKE800-TV External microphone

Product Variant:

Set 810 TV listening systems includes a stethoset receiver.



PX30

Optional Accessories:

EZT1011 Induction neck loop (hearing aid must be equipped with a telecoil)

EZ1120 Induction silhouette (hearing aid must be equipped with a telecoil) —connecting cable is required

HZL30-6 Monaural connecting cable for use with EZ1120 silhouette

HZL32-6 Binaural connecting cable for use with two EZ1120 silhouettes

HZL34-6E Monaural direct audio input cable with Euro plug for behind-the-ear hearing aids with a boot/shoe

HZL36-6E Binaural direct audio input cable with Euro plug for two behind-the-ear hearing aids with boot/shoe

PX30 Portable headphone

Sennheiser Electronic Corporation, 1 Enterprise Drive, Old Lyme, CT 06371

Telephone: 860-434-9190 • Fax: 860-434-1759 • Web: <http://www.sennheiserusa.com>

Sennheiser Mexico: Av. Xola 613, PH6, Col. Del Valle 03100, Mexico, DF. Telephone: (525) 639-0956. Fax: (525) 639-9482

Sennheiser Canada: 221 Labrosse Ave, Pte-Claire, PQ H9R 1A3. Telephone: 514-426-3013. Fax: 514-426-3953

Manufacturing Plant: Am Labor 1, 30900 Wedemark, Germany