- Consult the dealer or an experienced radio/TV technician for help. which the receiver is connected.
- Connect the equipment into an outlet on a circuit different from that to
 - Juckesse the separation between the equipment and receiver.
 - Reorient or relocate the receiving antenna.

more of the following measures;

and on, the user is encouraged to try to correct the interference by one or television reception, which can be determined by turning the equipment off installation. If this equipment does cause harmful interference to radio or However, there is no guarantee that interference will not occur in a particular the instructions, may cause harmful interference to radio communication. radio frequency energy and, if not installed and used in accordance with in a residential installation. This equipment generates, uses, and can radiate are designed to provide reasonable protection against harmful interference Class B digital device, pursuant to Part 15 of the FCC Rules. These limits I his equipment has been tested and found to comply with the limits for a

in this manual could void your authority to operate this equipment. You are cautioned that any changes or modifications not expressly approved

interference that may cause undesired operation. and (2) this device must accept any interference received, including following two conditions: (1) this device may not cause harmful interference, This device complies with Part 15 of FCC rules. Operation is subject to the

COMPLIANCE WITH FCC RULES (USA ONLY)

paffecies, simply use them as you normally would and then recharge them. two or three times before they reach peak performance. Io cycle the • It is often necessary to cycle new or deeply discharged Ni-MH batteries

> 2000 mAh Mi-IMH or similar type batteries. For best performance and optimal safety, use only the included

pecome warm during recharging.

• It is not abnormal for the charger and the rechargeable batteries to Ваттегу Сћагдег

ОРЕВАТІИС РЯЕСАUТІОИS

numérique de la classe B est conforme à la norme MMB-003 du Canada. This Class B digital apparatus complies with Canadian ICES-003. Cet appareil

CANADA ONLY

systems available.

- Contact your local government for information regarding the collection collection facilities.
- Do not dispose the batteries as unsorted municipal waste; use separate

RECYCLING OF NI-MH BATTERIES

sunlight, fire or the like.

- Do not expose batteries or charger to excessive heat such as direct disconnect the AC adapter quickly.
- you can easily grasp the AC adapter at anytime. In case of emergency,
- The charger should be located close enough to the AC outlet so that
 - Replace batteries only with the same or equivalent type. • The battery rating label is on the bottom of the apparatus.
 - Danger of explosion if the wrong type of batteries are used.

 - Keep the charger out of reach of small children.
 - Do not use the charger in extremely cold or hot conditions.

NOTIONS

rue broduct.

- Do not place any objects filled with liquids, such as vases, on
- Do not open the cover. No user serviceable parts inside. or similar unit.
- Do not install this product in a confined space such as a bookcase tablecloths, curtains, etc.
- To prevent fire, do not cover the ventilation of product with newspaper, cauqles) on the product.
- To prevent fire, do not place any naked flame sources (such as lighted or splashes.
 - To prevent fire or shock hazard, do not expose this product to drips

DNINRAW

batteries or any other rechargeable batteries besides Ni-MH. To avoid personal injury and damage, do not attempt to charge alkaline This charger is designed only for Ni-MH rechargeable batteries.

DANGER

To reduce the environmental impact of a multi-language printed document, product information

Afin de réduire l'impact sur l'environnement de l'impression de plusieurs, les informations concernant les produits sont disponibles sur le site www.audio-technica.com dans une large sélection de langue.

is available online at www.audio-technica.com in a selection of languages

Para reducir el impacto al medioambiente, y reducir la producción de documentos en varios leguajes, información de nuestros productos están disponibles en nuestra página del Internet: www.audio-technica.com.

Para reduzir o impacto ecológico de um documento impresso de várias linguas, a Audio-Technica providência as informações dos seus produtos em diversas linguas na www.audio-technica.com.

Per evitare l'impatto ambientale che la stampa di questo documento determinerebbe, le informazioni sui prodotti sono disponibili online in diverse lingue sul sito www.audio-technica.com.

Der Umwelt zuliebe finden Sie die Produktinformationen in deutscher Sprache und weiteren Sprachen auf unserer Homepage: www.audio-technica.com. Om de gevolgen van een gedrukte meertalige handleiding op het milieu te verkleinen, is

productinformatie in verschillende talen "on-line" beschikbaar op: www.audio-technica.com. 本公司基於環保理由將減少多語言文件印刷, 陸續產品訊息可在 www.audio-technica.com 的官方網頁

本公司基于环保理由将减少多语言文件印刷,陆续产品信息可在www.audio-technica.com的官方网页

자원절약, 환경보호를 위해 국문 사용 설명서는 인쇄하지 않았습니다. 제품정보는 www.audio-technica.com 에서 원하는 언어 선택 후에 다운로드 받으실 수 있습니다.

Audio-Technica U.S., Inc. 1221 Commerce Drive, Stow, Ohio 44224 USA +1 (330) 686-2600 Audio-Technica Limited Old Lane, Leeds LS11 8AG England +44 (0) 113 277 1441 Audio-Technica (Greater China) Limited Unit K, 9/F., Kaiser Est. (Ph.2) 51 Man Yue St. Kowloon, HK. +852-2356-9268 Audio-Technica (S.E.A.) Pte. Ltd. No 1 Ubi View, #01-14 Focus One, Singapore 408555 +65-6749-5686 Audio-Technica Corporation 2206, Naruse Machida, Tokyo Japan

©2010 Audio-Technica U.S., Inc. audio-technica.com P52205 P# 2323-04430



Two-Bay Recharging Station

For use with 2000 Series wireless transmitters:

ATW-T210a UniPak® Transmitter ATW-T220a Handheld Transmitter



ATW-CHG2 Features

- Batteries are charged within the transmitters.
- Versatile unit charges ATW-T220a handheld transmitters and/or ATW-T210a UniPak® transmitters (in any combination).
- Built-in safety feature monitors cell voltage and automatically turns off the unit if problems are detected.
- Automatic shut-off if alkaline (non-rechargeable) batteries are installed.
- Automatic shut-off if damaged batteries are installed.
- Maintenance charging prevents battery self-discharge until the transmitter is removed from charger.
- Includes Ni-MH rechargeable batteries 2 x AA 2000 mAh

How to charge

- 1. Connect the power cord.
- 2.Set the transmitter's power switch to the off position. (Note: The transmitter's power is automatically turned off if the transmitter is set in the charger with its power switch on; in this case, the transmitter will resume operation when it is removed from the charger.)
- 3.Install the Ni-MH AA batteries in the transmitter, observing correct polarity as marked inside the transmitter. For installation instructions, see the 2000 Series installation & operation manual.
- 4. Insert the transmitter into the charger with transmitter charging contacts facing toward the charger's contact pins.
- 5. Power is supplied to the charging bay when the transmitter is set into the unit; at this point the red indicator of each port lights. (Note: If the red indicator does not light, poor contact may be the cause; set the transmitter in the charger again.)
- 6. When the charge is completed, the red indicator is turned off. (Note: Maximum charging time is about ten hours.)
- 7. The unit keeps charging with ultra-low current (maintenance charge) until the transmitter is removed from the charger.

LED Status Indication

Charger indicator status	Charging status	Transmitter status
Off	Power off	Transmitter not in unit
Red light	Charging*	Transmitter in unit
Red flashing	Charging error (Charging is stopped)	Transmitter in unit
Off	Charging is finished (Still maintenance charging)	Transmitter in unit

Note: Red flashing light (charging error) is caused by use of alkaline (non-rechargeable) or damaged battery.

Specifications*

Input Rating	12V DC, 320 mA (maximum)
Output Rating	3.2V DC, 320 mA x2
Charging Time	Approx. 10 hours (2000 mAh Ni-MH)
Operating Temperature	0~+40° C
Dimensions	Approx. 131.0 mm (5.16") W x 130.0 mm (5.12") D x 105.0 mm (4.13") H
Weight	Approx. 40 g (1.4 oz)

^{*}Specifications are subject to change without notice.



^{*}Note: If a transmitter with fully charged batteries is placed in the charger, the red light will remain on for a minimum of 3 hours, even though the batteries are fully charged.